


## Antenna Locations

Note: The location of the test is detailed in Section 10.1.



ANT 0: GSM 850/WCDMA 5/LTE 5/12/13/26/71/NR n5/ n12/n71
ANT 1: LTE 2/66
ANT 2: GSM 1900/WCDMA 2/4/LTE 2/4/25/48/66/NR n2/n48/n25/n66/n77
ANT 4: LTE 7/41/NR n30/n41
ANT 7: Wi-Fi 2.4G/5G/Bluetooth