

A Quick Look at Your Device



Using Your Headphones

Powering Your Headphones On and OFF

1. Press and hold the power button in order to power on your headphones. If you have paired your headphones to your Bluetooth device previously, they will automatically remain paired each time you power on your headphones. 2. Press and hold the power button in order to power off your headphones.

Listening to Music

 Play/Pause Button : Press to play or pause a track. **NOTE:** You can adjust volume and playback settings on your phone or connected audio device.

Using the Phone Function

Answering a Call: Quickly press the Answer button to answer an incoming call.
Ending a Call: Quickly press the Answer Call button to end a call.

Auxiliary Input Mode

To use your headphones with devices that are not Bluetooth enabled, plug one end of a standard 3.5mm audio cable into the Auxiliary Port on your headphones. Plug the other end into the headphone jack on your audio device.

2. Insert the USB charging cable's

Micro USB plug into the charging port on your headphones.

Pairing Your Headphones with a Bluetooth



3. Go to the Bluetooth settings menu on your phone.


Make sure that Bluetooth is turned on. Connect to the device listed as "

headphones.

Pairing Mode Blue & Red Flashing LED 2. The LED indicator light will alternately flash red and blue to indicate that your headphones are in pairing mode.




Charging Your Headphones



1. The included USB charging cable has a Micro USB plug and a standard USB plug.



4. The LED indicator light turns red while the headphones are charging. It turns blue once charging is complete.



3. Insert the USB charging cable's standard USB plug into the USB ports of a computer or suitable USB charging adapter.

Charging takes 1-2 hours. Unplug when charging is complete.

Important: To avoid a complete discharge of the battery, charge your headphones at least once every six months.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.