


BLACKLOUD™ SOUNDOT

Quick Guide

Package Contents



SOUNDOT Earbuds
(with Microphone and
Control Module)




Charging Cable
(Micro-USB)



Earbud Stabilizers
(2 pairs in Medium
and Large)



Carrying Pouch



Earbud Cushions
(3 pairs in Small, Medium,
and Large)




Attachable Clip



Quick Guide and Safety
Document


Your SOUNDOT Earbuds



- 1 Earbud Cushions
- 2 Volume Down Button
- 3 Volume Up Button
- 4 Microphone
- 5 Power/Function Button
- 6 Status Indicator LED
- 7 Charging Port (Micro-USB)

Charging Your Earbuds


Although your SOUNDOT earbuds come with a partially charged battery, it is recommended that you fully charge your earbuds before first use. To charge your SOUNDOT earbuds:



- 1 Open the charging port cover on the right earbud.
- 2 Connect the charging cable to the right earbud and either a PC or a dedicated USB charger.
- 3 Once your SOUNDOT earbuds start charging the status indicator LED will light up a solid red color. When your SOUNDOT earbuds are fully charged the status indicator will turn a solid blue color.

NOTE: On average your SOUNDOT earbuds takes about 2.5 hours for a full charge when connected to a PC, and about 1 hour when connected to a dedicated charger.

Pairing Your SOUNDOT Earbuds



Before you start using your SOUNDOT earbuds, you must first pair it with the Bluetooth®-enabled device you want to connect it to (such as a smartphone, PC, or digital music player).

To pair your SOUNDOT earbuds with a device:

- 1 Enable Bluetooth on the device you want to pair your SOUNDOT earbuds to.
- 2 Press and hold the power/function button on your SOUNDOT earbuds for about 8 seconds until the status indicator LED flashes blue/red alternately and you hear the "Pairing" voice prompt from your earbuds. Your SOUNDOT earbuds are now in pairing mode.

NOTE: If left inactive in pairing mode your SOUNDOT earbuds will automatically power off after 3 minutes.

NOTE2: You must enter pairing mode from a powered-off state. Pressing and holding the power/function button for more than 4 seconds from a powered-on state will turn the earbuds off.




3 Search for your SOUNDOT earbuds ("SOUNDOT v1.0") in the device's list of available connections. Once you have found your SOUNDOT earbuds in the list of available connections select them and accept any confirmation messages.

* The name for your SOUNDOT earbuds in the list of available connections may vary depending on the model purchased.

4 Once your SOUNDOT earbuds have been successfully paired with the device the status indicator will flash blue and you will hear a tone from your earbuds. The frequency of the flashes will depend on the type of Bluetooth connection your device utilizes, as seen in the table below:

Type of Device	Frequency of Flashes	Connection Type
iOS	Once every 8 seconds	AAC
Android™ and others	Twice every 8 seconds	SBC
Samsung Galaxy S® 4 & S5	Three times every 8 seconds	aptX

NOTE: Your SOUNDOT earbuds can store pairing information for up to 8 devices. To pair additional devices to your SOUNDOT earbuds ensure that your SOUNDOT earbuds are not concurrently connected to any device, then repeat the steps outlined above.



Powering On


Once you have successfully paired your SOUNDOT earbuds to a Bluetooth-enabled device your SOUNDOT earbuds will automatically connect with that device once they are powered on.

To power on your SOUNDOT earbuds:

- 1 Press and hold the power/function button for about four seconds. Once the status indicator LED flashes blue and you hear the "Hello" voice prompt from your earbuds, your earbuds have powered on.

NOTE 1: If you have stored pairing information for multiple devices and more than one of those devices have Bluetooth enabled, your earbuds will automatically connect with the most recently paired device.

NOTE 2: Once powered on, the default battery status meter for the SOUNDOT earbuds will be visible on iOS devices only. For Android and other non-iOS devices, support for a battery status meter will be available via free apps found in the device's respective app store.



Powering Off

To power off your SOUNDOT earbuds:

- 1 Press and hold the power/function button for about 4 seconds. Once the status indicator LED flashes red and you hear the "Goodbye" voice prompt from your earbuds, your SOUNDOT earbuds have powered off.

Listening to Music

When you are listening to music you can control playback through the controller on your SOUNDOT earbuds. The following table describes your SOUNDOT controller's various playback options:

Playback Option	Button	Action
Play/Resume Music*	Power/Function button	Press
Pause Music	Power/Function button	Press (during playback)
Increase Volume	Volume Up button	Press
Decrease Volume	Volume Down button	Press
Forward to Next Song	Volume Up button	Press and hold for 2 sec.
Rewind to Previous Song	Volume Down button	Press and hold for 2 sec.

* When audio playback is initiated your SOUNDOT earbuds will open your Bluetooth device's default music player. To set your device's default music player, refer to the device's user manual.

Making/Receiving Phone Calls

When your SOUNDOT earbuds are connected to a Bluetooth-enabled smartphone you can make* and receive phone calls directly using your SOUNDOT earbuds.

* Your smartphone must feature voice-dialing capabilities to make a call using your SOUNDOT earbuds. To confirm and configure the voice-dialing function for your smartphone, refer to your smartphone's user manual.

To make a phone call using your SOUNDOT earbuds:

- 1 Press and hold the power/function button for 2 seconds, then release the button. Your smartphone's voice-dialer will activate.
- 2 Speak directly into the microphone to direct your smartphone's voice-dialer to make a call.
- 3 To end the phone call, press the power/function button.

To receive/reject a phone call using your SOUNDOT earbuds:

- 1 When you hear the ringtone in your earbuds indicating an incoming call, press the power/function button to answer the call. Press and hold the power/function button to reject the call.
- 2 To end the phone call, press the power/function button.

More Information

For safety and warning information, please refer to the "Safety Document" included in the product's package.

For more information on your SOUNDOT earbuds and its various capabilities please check the user manual available on the company website: www.blackloud.com

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by [licensee name] is under license. Other trademarks and trade names are those of their respective owners. Android is a trademark of Google Inc.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Samsung and Galaxy S are both registered trademarks of Samsung Electronics Co., Ltd. © Samsung Telecommunications America, LLC.

BLACKLOUD Inc.

42 Corporate Park #250
Irvine, CA 92606 USA
888-783-0378
customerservice@blackloud.com
www.blackloud.com

