



VOLUME/CHANNEL ADJUSTMENT

On OFF position, press and hold the button "B" and turn on the transmitter. Press the button "A" to scroll through the channel numbers (01-25). Press the button "B" to adjust the volume level.

SAMPLING RATE SWITCH

On OFF position, press and hold the button "A" and turn on the transmitter. When there is "HI" icon on the display, it means that the device sampling rate is set at 16KHz; When there is none, it means that it is set at 8KHz. Do it again to switch the sampling rate.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.