

Remote Control

(VPR-6700)

1. Button cell CR 2032 have been pre-installed into the remote controll.
2. Remove the paper slip inside the battery cabinet to activate the battery power in the remote control before use.
3. Press button on the remote control to control vibration function:

Short press: receiver will ready for operation. Everytime button is pressed the massager will rotate through the different functions.

Long press (appx. 2 seconds): receiver will change the massager to stand by mode, meaning the vibration will stop, however the connection between the remote and massager is still active.

LED: whenever button pressed, LED light will activate to indicate signal is being sent to the massager.

4. Remove the battery cabinet from the massager for extended storage. Store the battery and the remote control separately.

SPECIFICATIONS

Frequency: 433.92MHz for USA ,

Control range: 6 meters in open area.

Remote battery: CR 2032 (1 battery)

Please put FCC warning as below mentioned.

FCC ID: 2ACLV6700

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.