



Speaker, Cube, LED

Model Name #16619




PACKAGE CONTENTS

- Cube speaker system
- USB Charge Cable
- User's Guide


CHARGING CUBE SPEAKER

Charge Cube with the included USB charge cable. Plug the micro end into the socket (5V IN) on the bottom of the speaker and the other end into a power USB port like on a computer, you may use any USB AC adapter that is available to charge your Cube speaker.




PLAYING MUSIC VIA BLUETOOTH MODE

1. Make sure the Cube Speaker is fully charged.
2. Turn Cube speaker on by pressing the power button at the top of the speaker. A blue LED will illuminate and colorful lights will begin flashing.
3. Follow the instructions for pairing that came with your Bluetooth® ON. Make sure your device is discoverable or in search mode.
4. Your device should discover "Speaker, Cube, LED". Select this profile. Once connected, colorful lights will blink slowly.
5. You are now connected and play your audio content wirelessly!



LED FEATURE

- With the built-in LED panels, Cube speaker can provide light show or illumination needs if necessary.
1. To turn on the Led, locate the led button on the bottom of the speaker, press once to turn it on.
 2. Cycle through different mode by continue pressing the Led button on the speaker.
 3. The music flash mode will only work if the speaker is paired and music is playing.



PLAYING MUSIC VIA AUX IN MODE

1. Make sure the Cube speaker is charged.
2. Turn the Cube speaker on by pressing the power button at the top of the speaker. A blue LED will appear when on.
3. Connected one end of the 3.5mm audio cable to the "AUX IN" port on the bottom of the unit. Connect the other end to the 3.5mm headphone jack of your audio device.

Note: Connecting the audio cable will override the Bluetooth® mode. Cube will automatically switch to auxiliary when the audio cable is connected.

4. Make sure the volume of your audio device is set to medium/low.

TROUBLE SHOOTING

Problem: Bluetooth® not connecting.

Solution: Please consult the User Guide of your Bluetooth® enabled audio device for instructions. Make sure that both of your audio device and cube speaker are discoverable and charged. Try rebooting the speaker by turning it off then back on. Make sure someone else is not already connected to the speaker.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.