




QUICK START GUIDE

INTRODUCTION TO THE DESKTOP

You must log on to your Microsoft account before the start up application can run.

RUNNING PROGRAMS

Select the Start  button on the desktop or keyboard to open the Start Menu. Applications and programs are displayed on-screen as widgets. Click on the widget to open the program.



OPERATING THE START MENU

To pin a program to the Start Menu, right-click the program and select "Pin to Start" to add the program to the Start Menu. (Screen 1)

To remove a program from the Start Menu, right-click the program and select "Unpin from Start" to remove the program from the Start Menu. (Screen 2)



(Screen 1)



(Screen 2)


FORCE RESET/SHUTDOWN

If the laptop freezes or is unresponsive, you may press and hold the Power button for 8-12 seconds to force the laptop to shutdown.

EVOO customer service center directly at CustomerService@evooproducts.com or \call (888) 999-1675.



TECHNICAL SPECIFICATIONS



- 1 Power
- 2 Micro SD Slot
- 3 USB 2.0
- 4 Earphone
- 5 Touchpad
- 6 Camera
- 7 Touchscreen
- 8 DC In
- 9 USB 3.0
- 10 Mini HDMI

PRODUCT BOX CONTENT

- Laptop
- Charger
- QSG
- Warranty Book

TECHNICAL SPECIFICATIONS

- **Screen Size:** 11.6"
- **Resolution:** 1920 x 1080
- **USB 2.0:** 1
- **Operating System :** Windows 10 Home
- **Battery:** 4000 mAh Lithium
- **Processor:** Dual Core
- **Processor Frequency:** Up To 2.40 GHz
- **Storage:** 32GB*
- **Memory (RAM):** 4GB*
- **Expansion Slot:** Micro SD
- **Mini HDMI:** 1
- **WiFi:** Compatible
- **Front camera:** 2 MP
- **Bluetooth:** 4.0
- **USB 3.0:** 1

FCC PART 15 DISCLAIMER:

This device complies with part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ACPR-L2IN1-116-2