



Tap finger on Banshee's back 1x, 3x, or 5x times to activate movement/sounds.




Hold finger on Banshee's back for 3 seconds to activate movement/sounds.



Hold Teylu next to Banshee's head

to activate movement/sounds and communicate with nearby Banshee's.





BATTERY INSTRUCTIONS

DO NOT MIX OLD AND NEW BATTERIES.
DO NOT MIX ALKALINE, STANDARD (CARBON ZINC), OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT CIRCUITED. REMOVE BATTERIES WHEN NOT IN USE OR DISCHARGED.

BATTERY REPLACEMENT

1. REMOVE THE SCREW TO ACCESS THE BATTERY COMPARTMENT

2. OPEN BATTERY COMPARTMENT. EXAUSTED BATTERIES TO BE REMOVED.

3. NEW BATTERIES ARE TO BE INSERTED WITH CORRECT POLARITY.

CAUTION: CHOKING HAZARD: MAY CONTAIN SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS OF AGE. CAUTION: KEEP AWAY FROM LONG HAIR.

## FCC ID: 2ACU8INT107

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. and (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class 8 digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



DISNEY THEME PARK MERCHANDISE LAKE BUENA VISTA. FL 32830

© TWENTIETH CENTURY FOX FILM CORPORATION. JAMES CAMERON'S AVATAR IS A TRADEMARK OF TWENTIETH CENTURY FOX FILM CORPORATION. ALL RIGHTS RESERVED.

© DISNEY MADE IN CHINA