




Jedi Training Remote and Hilt

Sphère d'entraînement Jedi et poignée
Mando de entrenamiento y empuñadura Jedi

- 1 Remote
- 2 Hilt
- 3 Mode Panel
- 4 Scoreboard
- 5 Remote Base
- 6 Start Button




O = OFF
I = Padawan Mode
II = Jedi Mode
III = Jedi Master Mode



Remote should be placed between the user and the wall.
User should be facing the scoreboard.
Recommended distance from user to Remote is 1-1.5 feet.
Recommended distance from Remote to wall is 6 to 8 feet.
Recommended height from the Remote to the floor is 2 ½ to 3 ½ feet.
For optimal training, the wall should be flat and not contain any objects.
For optimal training, objects should not be blocking light projection or placed between Remote and wall. Space between Remote and wall should remain unobstructed.

Strike




START position = Hold the Hilt vertically in front of you for default position.
NOTE: The switch on the Hilt should always be facing upward.

When BLUE light is emitted from the Remote, move the Hilt 90 degrees FORWARD toward the Remote to activate strike.
If strike is SUCCESSFUL, the light on Hilt will flash YELLOW and vibrate.
If strike is UNSUCCESSFUL, the light on Hilt will remain BLUE.

END position = Move the Hilt upward 90 degrees back to default position until it is vertical in front of you.

Block (Right)




START position = Hold the hilt vertically in front of you for default position.
NOTE: The switch on the Hilt should always be facing upward.

When RED light is emitted from Remote, turn the Hilt 90 degrees RIGHT or LEFT to activate block.
If block is SUCCESSFUL, the light on Hilt will flash RED and vibrate.
If block is UNSUCCESSFUL, the light on Hilt will remain BLUE.

END position = Move the Hilt upward 90 degrees back to default position until it is vertical in front of you.

Block (Left)



START position = Hold the Hilt vertically in front of you for default position.
NOTE: The switch on the Hilt should always be facing upward.

When RED light is emitted from Remote, turn the Hilt 90 degrees RIGHT or LEFT to activate block.
If block is SUCCESSFUL, the light on Hilt will flash RED and vibrate.
If block is UNSUCCESSFUL, the light on Hilt will remain BLUE.

END position = Move the Hilt upward 90 degrees back to default position until it is vertical in front of you.

REQUIRES (4) (AA) (1.5V), (3) (AAA) (1.5V) BATTERIES, NOT INCLUDED.
FONCTIONNE AVEC (4) PILES (AA)(1.5V), (3) PILES (AAA)(1.5V), NON INCLUSES.
NECESITA (4) PILAS (AA) (1.5V), (3) PILAS (AAA) (1.5V), NO INCLUIDAS.
SONO NECESSARIE (4) (AA) (1.5V), (3) (AAA) (1.5V) BATTERIE, NON INCLUSE.
REQUIER (4) PILHAS (AA) DE (1.5V), (3) PILHAS (AAA) DE (1.5V), NÃO INCLUIDAS.

DC IN 5V 2A

X1

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA

AAA

AA</