

EN

Warranty


At mophie, we are dedicated to making the best quality products. To back this up, this product is warranted for two years. This warranty does not affect any statutory rights that you may be entitled to. Keep a copy of your purchase receipt as proof of purchase. Be sure to register your product at mophie.com/warranty.

Customer Service


Telephone: 1-888-8mophie (1-888-866-7443)
International: +1 (269) 743-1340
Web: www.mophie.com/cs

IMPORTANT SAFETY INSTRUCTIONS**Warning**

Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage.

snap+ juice pack® mini**QUICK START GUIDE**

*Recommend a wall adapter ≥ 10W (not included)
*Nous recommandons d'utiliser un adaptateur mural ≥ 10W (non inclus)



Charging the juice pack mini with a smartphone

Charging the juice pack mini with a laptop

Charging the juice pack mini with a power bank

Charging the juice pack mini with a car adapter

Charging the juice pack mini with a wall adapter

excess heat, toxic fumes, fire or explosion, for which damages you ("Purchaser"), and not mophie Inc. ("Manufacturer") are responsible.

Before using your juice pack portable battery for the first time, fully charge it (so that the pressing the charge status buttons lights all four status LEDs).

Do not store product in high-temperature environment, including heat caused by intense sunlight or other forms of heat. Do not place product in fire or otherwise excessively hot environments. Exposure to fire or temperature above 212°F (100°C) may cause explosion.

This product should be operated only in open-air conditions. It should not be operated in an enclosed, unventilated space such as a carrying bag, pocket, purse or bedding. Failure to follow these instructions may damage the product by overheating.

Do not disconnect the juice pack battery from a connected device while the device is charging—wait until the device is fully charged.

Be cautious of drops, bumps, abrasions, or other impacts to this device. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Manufacturer or dispose of it in an appropriate manner at your local battery-recycling center.

Do not expose the battery case to rain or snow.

Do not put fingers or hands into the product.

Do not disassemble this device or attempt to re-purpose or modify it in any manner.

For questions or instructions for the various ways to charge this device, refer to the illustrations in this quick-start guide.

Use of a power supply or charger not recommended or included by mophie may result in a risk of fire or injury to persons.

Do not use the battery case in excess of its output rating.

Overloading outputs above rating may result in a risk of fire or injury to persons.

Do not attempt to replace any part of this device.

If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

All products have gone through a thorough quality assurance inspection. If you find that your device is excessively hot, is emitting odor, is deformed, abraded, cut or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Manufacturer.

Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be used with certified peripherals and shielded cables. All peripherals must be shielded and grounded. Operation with non-certified peripherals or non-shielded cables may result in interference to radio or reception.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

MODIFICATION: Any changes or modifications of this device could void the warranty.

STATEMENT OF COMPLIANCE:

Hereby, ZAGG International declares that the radio equipment wireless charging device is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address: http://www.mophie.com/cert_red

WEEE STATEMENT: All of our products are marked with the WEEE symbol; this indicates that this product must NOT be disposed of with other waste. Instead it is the user's

responsibility to dispose of their waste electrical and electronic equipment by handing it over to an approved re-processor, or by returning it to mophie, inc. for reprocessing. For more information about where you can send your waste equipment for recycling, please contact mophie, inc. or one of your local distributors.

THIS DEVICE CONFORMS TO UL STD. 62368-1, CERTIFIED TO CSA STD. C22.2 NO. 62368-1. CONFORMS TO UL SUBJECT 2056.

FR**Garantie**

mophie s'engage à fabriquer des produits de la meilleure qualité possible. Afin d'atteindre cette promesse, ce produit est garanti 2 ans à compter de la date d'achat. Cette garantie n'invalide pas les réparations effectuées par mophie, inc. ou l'un de ses partenaires.

Do not disconnect the juice pack battery from a connected device while the device is charging—wait until the device is fully charged.

Be cautious of drops, bumps, abrasions, or other impacts to this device. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Manufacturer or dispose of it in an appropriate manner at your local battery-recycling center.

Do not expose the battery case to rain or snow.

Do not put fingers or hands into the product.

Do not disassemble this device or attempt to re-purpose or modify it in any manner.

For questions or instructions for the various ways to charge this device, refer to the illustrations in this quick-start guide.

Use of a power supply or charger not recommended or included by mophie may result in a risk of fire or injury to persons.

Do not use the battery case in excess of its output rating.

Overloading outputs above rating may result in a risk of fire or injury to persons.

Do not attempt to replace any part of this device.

If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

All products have gone through a thorough quality assurance inspection. If you find that your device is excessively hot, is emitting odor, is deformed, abraded, cut or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Manufacturer.

Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

REMARQUE: Cet équipement a été testé et jugé conforme aux limites établies pour un appareil numérique de classe B, conformément à la partie 15 des directives de la FCC. Ces limites sont objets pour assurer une protection raisonnable contre les interférences dangereuses dans l'environnement.

ATTENTION: Pour respecter les limites de l'appareil numérique de Classe B, et conformément à la partie 15 des directives de la FCC, cet appareil doit être utilisé avec des câbles blindés et des périphériques certifiés. Tous les périphériques doivent être blindés et mis à la terre. L'utilisation avec des périphériques non agréés ou des câbles non blindés peut entraîner des interférences avec la radio ou au niveau de la réception.

CET ÉQUIPEMENT EST CONFORME À LA NORME UL STD. 62368-1, CERTIFIÉ CONFORME À LA NORME CSA STD. C22.2 NO. 62368-1, ET CONFORME À LA NORME UL 2056.

FR

Garantie

mophie s'engage à fabriquer des produits de la meilleure qualité possible. Afin d'atteindre cette promesse, ce produit est garanti 2 ans à compter de la date d'achat. Cette garantie n'invalide pas les réparations effectuées par mophie, inc. ou l'un de ses partenaires.

Do not disconnect the juice pack battery from a connected device while the device is charging—wait until the device is fully charged.

Be cautious of drops, bumps, abrasions, or other impacts to this device. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Manufacturer or dispose of it in an appropriate manner at your local battery-recycling center.

Do not expose the battery case to rain or snow.

Do not put fingers or hands into the product.

Do not disassemble this device or attempt to re-purpose or modify it in any manner.

For questions or instructions for the various ways to charge this device, refer to the illustrations in this quick-start guide.

Use of a power supply or charger not recommended or included by mophie may result in a risk of fire or injury to persons.

Do not use the battery case in excess of its output rating.

Overloading outputs above rating may result in a risk of fire or injury to persons.

Do not attempt to replace any part of this device.

If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

All products have gone through a thorough quality assurance inspection. If you find that your device is excessively hot, is emitting odor, is deformed, abraded, cut or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Manufacturer.

Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

CONSERVEZ CES INSTRUCTIONS

Mentions légales

Le fabricant ne peut en aucun cas être tenu pour responsable envers vous ou tout tiers des dommages que vous ou ce tiers pourriez subir suite à l'utilisation, intentionnelle ou non, ou à une utilisation inappropriée de ce produit conjointement avec tout appareil ou accessoire avec lequel les appareils appropriés pour lesquels ce produit est conçu. Le fabricant ne pourra pas être tenu pour responsable des dommages que vous ou tout tiers pourriez subir suite à une utilisation inappropriée de ce produit, tel que décrit ci-dessus. Si vous êtes responsable de l'utilisation du produit avec un appareil inapproprié et que des dommages résultent d'une telle utilisation, vous engagez à indemniser le fabricant pour toutes les blessures infligées à tiers.

mophie juice pack, Stay Powerful, mophie loves you, le concept de cinq cercles et le logo mophie sont des marques commerciales de mophie, Inc. MagSafe est une marque d'Apple Inc. enregistrée aux États-Unis et dans d'autres pays. USB-C est une marque déposée de USB Implementers Forum. Brevets : mophie.com/patents.

STATEMENT OF COMPLIANCE:

Hereby, ZAGG International declares that the radio equipment wireless charging device is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following Internet address: http://www.mophie.com/cert_red

WEEE STATEMENT: All of our products are marked with the WEEE symbol; this indicates that this product must NOT be disposed of with other waste. Instead it is the user's

responsabilité de disposer de leur équipement électrique et électronique par le remettre à un appareil de recyclage ou de la déposer dans une installation particulière.

REMARQUE: Cet équipement provoque des interférences négatives à la réception de la radio ou de la télévision (ce qui se vérifie en allumant et en éteignant l'appareil), l'utilisateur pourra tenter de corriger ces interférences en appliquant une ou plusieurs des mesures suivantes :

- Réorienter ou déplacer l'antenne de réception.
- Augmenter la distance entre l'équipement et le récepteur.
- Brancher l'équipement à une prise d'un circuit différent de celui sur lequel est branché le récepteur.
- Consulter le revendeur ou un technicien expérimenté pour obtenir de l'aide.

ATTENTION: Pour respecter les limites de l'appareil numérique de Classe B, et conformément à la partie 15 des directives de la FCC, cet appareil doit être utilisé avec des câbles blindés et des périphériques certifiés. Tous les périphériques doivent être blindés et mis à la terre. L'utilisation avec des périphériques non agréés ou des câbles non blindés peut entraîner des interférences avec la radio ou au niveau de la réception.

CET ÉQUIPEMENT EST CONFORME À LA NORME UL STD. 62368-1, CERTIFIÉ CONFORME À LA NORME CSA STD. C22.2 NO. 62368-1, ET CONFORME À LA NORME UL 2056.

FR

Garantie

mophie s'engage à fabriquer des produits de la meilleure qualité possible. Afin d'atteindre cette promesse, ce produit est garanti 2 ans à compter de la date d'achat. Cette garantie n'invalide pas les réparations effectuées par mophie, inc. ou l'un de ses partenaires.

Do not disconnect the juice pack battery from a connected device while the device is charging—wait until the device is fully charged.

Be cautious of drops, bumps, abrasions, or other impacts to this device. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Manufacturer or dispose of it in an appropriate manner at your local battery-recycling center.

Do not expose the battery case to rain or snow.

Do not put fingers or hands into the product.

Do not disassemble this device or attempt to re-purpose or modify it in any manner.

For questions or instructions for the various ways to charge this device, refer to the illustrations in this quick-start guide.

Use of a power supply or charger not recommended or included by mophie may result in a risk of fire or injury to persons.

Do not use the battery case in excess of its output rating.

Overloading outputs above rating may result in a risk of fire or injury to persons.

Do not attempt to replace any part of this device.

If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

All products have gone through a