



Instructions PLAY AUDIO VIA BLUETOOTH:

- 1 Use the included mini-USB cable to charge your sound system by connecting it to any USB port on a computer or USB wall adaptor.
- 2 The LED indicator will turn red to indicate your system is charging. Once fully charged the LED will turn off.
- Power ON your system by sliding the power switch to the on position.
- 4 You will hear a tone from the speaker and the Bluetooth LED will flash. The speaker is now ready to be paired to your device.
- Navigate to Bluetooth menu on your device and select "PlanterTech" from the menu.
- 6 The Bluetooth LED will stop flashing and stay on when connection is complete.
- 7 Press and hold the PAIR button any time you need to reconnect your device or to pair a new device. The blue PAIR LED will flash when the speaker is ready to pair.

plantertech

PLAY AUDIO VIA AUX JACK:

- 1 Plug in one end of a 3.5mm audio cable (not included) into the AUX jack and the other into the music device.
- ² Turn on your music source and press play.
- ³ Control the music and volume using the controls on your music device.

HELPFUL TIPS:

For best sound quality, place your plant next to a wall or vertical surface.

For more information visit: plantertech.com

To keep your plant looking like new use Miracle Coating products: miraclecoatings.com



- A Power ON / OFF switch
- B PAIR, blue LED indicator
- C AUX jack port
- D Charging, red LED indicator
- **E Mini-USB Power Connector**
- F Bluetooth Pairing Button

Warranty

Any questions regarding operation, repair, replacement or warranty issues should be directed to PlanterTech at www.plantertech.com. PlanterTech warrants the product will be free of defects in material, parts and worksmanship for a period of ninety (90) days from date of purchase. PlanterTech agrees that it will replace the defective product, at it's option, with a new or remanufactured product equivalent to the original product during this period. Any returned product must have the original proof of purchase included. PlanterTech does not warrant that the speaker system will work properly in all applications or environments. This product is not warranted for use in outdoor applications or exposure to excessive moisture. PlanterTech makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a specific purpose other than that identified in the instructions included with this product. PlanterTech has made every effort to make sure these instructions are accurate and disclaims liability for any inaccuracies or omissions that may have occurred. Information and instructions are subject to change without notice and does not represent a commitment on the part of PlanterTech. PlanterTech reserves the right to make improvements to these instructions and the product described in these instructions at any time without notice. If you encounter information in these instructions that is incorrect, incomplete or misleading, please contact us at www.plantertech.com. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth/SIG, Inc and any use of such marks by PlanterTech is under license.

Compliance with FCC Regulations This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that radio interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) Reorient or relocate the receiving antenna. 2) Increase the separation between the equipment and receiver. 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. 4) Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF warning statement; The device has been avulated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restrictions.