APPENDIX I (External Photos)

Figure 1

The Overall View

EUT is placed inside the host

Figure 2

The Overall-Front View

EUT

Figure 3

The EUT-Front View

EUT

Figure 4

The Overall-Back View