

# MAGNAVOX

## STEREO HEADSET with Bluetooth® Wireless Technology

OWNER'S MANUAL

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

MODEL: MBH513

### FCC NOTICE:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC WARNING:

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. Modifications not authorized by the manufacturer may void user's authority to operate this device.

### LOCATION OF CONTROLS:



1. Power ON/OFF Switch
2. + Volume Up Button
3. - Volume Down Button
4. ) Button with Indicators
5. << Skip Backward Button
6. >> Skip Forward Button
7. || Play / Pause Button
8. Micro USB Port (For Charging Only)
9. Earbuds
10. Magnetic Earbuds Holder

1

2

### POWER SOURCE:

The unit has built in Li-ion rechargeable battery; recharge it before use or when battery is drained as follows:

1. Open the rubber cover on the Micro USB Port.
2. Connect the Micro USB Plug from the supplied connection cable to the Micro USB Port.
3. Connect the full sized USB Plug from the supplied USB Connection Cable to the USB Port on the Computer or USB Charger. (Computer and USB Charger NOT supplied).
4. During charging, the Red Charging Indicator around the ) Button will illuminate. When finished charging, it will turn off.

### Notes:

Your battery will last longer if you're following these simple guidelines for caring and storing.

- A. Before first time use, charge it approximately 4 hours until the unit is fully charged.
- B. Recharge and store the unit within the temperature range of 5°C~35°C (40°F~95°F).
- C. Do not charge longer than 24 hours. Excessive charging or running the Charger and/or Earpieces until battery fully drains will damage battery. Battery life will be extended if you keep the battery fully charged.
- D. Battery life naturally shortens slowly over time.
- E. The rechargeable battery incorporated in this product is not user replaceable.

# MAGNAVOX

## STEREO HEADSET with Bluetooth® Wireless Technology

OWNER'S MANUAL

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

MODEL: MBH513

### FCC NOTICE:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC WARNING:

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. Modifications not authorized by the manufacturer may void user's authority to operate this device.

### LOCATION OF CONTROLS:



1. Power ON/OFF Switch
2. + Volume Up Button
3. - Volume Down Button
4. ) Button with Indicators
5. << Skip Backward Button
6. >> Skip Forward Button
7. || Play / Pause Button
8. Micro USB Port (For Charging Only)
9. Earbuds
10. Magnetic Earbuds Holder

1

2

### POWER SOURCE:

The unit has built in Li-ion rechargeable battery; recharge it before use or when battery is drained as follows:

1. Open the rubber cover on the Micro USB Port.
2. Connect the Micro USB Plug from the supplied connection cable to the Micro USB Port.
3. Connect the full sized USB Plug from the supplied USB Connection Cable to the USB Port on the Computer or USB Charger. (Computer and USB Charger NOT supplied).
4. During charging, the Red Charging Indicator around the ) Button will illuminate. When finished charging, it will turn off.

### Notes:

Your battery will last longer if you're following these simple guidelines for caring and storing.

- A. Before first time use, charge it approximately 4 hours until the unit is fully charged.
- B. Recharge and store the unit within the temperature range of 5°C~35°C (40°F~95°F).
- C. Do not charge longer than 24 hours. Excessive charging or running the Charger and/or Earpieces until battery fully drains will damage battery. Battery life will be extended if you keep the battery fully charged.
- D. Battery life naturally shortens slowly over time.
- E. The rechargeable battery incorporated in this product is not user replaceable.

**OPERATION:**

**BT (Bluetooth) Pairing:**

The first time you use the unit or pair it to a new Bluetooth Device, pair it as follows:

- Power on the unit by sliding the Power ON/OFF Switch to ON position. The Blue and Red Indicators around the **⏻** Button will illuminate and blink. The unit will vibrate briefly.
- Power on the external BT Device and enter the BT search mode. Start pairing following on the screen instructions from the external BT Device.  
After pairing:
  - The Blue Indicator will stop blinking.
  - The Red Indicator will go out.
  - The unit will vibrate briefly.
- Plays the music in the paired BT Device as usual.
- During playback:
  - Press the **+** or **-** Buttons on the unit to adjust volume level as desire.
  - Press the **⏸** Button to pause: press again to resume normal playback.
  - Press the **⏮** or **⏭** Buttons to skip tracks.
  - Press and holding the **⏮** or **⏭** Buttons to fast search.
- If the unit is paired to a Cell Phone and a call is received while listening to music, press and release the **⏻** Button to pause the music playback then use the built-in Microphone to answer the call. When your call is complete, press and releases the **⏻** Button to resume music playback.

- When finished listening, slide the Power ON/OFF Switch to OFF position to shut off the unit. Place the Earbuds to the magnetic holder as illustrated below:



**Notes:**

- When the external Bluetooth Device searched the unit, our model number "MBH513" will appear on the display of external Bluetooth Device.
- Pairing code "0000" or "1234" may need to enter.

**Normal Operation After Pairing:**

- Power on the unit by sliding the Power ON/OFF Switch to ON position. The Blue and Red Indicators around the **⏻** Button will illuminate and blink. The unit will vibrate briefly.
- Power on the external BT Device and enter to BT mode.
- Wait a few seconds until the unit auto pairs to the external BT Device. Then:
  - The Blue Indicator will stop blinking.
  - The Red Indicator will not light.
  - The unit will vibrate briefly.
- Plays music in the paired BT Device as usual.

**TROUBLESHOOTING:**

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built in battery drained	Recharge the battery as page 3
No sound or sound weak	Volume of the unit was set to minimum position	Increase the volume by press the + Button
	Volume level of paired BT Device is in low level	Rise the volume level of the paired BT Device
Sound distortion	Volume level too high	Reduce the volume level by press the - Button
	Volume level of the paired BT Device too high	Reduce the volume level of the paired BT Device
BT not functioning	The external BT Device NOT paired to the unit	Pair the external BT Device to the unit as page 4
	The external BT Device too far from the unit	Place the external BT Device close to the unit

**GENERAL SPECIFICATIONS:**

Power source: Built-in DC 3.7V, 150mAh (0.555WH) rechargeable Li-ion Battery;  
Recharge by DC 5V through Micro USB Port

Impedance of the Earbuds: 2 x 20mW; 32 ohm  
Audio power: 10mW per channel (Total 20mW, RMS)  
BT Version: 4.0  
BT Operation Distance: ≥ 32 Feet in opera area

**PACKAGE INCLUDES:**

- 1 x Headset
- 1 x USB Connection Cable (For charging only)
- 1 x User's Manual

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

**LIMITED WARRANTY**

Craig Electronics warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 180 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit cannot be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

Craig Electronics Inc.  
1160 NW 163 Drive  
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig service center. d) Damaged because it is improperly connected to any other equipment. Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

This product has been manufactured by and is sold under the responsibility of Craig Electronics Inc. and Craig Electronics Inc. is the warrantor in relation to this product. MAGNAVOX and SMART VERY SMART are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

To Obtain Service on your Product  
email:service@craigelectronics.com

Printed in China

MBH513\_WC\_EOCS1\_B0US

**OPERATION:**

**BT (Bluetooth) Pairing:**

The first time you use the unit or pair it to a new Bluetooth Device, pair it as follows:

- Power on the unit by sliding the Power ON/OFF Switch to ON position. The Blue and Red Indicators around the **⏻** Button will illuminate and blink. The unit will vibrate briefly.
- Power on the external BT Device and enter the BT search mode. Start pairing following on the screen instructions from the external BT Device.  
After pairing:
  - The Blue Indicator will stop blinking.
  - The Red Indicator will go out.
  - The unit will vibrate briefly.
- Plays the music in the paired BT Device as usual.
- During playback:
  - Press the **+** or **-** Buttons on the unit to adjust volume level as desire.
  - Press the **⏸** Button to pause: press again to resume normal playback.
  - Press the **⏮** or **⏭** Buttons to skip tracks.
  - Press and holding the **⏮** or **⏭** Buttons to fast search.
- If the unit is paired to a Cell Phone and a call is received while listening to music, press and release the **⏻** Button to pause the music playback then use the built-in Microphone to answer the call. When your call is complete, press and releases the **⏻** Button to resume music playback.

- When finished listening, slide the Power ON/OFF Switch to OFF position to shut off the unit. Place the Earbuds to the magnetic holder as illustrated below:



**Notes:**

- When the external Bluetooth Device searched the unit, our model number "MBH513" will appear on the display of external Bluetooth Device.
- Pairing code "0000" or "1234" may need to enter.

**Normal Operation After Pairing:**

- Power on the unit by sliding the Power ON/OFF Switch to ON position. The Blue and Red Indicators around the **⏻** Button will illuminate and blink. The unit will vibrate briefly.
- Power on the external BT Device and enter to BT mode.
- Wait a few seconds until the unit auto pairs to the external BT Device. Then:
  - The Blue Indicator will stop blinking.
  - The Red Indicator will not light.
  - The unit will vibrate briefly.
- Plays music in the paired BT Device as usual.

**TROUBLESHOOTING:**

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built in battery drained	Recharge the battery as page 3
No sound or sound weak	Volume of the unit was set to minimum position	Increase the volume by press the + Button
	Volume level of paired BT Device is in low level	Rise the volume level of the paired BT Device
Sound distortion	Volume level too high	Reduce the volume level by press the - Button
	Volume level of the paired BT Device too high	Reduce the volume level of the paired BT Device
BT not functioning	The external BT Device NOT paired to the unit	Pair the external BT Device to the unit as page 4
	The external BT Device too far from the unit	Place the external BT Device close to the unit

**GENERAL SPECIFICATIONS:**

Power source: Built-in DC 3.7V, 150mAh (0.555WH) rechargeable Li-ion Battery;  
Recharge by DC 5V through Micro USB Port

Impedance of the Earbuds: 2 x 20mW; 32 ohm  
Audio power: 10mW per channel (Total 20mW, RMS)  
BT Version: 4.0  
BT Operation Distance: ≥ 32 Feet in opera area

**PACKAGE INCLUDES:**

- 1 x Headset
- 1 x USB Connection Cable (For charging only)
- 1 x User's Manual

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

**LIMITED WARRANTY**

Craig Electronics warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 180 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit cannot be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

Craig Electronics Inc.  
1160 NW 163 Drive  
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig service center. d) Damaged because it is improperly connected to any other equipment. Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

This product has been manufactured by and is sold under the responsibility of Craig Electronics Inc. and Craig Electronics Inc. is the warrantor in relation to this product. MAGNAVOX and SMART VERY SMART are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

To Obtain Service on your Product  
email:service@craigelectronics.com

Printed in China

MBH513\_WC\_EOCS1\_B0US

## FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.