



802.11n-HT20 AVGPDS - Ant 0


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPSD - Ant 0


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)



### 802.11b AVGPDS - Ant 1


#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)




### 802.11g AVGPDS - Ant 1


#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)




802.11n-HT20 AVGPDS - Ant 1


Channel 01 (2412MHz)



Channel 06 (2437MHz)





Channel 11 (2462MHz)




802.11n-HT40 AVGPSD - Ant 1

Channel 03 (2422MHz)

Channel 06 (2437MHz)



Channel 09 (2452MHz)



### 802.11b AVGPDS - Ant 2

#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)




### 802.11g AVGPDS - Ant 2


#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)






802.11n-HT20 AVGPDS - Ant 2


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 2


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




### 802.11b AVGPDS - Ant 3


#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)




### 802.11g AVGPDS - Ant 3


#### Channel 01 (2412MHz)



#### Channel 06 (2437MHz)




#### Channel 11 (2462MHz)




802.11n-HT20 AVGPSD - Ant 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11b AVGPDS - Ant 0 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPDS - Ant 0 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)






802.11n-HT20 AVGPDS - Ant 0 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 0 / Ant 0 + 1 + 2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



802.11b AVGPDS - Ant 1 / Ant 0 + 1 + 2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPDS - Ant 1 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT20 AVGPDS - Ant 1 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11n-HT40 AVGPDS - Ant 1 / Ant 0 + 1 + 2 + 3


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11b AVGPDS - Ant 2 / Ant 0 + 1 + 2 + 3


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11g AVGPDS - Ant 2 / Ant 0 + 1 + 2 + 3

Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)

