

NVNT	ac20	5825	Ant1	-33.61	-27	Pass
NVNT	ac20	5180	Ant2	-34.23	-27	Pass
NVNT	ac20	5200	Ant2	-33.75	-27	Pass
NVNT	ac20	5240	Ant2	-33.98	-27	Pass
NVNT	ac20	5745	Ant2	-34.27	-27	Pass
NVNT	ac20	5785	Ant2	-33.9	-27	Pass
NVNT	ac20	5825	Ant2	-33.8	-27	Pass
NVNT	ac40	5190	Ant1	-33.64	-27	Pass
NVNT	ac40	5230	Ant1	-34.37	-27	Pass
NVNT	ac40	5755	Ant1	-34.19	-27	Pass
NVNT	ac40	5795	Ant1	-33.72	-27	Pass
NVNT	ac40	5190	Ant2	-34.38	-27	Pass
NVNT	ac40	5230	Ant2	-34.09	-27	Pass
NVNT	ac40	5755	Ant2	-34.07	-27	Pass
NVNT	ac40	5795	Ant2	-34.58	-27	Pass
NVNT	ac80	5210	Ant1	-34.76	-27	Pass
NVNT	ac80	5775	Ant1	-34.1	-27	Pass
NVNT	ac80	5210	Ant2	-34.13	-27	Pass
NVNT	ac80	5775	Ant2	-34.26	-27	Pass
NVNT	ax20	5180	Ant1	-34.28	-27	Pass
NVNT	ax20	5200	Ant1	-32.95	-27	Pass
NVNT	ax20	5240	Ant1	-34.55	-27	Pass
NVNT	ax20	5745	Ant1	-33.76	-27	Pass
NVNT	ax20	5785	Ant1	-34.42	-27	Pass
NVNT	ax20	5825	Ant1	-33.17	-27	Pass
NVNT	ax20	5180	Ant2	-33.89	-27	Pass
NVNT	ax20	5200	Ant2	-34.72	-27	Pass
NVNT	ax20	5240	Ant2	-34.15	-27	Pass
NVNT	ax20	5745	Ant2	-34.11	-27	Pass
NVNT	ax20	5785	Ant2	-34.07	-27	Pass
NVNT	ax20	5825	Ant2	-33.26	-27	Pass
NVNT	ax40	5190	Ant1	-33.98	-27	Pass
NVNT	ax40	5230	Ant1	-34.02	-27	Pass
NVNT	ax40	5755	Ant1	-32.91	-27	Pass
NVNT	ax40	5795	Ant1	-34.15	-27	Pass
NVNT	ax40	5190	Ant2	-33.62	-27	Pass
NVNT	ax40	5230	Ant2	-33.54	-27	Pass
NVNT	ax40	5755	Ant2	-33.83	-27	Pass
NVNT	ax40	5795	Ant2	-33.39	-27	Pass
NVNT	ax80	5210	Ant1	-33.84	-27	Pass
NVNT	ax80	5775	Ant1	-33.72	-27	Pass

NVNT	ax80	5210	Ant2	-33.8	-27	Pass
NVNT	ax80	5775	Ant2	-33.68	-27	Pass























































