



# KIENZLE AUTOMOTIVE

MODEL NO.: **MCR1120DAB+**

USB/BLUETOOTH PLAYER  
WITH FM/MW TUNER

12V 15A max

DO NOT connect any speaker wires to the metal body or chassis of the vehicle. DO NOT connect the speaker common (-) wires to each other. Connect each speaker wire directly to each speaker terminal. All speaker common (-) wires must remain floating.

Kienzle Automotive GmbH  
Alexanderstr. 37-39, D-45472 Mülheim/Ruhr  
USB: 5V 2.1A    FCC ID: 2AD9T-CR1226DAB




10R-06 4732

### FCC STATEMENT


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

USB/SUBWOOFER/Aux-in/MIC Wire harness  
Front left Line-out (White)  
Rear left Line-out (White)



NO.	PIN definition	NO.	PIN definition
1	NC	9	Rear Right (+)
2	Telemute	10	Rear Right (-)
3	NC	11	Front Right (+)
4	Battery (12V)	12	Front Right (-)
5	AMP remote	13	Front Left (+)
6	Illumination	14	Front Left (-)
7	ACC (12V)	15	Rear Left (+)
8	Ground 0V	16	Rear Left (-)



55mm

90mm

