

OPERATING INSTRUCTIONS

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

Carefully remove items from package.
 Locate the battery compartment on the back of each item (see diagram on right).
 Swivel latches on bottom of car to release battery packaged insert batteries.

4. Switch both car and remote buttons to "ON" position.5. For best result use the car on hard surfaces such as

Reverse Press both control sticks backward.

Do not operate during thunderstorms or rain.
 Avoid water, sand and snow when operating car.
 Do not submerge car or controller in water.
 Never operate your car on the street or highway.
 Never operate your car in a confined or crowded area, and do not use people or animals as obstacles.
 Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
 Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".
 Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
 Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.
 Remove all batteries when not in use to avoid accidental operation.
 Adult supervision is recommended when operating this car.

GENERAL CONTROLS

Spinning Action
Press and hold the control sticks
in opposite directions to make the car spin.

SF2017A

Toy RC Monster Spinning Car

SPINNING ON REAR WHEEL (ACTION BUTTON)

Forward
Press both control
sticks forward.

1) Spin the car by pressing and holding the control sticks in opposite directions.

and insert batteries.