



**Monoprice™ Dual Driver
Bluetooth® Headphone with ANC**

P/N 44517
User Manual

Thank You for Purchasing this Product

To ensure optimum performance and safety, read the following instructions before connecting, operating, or adjusting the product. Keep this manual for future reference.

Table of Contents

Safety Warnings and Guidelines.....	2
Introduction.....	2
Features.....	3
Package Contents.....	3
Key Operations.....	4
Specifications.....	7

Safety Warnings and Guidelines

- Keep the User Manual for future reference
- Refrain from using the device in an environment with potential dangers (such as thunderstorms, heavy rain, extreme heat, etc)
- Avoid using the device while doing activities that require one's utmost attention (such as driving) to prevent danger
- Place the headphones out of children's reach to avoid improper use
- Avoid water to prevent damaging the function of the device
- Avoid increasing the volume to an extreme level to prevent hearing damage
- Prevent using the device while charging
- Do not remove the battery from the headset to avoid damaging its built-in non-removable rechargeable battery
- Stop using the device immediately when you feel discomfort, irritation, or other adverse reactions

Introduction

The Dual Driver Bluetooth® Headphone by Monoprice™ features Active Noise Cancellation (ANC) to help emphasize sound quality anywhere on the go. Any music will sound more immersive with its dual driver, splitting the entire broad spectrum of audio frequencies for ear-to-ear. Its Bluetooth 5.0 allows you to connect to quality sounds. Listen comfortably all day with the help of its comfortable ear foams and battery life of up to 70 hours. The device also features a low-battery alarm prompt that signals you whenever it needs to recharge.

Features

- Active Noise Cancelling
- Dual Drivers
- Transparency Mode
- Bluetooth 5.0
- Mode Switch
- Up to 70 hours of music and talk time
- Frequency Response Range of 20Hz-20KHz
- Supports A2DP, HFP, SPP, HID, and PBAP
- Low Battery Alarm Prompt
- Two Mobile Phones Connection

Package Contents

- 1x Monoprice Dual Driver Bluetooth Headphone
- 1x USB-C Charging Cable
- 1x Carrying Case
- 1x User Manual

Key Operations

BLUETOOTH CONNECTION STEPS

1. Please control the distance between the Bluetooth headphones and your mobile phone (or other device used for connection). Make sure it is within 1 meter.
2. In its shutdown state, press and hold the "MF button" for 3 seconds to hear the prompt tone "power on" and "pairing" at the same time.
3. The blue LED flash indicates that the device is entering the pairing mode.
4. Open your phone's (or device's) Bluetooth connection and select "MP44517" to automatically connect.
5. If the "connected" prompt tone appears, it means you have successfully connected your device with the headphones.

Note: Press and hold the "MF button" for 3 seconds to turn on the headphones and automatically connect to its last connected device. If there is no connected device present, the headset will automatically enter the pairing mode after 10 seconds.

DISCONNECTION AND RECONNECTION

1. When the distance between the paired device and the headset exceeds the receiving range, the Bluetooth will automatically disconnect. The blue LED flash will appear along with a "disconnected" prompt tone.
2. After the disconnection time exceeds 10 minutes, the headset will automatically enter pairing mode again.

CONNECTING TWO MOBILE PHONES/DEVICES

1. After connecting to the first device, turn off the Bluetooth headset.
2. While turned off, press and hold the “MF button” for 5 seconds until a blue LED light flashes quickly.
3. In the second device’s Bluetooth pairing devices, search and select “MP44517”.
4. Reconnect with the first device by also selecting “MP44517” in its pairing device to connect to both simultaneously.
5. To answer a call on one of the mobile devices, press the “MF button”. If the other phone gets a call, press the “MF button” in order to answer and end the call on the first device.
6. Music automatically stops if one of the mobile devices receives a call and answers it.

OTHER OPERATIONS

Answering Calls	Short press the “MF button” once to answer a call.
Ending Calls	Short press the “MF button” once during a call interval to end the call.
Rejecting Calls	Press and hold the “MF button” for 2 seconds to reject a call.
Call Waiting	When you want to answer an incoming call when you are already on a call, short press the “MF button” once to answer the incoming call and keep the first call on hold.
Mode Switch	Short press the “M button” to switch mode: ANC - Normal - Transparency.

Activate Voice Function	Double press the “MF button” to activate voice assistant (make sure your mobile device supports this).
Play/Pause Music	Click the “MF button” in order to pause or play music.
Song Selection	Long press the volume up button to skip to the next song. Long press the volume down button to skip to the previous song.
Volume Adjustment	Press the volume up or volume down button to increase and decrease the level. A beep will appear if you reach the maximum volume.
Reset	When the headset is turned off, long press the “MF button” and the volume up button at the same time in 5 seconds while the cable is charged. A red and purple LED light will flash twice to signal that the device has cleared all previous pairing records.
Low Battery Alarm Prompt	When there are only 2 hours left in the battery, the headset will enter its low-power mode. A “battery low” prompt tone will appear every 30 minutes. When the power is too low, the device will automatically shut down.

Specifications

P/N	44517
Working Range	10 meters
Play Music/Talk Time	70 hours
Battery	Li-ion 3.7V/1000mAh
Charging Environment Temperature	0-45°C
Frequency Response Range	20Hz-20KHz
Speaker Diameter and Impedance	40mm+20mm diameter and 32 ohms
Support	A2DP, HFP, SPP, HID, and PBAP
Environment Temperature	-10-45°C
Bluetooth Version	5.0
Net weight	316g

CUSTOMER SERVICE

The Monoprice Customer Service department is dedicated to ensuring that your ordering, purchasing, and delivery experience is second to none. If you have any problems with your order, please give us an opportunity to make it right. You can contact a Monoprice Customer Service representative through the Live Chat link on our website www.monoprice.com or via email at support@monoprice.com. Check the website for support times and links.

TECHNICAL SUPPORT

Monoprice™ is pleased to provide free, live, online technical support to assist you with any questions you may have about installation, setup, troubleshooting, or product recommendations. If you ever need assistance with your new product, please come online to talk to one of our friendly and knowledgeable Tech Support Associates. Technical support is available through the online chat button on our website www.monoprice.com or through email by sending a message to tech@monoprice.com. Check the website for support times and links.

To download the latest drivers, firmware, manuals, etc., go to www.monoprice.com and type 44517 into the search bar. If available, support files are linked at the bottom of the product page.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc

Radio Notice for FCC

Caution

This FCC Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Monoprice, including the use of non-approved antennas, could void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Notice for ISED Canada:

This device complies with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radio Frequency Exposure

This device meets the ISED Canada requirements for exposure to radio waves and is designed and manufactured not to exceed the emission limits for exposure to

radiofrequency (RF) energy. To comply with Canada RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or

Notice for ISED Canada:

CAN ICES-3 (B)/NMB-3(B)

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help



TECHNOLOGY AT PRICES THAT MAKE SENSE

www.monoprice.com

Need Help? We're here for you!

Contact us: www.monoprice.com/contactus

Product pictures are for reference only.

Specifications described herein are subject to change without prior notification.

Monoprice™ and all Monoprice logos are trademarks of Monoprice Inc.

Copyright © 2023 Monoprice, Inc. All rights reserved.

Monoprice, Inc.

1 Pointe Drive, Suite 400

Brea, CA 92821 – USA

www.monoprice.com