

Podo charging

3 FLASHES → SLOW PULSE



## CIRCLING MOTION

Ready to connect (40 sec. time out)



ONE LED

# NOTE: LEDs always indicate when pictures and videos are being recorded.



SAFETY, HANDLING, AND STICKY PAD CARE FAILURE TO FOLLOW INSTRUCTIONS MAY RESULT

IN INJURY OR DAMAGE TO PODO OR OTHER PROPERTY. DO NOT ATTEMPT TO OPEN PODO. REFER ALL SERVICING QUESTIONS TO PODO LABS

Using Podo and the sticky pad carries inherent risk; please be careful and follow all directions in this guide!

### STICKY PAD

Sticky pad provides temporary adhesion to surfaces for quick shots. It is not intended for permanent attachment. Use magnet for longer videos or time-lapse shots. Caution: Sticky pad can be very sticky and damage surfaces (e.g. rip paint). Do not apply on delicate surfaces and use with care. Podo assumes no responsibility for damages resulting from the use of our product.





Pat dry with hand or use dryer.

