REG02 – International – US and Canada Online

FRONTCOVER



KSBTAP2 KitSound Airline Adaptor 2

User Manual

INNER LEAF

Please read this manual carefully before use.



WARNING

- Please do not get the product wet. If your product is IP rated, please follow guidelines on how to safely use your product overleaf.
- Please don't take the product apart. There are no user serviceable parts inside
- Please don't modify or alter the product or accessories
- Please don't expose the product to extreme temperatures or rapid changes of hot to cold or vice versa
- Please don't use damaged cables or plugs, or loose electrical sockets
- Please don't touch the device, cables, plugs, or the electrical socket with wet hands or other wet body parts
- Please don't pull the cable excessively when disconnecting it if the cable is not fixed
- Please don't bend or damage the cable
- Please don't drop or cause an impact to the product or the device
- Please don't place naked flame sources, such as lighted candles, on the product

Battery Information

- Batteries may malfunction if they are not used for extended periods
- Over time, unused devices will discharge and must be recharged before use
- Disconnect the charger from power sources when not in use
- Use the batteries only for their intended purposes
- Follow all instructions in this manual to ensure the longest lifespan of your device and battery.
 Damages or poor performance caused by failure to follow warnings and instructions can void your manufacturer's warranty
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like

Box contents

- KS Bluetooth Airline Adaptor
- Micro USB charge cable
- User manual

Functions

- 1. Multifunction Button
- 2. LED light indicator
- 3. DC 5V Micro USB charge port
- 4. Stereo Pin
- 5. Mono Pins

Instructions for use

How to use the Airline Adaptor:

- 1. Connect the Airline Adaptor to your media device using either the single stereo pin(4) or both pins in mono mode(5).
- 2. Once the Airline Adaptor pin(s) are connected, hold the multifunction button for 3 seconds to power on.
- 3. The KS Airline Adaptor goes into Bluetooth pairing mode automatically. Pairing mode is indicated by a white flashing light. Once a connection is made, the light will be solid white. The Airline Adaptor will auto reconnect to the last connected device in pairing mode.
- 4. If you are auto reconnected to a device, but wish to connect a new device please hold the multifunction button for 5 seconds, the light will flash white as the KS Airline Adaptor searches for available devices.
- 5. Hold the multifunction button for 3 seconds for power off.

Mono and Stereo input modes

- 1. The Airline Adaptor can be used in either Mono or Stereo input mode, depending on what terminal is availabe to you.
- 2. Mono mode uses both pins(5) and stereo mode uses the single stereo pin(4).
- 3. If you are presented with dual input terminal then you will need to use both pins in mono mode.
- 4. If you are presented with a single input terminal then you will need to us the single stereo pin.

Getting started

Function	Button Action
Turn ON/OFF	Press and hold the Multifunction button for 3 seconds.
Enter pairing mode	Press and hold Multifunction button for 5 seconds.
Clear paired record	Press and hold the Multifunction button for 7 seconds.

Charging the battery:

Give the Airline Adaptor a full charge before its first use.

- 1. Connect the USB charging cable to the Micro USB charging port and plug into power.
- 2. The battery LED indicator will be solid red whilst charging.
- 3. Charging will take up to around 2 hours.
- 4. Once fully charged the battery LED indicator will turn off.

Note: Allow up to 3 hours for the first charge.

Battery information

- 1. Your device is powered by a rechargeable battery. Unplug the charger from the electrical plug and the device when not in use.
- 2. If left unused, a fully charged device will lose its charge over time. We recommend a full charge twice a month to ensure battery integrity.
- 3. Please do not leave the device in hot or cold places, such as in a closed car in summer or wintery conditions as it will reduce the capacity and lifetime of the battery.
- 4. Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged.

LED lights indication

Pairing mode	Flashing White
Paired in Bluetooth®	Solid White
Clear paired record	Red and White LED flash once
Battery below 30 minutes playtime	Flash Red every 6 seconds
Charging battery	Solid Red
Charging complete (around 95%)	Red LED turns off

Pairing the Airline Adaptor 2 to your device

- 1. Start by turning on the KS Airline Adaptor 2 by long press the Multifunction button for 3 seconds. The KS Airline Adaptor 2 will automatically enter pairing mode upon startup, if your device has not been paired previously.
- 2. Turn on your IOS, Android or Windows device's Bluetooth to ON and search for new devices.
- 3. Select KS Airline Adaptor 2 from the list of found devices. If asked for a pass code, enter '0000' and the KS Airline Adaptor will be connected.

Re-pairing or pairing new devices

1. Turn Bluetooth connectivity off on any previously paired devices

OR

2. Long press the MFB (1) to re-enter pairing mode

3. Follow the 'Pairing the Airline Adaptor 2 to your device' instructions

Note: If a previously paired device is not present within the Bluetooth connectivity range then the Airline Adaptor will re-enter pairing mode.

Bluetooth

When your headphones/speaker is connected to the Airline Adaptor via Bluetooth, play media on the device that the Airline Adaptor is connected too and the sound will play through your headphones/speaker.

Specifications

Bluetooth® technology v4.2		
Bluetooth connectivity distance	up to 18 m	
Battery	Li-ion, 500mAh	
Play time	up to 15 hours	
Charging time	up to 2 hours	
Working temperature	-20°C ~ +70°C	
Product size (mm)	H100mm x W62mm xD62mm	
Cable length	0.8 m	
Weight	20 g	

Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: support@kitsound.co.uk

'Hereby, Kondor Ltd declares that the radio equipment type, Airline Adaptor 2 (KSBTAP2), is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://kondor.co.uk/product-documents.'

FCC ID: 2ADFF-KSBTAP2

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device and ISM equipment, pursuant to part 15 of the FCC Rules respectively. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The use and operation of this product is beyond our control. Warranty of the Airline Adaptor 2 is limited to defects caused by faulty manufacture or defects in materials only. No warranty whatsoever is given or implied for damage caused by the user under any circumstances.

This does not affect your statutory rights.

Please do not attempt to open this product. There are no user serviceable parts inside. If your product has an embedded, non-replaceable battery, do not attempt to access or remove the battery. This may cause personal injury and will damage the product.

Making any attempt to open the product or carry out repair voids any and all warranties.

We are sorry for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.

BACKCOVER



The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Kondor Ltd. is under license. Other trademarks and trade names are those of their respective owners.

All trademarks are acknowledged as the property of their respective owners. Unless otherwise stated their use does not imply that the trademark owner is affiliated with KitSound or endorses the products herein.

Products showing the 'Crossed Through' wheelie bin symbol must be recycled separately from household waste at the end of their useful life. Please DO NOT dispose of this appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

Please recycle this packaging responsibly.



JB. 6775-a/REG02/KSBTAP2/Made in China. © KitSound is a trademark of Kondor Limited, 2019. Christchurch, Dorset, BH23 4FL, UK