

REG02 – International – US (MINUS CANADA)

FRONTCOVER



## ENGAGE 2 BLUETOOTH HEADPHONES WITH ACTIVE NOISE CANCELLING User Manual

INNER LEAF

**Please read this manual carefully before use.**



### **WARNING**

- Please do not get the product wet. If your product is IP rated, please follow guidelines on how to safely use your product overleaf.
- Please don't take the product apart. There are no user serviceable parts inside
- Please don't modify or alter the product or accessories
- Please don't expose the product to extreme temperatures or rapid changes of hot to cold or vice versa
- Please don't use damaged cables or plugs, or loose electrical sockets
- Please don't touch the device, cables, plugs, or the electrical socket with wet hands or other wet body parts
- Please don't pull the cable excessively when disconnecting it if the cable is not fixed
- Please don't bend or damage the cable
- Please don't drop or cause an impact to the product or the device
- Please don't place naked flame sources, such as lighted candles, on the product

### **Protect your hearing and ears when using a headset**



- Excessive exposure to loud sounds can cause hearing damage
  - Exposure to loud sounds while walking may distract your attention and cause an accident
- Always turn the volume down before plugging the earphones into an audio source and use only the minimum volume setting necessary to hear your conversation or music

- In dry environments, static electricity can build up in the headset. Avoid using headsets in dry environments or touch a metal object to discharge static electricity before connecting a headset to the device
- Do not use a headset while driving or riding. Doing so may distract your attention and cause an accident, or may be illegal depending on your region

### Battery Information


- Batteries may malfunction if they are not used for extended periods
- Over time, unused devices will discharge and must be recharged before use
- Disconnect the charger from power sources when not in use
- Use the batteries only for their intended purposes
- Follow all instructions in this manual to ensure the longest lifespan of your device and battery. Damages or poor performance caused by failure to follow warnings and instructions can void your manufacturer’s warranty
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like
- Please do not dispose of the battery in a fire or an oven, or mechanically crush or pierce the battery, as this may result in an explosion.
- Please do not subject the battery to extremely low air pressure, which may result in an explosion and/or the release of flammable liquid or gas

### Box contents

- KS Engage Bluetooth Headphones with Active Noise-Cancelling
- 3.5 mm aux cable
- USB charging cable
- User manual

### Functions

1. Micro USB Charging Port
2. Battery LED
3. ANC Function Button
4. ANC LED Indicator
5. Volume+/Next track
6. Multi-Function Button (MFB)
7. Volume-/Previous track
8. Aux Port
9. LED Indicator
10. Microphone



### Instructions for use

### Getting started

#### Charging the battery

Give the headphones a full charge before their first use.

1. Connect the Micro USB Charge Cable to the Micro USB Charging Port (1) and plug into power
2. The Battery LED (2) will be red whilst charging which will take up to 2 hours
3. Once fully charged the Battery LED (2) will turn green

**Note:** The first charge may take up to 2 hours to complete.

### Pairing the headphones to your device

1. Hold the MFB (6) down for 5 seconds. You will see the LED Indicator (9) flash red and blue and enter pairing mode
2. Turn on your iOS, Android, or Windows device's Bluetooth ON and search for new devices
3. Select KSENGAGE2 from the list of found devices. If asked for a passcode, enter '0000' or '1234' and the device will pair
4. Once connected, an audio tone will sound and the LED Indicator (4) will flash white. You can then answer the phone or listen to your music

**Note:** The next time you switch the headphones on they will automatically search for and attempt to connect to the last paired device

### Re-pairing or pairing new devices

1. Turn Bluetooth connectivity off on any previously paired devices
2. Follow the 'Pairing the headphones to your device' instructions from step 1

## Call handling

Answer a call	Short press MFB (6) to answer. You can adjust the volume by using Volume+ (5) or Volume- (7)
Reject a call	Hold MFB (6) to reject the incoming call
End call	Press MFB (6) while in the call to end it

## Playing music

### Bluetooth

Play/Pause	Press MFB (6)
Adjusting the volume	Press Volume+ (5) or Volume- (7). The volume can also be controlled on your device
Changing track	Press and hold Next track (5) or Previous track (7)

### Wired use [HEADPHONES ONLY]

1. Turn off the headphones
2. Plug the 3.5 mm aux cable into the headphone's Aux-in Port (8) and the other end into your device

**Note:** All functions are controlled via your device.

## Specifications

Bluetooth® technology v5.0	
Bluetooth connectivity distance	up to 10 m
Frequency band	2.402GHz-2.480GHz
Transmission power	+1 dBm (conducted)
S/N	≥80 dB
Frequency response	20 - 20, 000 Hz
Drivers	40mm
Output RMS	6mW
Battery	LiPo
Play time	Bluetooth with ANC off play time - 22 hours Bluetooth with ANC on play time - 13 hours Wired use with ANC on play time - 33 hours
Charging time	Up to 2 hours
Working temperature	-10°C to +45°C
Headphone (mm)	H210 x W180 xD80
Cable length	1.3 m
Weight	246g

## Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: [support@kitsound.co.uk](mailto:support@kitsound.co.uk)

'Hereby, Kondor Ltd declares that the radio equipment type, Engage 2, is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://kondor.co.uk/product-documents>.'

## **FCC ID: 2ADFF- KSENGA2**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device and ISM equipment, pursuant to part 15 of the FCC Rules respectively. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

The use and operation of this product is beyond our control. Warranty of the Engage 2 is limited to defects caused by faulty manufacture or defects in materials only. No warranty whatsoever is given or implied for damage caused by the user under any circumstances.

This does not affect your statutory rights.

Please do not attempt to open this product. There are no user serviceable parts inside. If your product has an embedded, non-replaceable battery, do not attempt to access or remove the battery. This may cause personal injury and will damage the product.

Making any attempt to open the product or carry out repair voids any and all warranties.

We are sorry for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.

#### BACKCOVER




[kitsound.co.uk](http://kitsound.co.uk)

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Kondor Ltd. is under license. Other trademarks and trade names are those of their respective owners.

All trademarks are acknowledged as the property of their respective owners. Unless otherwise stated their use does not imply that the trademark owner is affiliated with KitSound or endorses the products herein.

Products showing the 'Crossed Through' wheelee bin symbol must be recycled separately from household waste at the end of their useful life. Please DO NOT dispose of this appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

Please recycle this packaging responsibly.





JB. 7054-a/REG02/ KSENGA2/Made in China. © KitSound is a trademark of Kondor Limited, 2019.  
Christchurch, Dorset, BH23 4FL, UK