


# Quick Start Guide

Video Phone 30KH IT-14/15


## Step 1 - Connecting the Handset

Remove the device from the box and connect the coiled cord handset cable into the handset and the back of video phone.



## Step 2 - Connection

Remove the Ethernet network cable from the box and plug one end into the video phone as illustrated below and the other into your router. If you are connecting using Wi-Fi go to step 3.




# Quick Start Guide

Video Phone 30KH IT-14/15

## Step 3 - Switching On

Remove the power adapter and connect to the back of the video phone. Plug in the adapter to the mains socket and switch on. The video phone will display a logo. Follow the on-screen instructions.




Power Adapter Socket

## Step 4 - Login

Once you have switched on the video phone you will be presented with a login screen. Login to your account to unlock the phone.

## Video Phone Rear View



## Troubleshooting

For troubleshooting visit [www...](http://www...)