


# **CASE** Quick Start Remote Instructions

---




※ Accessories include a hot shoe adaptor, a charge cable and a hand strap

**Step 1, Connect CASE Remote with your camera through a USB cable**



**Attention:**A factory USB cable along with your camera package is recommended for connection. This package does NOT include this USB cable.

## Step 2, Turn on CASE Remote and your camera



### Step 3, Connect to CASE Remote WiFi and start App

- Go to your mobile device WiFi setting and choose the SSID and password on the label



## CHARGING

CASE Remote can be charged by any standard USB charger through provided cable. This package does NOT include a charger.



## **FCC Caution**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may

cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced



radio/TV technician for help.

### **FCC Radiated Exposure Statement:**

This equipment complies with FCC radiation exposure limits set for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

More operation instructions are available on

<http://www.CASERemote.com>

<http://www.cheeringtech.com/caseremote/>

and CheeringTech youtube channel

For any technical support, please contact  
[service@cheeringtech.com](mailto:service@cheeringtech.com)

For any sales questions, please contact  
[sales@cheeringtech.com](mailto:sales@cheeringtech.com)

