

# INNO Flask Manual

## 블랙 1도 양면인쇄 (520mm X 191mm)





Product Data	
Name of Product	Bluetooth wireless stereo Speaker
Model	INNO - FLASK
Power	5V DC +/- 5%, 1A
Size(Without Cover)	138mm X 67mm X 24.4mm (W X D X H, without case)
Internal Battery	3.7V DC / 750 mAh Li-Ion (play 10 hours)
Power	3W X 2 at 10% THD
Connection	Micro USB (Charging) / AUX Input (3.5mm)
Bluetooth	Bluetooth V2.1, Class2, A2DP
Used Frequency	2.4 ~ 2.48 GHz
Proper Temperature	0 ~ 45 °C
Manufacturer / Country	HAIJEN Co., Ltd. / China

This wireless equipment has a possibility of mixing electric waves and cannot provide the services on life and safety.

Thank you for purchasing INNO Device Bluetooth wireless Speaker. This product supports Bluetooth 2.1 and easy to hand carry, to provide high quality sound by simplified control. From your Bluetooth devices, you can play your music library to the product without connecting wires also by AUX cable. This product is targeting home-use (class B) electromagnetic wave instrument and can be used in any place.

The life time of battery may decrease slowly by repeating charging and discharging cycles. Play time is based on 1/2 volume.



### Before You Begin

This Product can provide you a music enjoyment by wireless stream audio contents from your mobile devices such as smartphone, MP3 player tablet or PC. You can roam around the house, office or outdoor to listen great music since the product has a rechargeable battery inside. Also, you can directly connect the devices using AUX line out. The device shall support Bluetooth higher than ver.2.1 and A2DP.

### Connecting Power and Charging

To charge battery, connect supplied USB cable to USB port of PC or DC adaptor with USB Port and the other end to Micro USB Port of the right hand side of the Product. From the connection, the internal battery will start to be charged. During re-charging, AUX source can playback regardless of the Product Power status.

**The internal battery may not be fully charged when you first open the Product. Please full charge the battery before use. Please use safety approved power adaptor.**

### Operation and Indication

- 1.1.1 Power Knob**
  - Slide Knob: Power On / Off
  - Sliding the knob up and down makes the system on and off. (It takes 2 sec to "On" after slide the knob.)
- Pairing Button**
  - Short press (0.5sec) : Pause and Play
  - Press and hold more than 2sec: Enter to Pairing mode
  - Press and hold more than 3sec: Enter to Device reset mode \*1
  - \*1 : If there is system error, use this function.
- Volume Up Button(+)**
  - Press shortly : Volume up
  - Press and hold more than 1sec : Track up
- Volume Down Button(-)**
  - Press shortly : Volume down
  - Press and hold more than 1sec : Track down
  - The volume control and track up/down control of system is also possible by a Bluetooth device that paired with the system, (using AVRCP function)
- 2.5 BT Pairing**
  - Pairing and connecting with a Bluetooth device.**
    - Turn on the system
    - White LED will slowly (0.5Hz) blink and search for the paired device.
    - Press and hold the pairing button more than 2 sec to enter pairing mode. White LED will begin to blink fast (2Hz).
    - Select "INNO FLASK" shown on the list of the Bluetooth devices.
    - "INNO FLASK" does not appear on the device's display, repeat from 2.

- Un-pairing Bluetooth**
  - Power off the product or deactivate Bluetooth wireless mode on your device.
- AUX source play back**
  - Connect your auxiliary source to the AUX-in jack on the right side of the Product with 3.5mm AUX cable.
- LEDs**
  - White LED (Bluetooth indicator)**
    - Power ON: Slow blinking (0.5Hz)
    - Wait pairing mode: Fast blinking (2Hz)
    - Bluetooth paired: Always ON
  - Red LED**
    - Battery in-charging: Always ON
    - Battery low: LED flash (times) 1min
    - Battery full charged: LED OFF
    - Bluetooth Device reset: LED flash 5times
  - Tone sound**
    - When power ON: 'Bebebebeep' tone up,
    - When power OFF: 'Bebebebeep' tone down,
    - When a Bluetooth device paired: 'Bebebeep' tone up

### Safety Instructions

As with general electronic product, precautions should be observed during handling and use.

- Read this instruction carefully and keep it.
- Heed all warnings and follow the instruction.
- Do not use the Product near water.
- Do not use with dry cloth.
- Do not block front or rear grilles.
- Do not install near any heat sources such as stoves.
- Protect the power (USB) cable from pressing by heavy substances or pulled by excessive power.
- Only use on horizontal and flat place.
- Unplug the Product during lightning storms or when unused for long periods of time.
- Contact a designated AS center when the power (USB) cable damaged, spilling liquid on Product, exposing Product to rain for long time, serious damage on Product by dropping it.
- Keep away magnetic recording devices from the Product as there may be a small amount of magnetic flux leakage.
- Only use under 50°C of environment to prevent any damage to built-in battery.

- Do not dispose of in the household waste, as the product contains a built-in battery and should be treated and disposed according to regulations on waste disposal.
- Sudden movement from cold to hot environment may cause moisture condensing on the Product and degrade system performance and decrease product life span.
- Protect product from direct sun light.
- Do not use solvents to clean the Product and keep away from dusty environment.
- Do not attempt to disassemble the Product.
- AC adaptor is not supplied with the Product. Damages caused by improper power adaptors is not compensated.
- Always leave sufficient space around the Product for ventilation. Do not place Product in or on a bed, in a bag that may prevent air flow through vent openings.
- Don't place lighted candles, cigarettes, etc. on the Product.
- Be care that heavy objects do not fall into the Product.
- To completely disconnect the power input, the USB cable should be disconnected from the Product.
- Use of the Product in moderate climates.
- Use under extreme temperature may degrade system performance and product life span.

### Certification Information and Warnings

**FCCID:2ADLCBTSACCESS**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**WARNING:** This equipment may generate or use radio frequency energy. Changes or modification to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

**WARNING:** This product contains magnets which can be harmful to pacemaker wearers.

Certified Company : INNO Device Co., Ltd.  
Product Name : Wireless Equipment with specified small power.  
Model : Series of INBTS - FLASK(BK)  
Manufacturer/Country : HAIJEN Co., Ltd. / China

**CAUTION**

THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.

CAUTION TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER OR BACKS. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

SEE MARKING ON BOTTOM / BACK OF PRODUCT

**WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

### Troubleshooting

**Q: The Product is not turned on.**  
A: Make sure built-in battery is fully charged. Check that the USB cable is not damaged and USB port of adaptor or PC is normal.

**Q: The Product is not charged.**  
A: Make sure the USB cable, plug is not damaged. Check the USB cable is connected to PC or adaptor USB port properly.

**Q: No sound or sound is very low.**  
A: Make sure the Bluetooth wireless connection is correct and playback has been successfully started. Make sure the volume on your Bluetooth device is turned up.

**Q: Paired device can not reconnect to the Product.**  
A: Delete "INNO FLASK" from the list on your Bluetooth device. Repeat the pairing procedures again. A re-connection may fall due to the pairing information has been deleted from your Bluetooth device.

Note in some device you may be prompted to enter a passkey. The passkey is "0000". This can be different for different devices.

### Warranty

INNO Device Co., Ltd. warrants to the original retail buyer of this product, under normal use and condition, to be free of material or workmanship within 12 month from the date of original purchasing. But the warranty for built-in battery is for 6 month.

Such defect will be repaired or replaced at designated AS center without charging cost.

To obtain proper repair or replacement within the terms of this warranty, the product to be returned with proof of warranty coverage (e.g. dated bill of sale) or visit the AS center with them. If the defective is proven as a user's responsibility, the cost of delivery and repair can be charged.

This warranty does not extend to the problem of compatibility with user's device nor the problem by using abnormal installation or cable. Also it does not apply to the problem by mis-handling, waterlogged or by removal of the Series labels or disassembled by non-qualified person. Company's liability is limited to the purchase price paid by purchaser for the product.

**INNO Device**  
www.innodevice.com

This warranty gives you specific legal rights and it may vary by regions. This warranty can not be moved nor transferred to the other person.

**BEFORE AS CLAIM**

Properly pack your unit including supplied accessories. We recommend using the original packing materials when you return the product to AS center.

**COPYRIGHT AND TRADEMARK**

The copyright of the product is owned by INNO Device Co., Ltd. Without INNO Device permission, it can not be copied, modified, transferred nor saved. Note the copyright and trademark not to be transformed to electric, mechanical, chemical, magnetic, optical or any other artificial media.

**USE AND RESPONSIBILITY**

The contents within this publication can be changed by INNO Device for improvement of internal design, operation, performance or reliability without a prior notice. INNO Device has no responsibility on installable, direct, indirect and accompanying injuries by faults or omission of this publication.

**INNO Device Co., Ltd**  
402 Uspace 1A, 670 Sampyeong-dong, Bundang-gu  
Seongnam Korea  
TEL : +82 31 724 2590  
CS : +82 31 724 2591  
FAX : +82 31 724 2594  
E-mail : cs@innodevice.com  
www.innodevice.com  
DESIGN BY INNO California  
Manufactured in China

**INNO Device Co., Ltd**  
402 Uspace 1A, 670 Sampyeong-dong, Bundang-gu  
Seongnam Korea  
TEL : +82 31 724 2590  
CS : +82 31 724 2591  
FAX : +82 31 724 2594  
E-mail : cs@innodevice.com  
www.innodevice.com  
DESIGN BY INNO California  
Manufactured in China

**INNO Device Co., Ltd**  
402 Uspace 1A, 670 Sampyeong-dong, Bundang-gu  
Seongnam Korea  
TEL : +82 31 724 2590  
CS : +82 31 724 2591  
FAX : +82 31 724 2594  
E-mail : cs@innodevice.com  
www.innodevice.com  
DESIGN BY INNO California  
Manufactured in China

### 제품 소개

INNO DEVICE의 블루투스 스피커를 구입해 주셔서 감사합니다. 본 제품은 블루투스 2.1을 지원하는 시스템으로 휴대와 조작성이 간편하며, 맑고 선명한 고품질 사운드를 제공합니다. 모든 스마트폰의 블루투스를 통해 무선으로 음악을 수신하여 플레이 할 수 있으며, 또한, AUX 케이블을 이용한 직접 입력도 가능합니다. 본 기기는 가정용(비급) 전자파 적합기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

### 제품의 제원

제품의 명칭	블루투스 무선 스피커/스피커
모델명	INNO - FLASK
사용 전원	5V DC +/- 5%, 1A
스피커 크기	138mm X 67mm X 24.4mm (W X D X H, 케이스 제외)
내장 배터리	3.7V DC / 750mAh Li-Ion (충전시간, 재생시간)
출력	3W X 2 at 10% THD
접속단자	Micro USB (충전) / AUX Input (3.5mm)
블루투스	Bluetooth V2.1, Class2, A2DP
사용 주파수	2.4 ~ 2.48 GHz
작동 동작 온도	0 ~ 45 °C
제조국가	중국

배터리의 수명/충/방전을 반복하면서 서서히 줄어들게 됩니다. 재생시간 기준은 1/2 볼륨입니다.

\* Series models per colors: INBTS - FLASK(BK) INBTS - FLASK(BL) INBTS - FLASK(OR) INBTS - FLASK(WH)



### 사용하기 전에

본 제품은 모든 종류의 블루투스 기기 (스마트폰, MP3 player, 태블릿, PC 등)로부터 무선으로 음악을 전송 받아 재생할 수 있도록 되었습니다. 또한, 기기에 내장된 배터리를 이용하여 집이나 사무실 또는 야외에서 별도의 전원 연결없이 음악을 들을 수 있으며, 경우에 따라 AUX 케이블을 통해서도 쉽게 연결할 수 있습니다. 단, 모바일 기기는 블루투스 버전 2.1 이상과 A2DP를 지원해야 합니다.

**전원연결 및 충전**

함께 제공되는 Micro USB 케이블을 이용하여 PC의 USB 포트 또는 USB 포트가 있는 DC 어댑터를 이용하여 제품 후측면 Micro USB 포트(DC IN)에 연결하면 전원이 공급 됩니다. 이때 내부 배터리는 자동으로 충전되기 시작 합니다. 충전중, AUX in Play인 경우 Power Off를 하여도 AUX in Play는 계속됩니다.

최초 사용자 내부 배터리가 충분히 충전되어 있지 않을 수 있으므로, 충전 후 사용 바랍니다. 충전용 어댑터는 안전 인증품을 사용 바랍니다.

### 조작과 표시

**전원키** : 슬라이드 버튼을 ON으로 밀면 약 2초후에 시작음과 함께 LED가 켜지면서 전원이 켜집니다.

**전원키** : 슬라이드 버튼을 OFF으로 밀면 종료음과 함께 함께 LED가 꺼집니다.

**볼륨 버튼**

- ▶ 짧게 누르면 소리를 높일 수 있으며 길게 (1초) 누르면 작성되는 다음 곡으로 이동합니다.
- ▶ 길게 누르면 소리를 줄일 수 있으며 길게 (1초) 누르면 재생되는 이전 곡으로 이동합니다.

**페어링 모드 진입** : 전원이 켜져 있는 상태에서, 페어링 버튼( )을 2초간 누릅니다.  
- 페어링 대기음과 함께 백색 LED가 빨리 깜빡입니다.

**페어링 대기** : 블루투스 기기에서 블루투스 기능을 활성화 시키고, '기타의 검색', '장치들을 실행하여 "INNO FLASK"를 선택하면 페어링이 됩니다.  
- 페어링 대기음: 백색 LED가 항상 점등되어 있습니다.

**페어링 해제하기** : 스피커의 전원을 끄거나, 블루투스 기기에서 블루투스 기능 활성화를 해제 시킵니다.

**스피커 시스템 리셋하기** : 시스템 오류가 있을 시 페어링 버튼( )을 5초간 누릅니다.

**다시 연결 하기** : 스피커의 전원이 꺼질 때마다 마지막으로 연결 된 기기와의 자동으로 연결 됩니다.

**AUX원래 재생하기** : AUX 잭을 AUX-IN 단자에 연결하는 것으로 재생은 가능합니다.

**LED 표시상태**

전원 ON : 백색 LED 느리게 점멸  
충전중 : 적색 LED 점멸  
점멸곡 : 적색 LED 소등  
방전경고 : 적색 LED 점멸(LED 플래시 5times / 1min)  
페어링 대기 : 백색 LED 점멸  
페어링 완료 : 백색 LED 점멸  
블루투스장치 리셋 : 적색 LED 플래시 5번 점멸 후 백색 LED로 점멸

**토노리**

전원 ON : 'Bebebebeep' 톤이 높아진다,  
전원 OFF : 'Bebebebeep' 톤이 낮아진다,  
블루투스 장치 연결 : 'Bebebeep'

케이스를 사용하여 제품을 보관하거나 우측 그림과 같이 설치 또는 제품 본체를 세우거나 놓아서 사용할 수 있습니다.

### 안전지침 및 주의사항

**전자 제품 취급 및 사용에 대한 일반적인 주의 사항들이므로 주의깊게 읽어 주시기 바랍니다.**

- 본 사용 설명서를 필독하신 후 보관하여 주십시오. 모든 권고에 주의를 기울여 본 사용 설명서에 순차적으로 따라 주십시오.
- 제품을 물 근처에서 사용하지 않아 주십시오.
- 제품 외관은 마른걸레로 닦아 주십시오.
- 제품의 전면부 그림을 가리지 않아 주십시오.
- 난방기구나 발열기 근처에 두지 마십시오.
- 전원(USB)케이블 위에 무거운 물체를 올려두거나 무리한 힘을 가해 사용하지 않도록 주의 하십시오.
- 제품은 평평한 곳에서 사용해 주십시오.
- 문제가 있는 날이나 오래 사용하지 않을 경우에는 전원(USB) 케이블을 분리하십시오.
- 본 제품은 약초, 담배등을 올려 놓지 않아 주십시오.
- 무거운 물체가 떨어지지 않도록 주의해 주십시오.
- 제품을 임의로 분해하지 않아 주십시오.
- 본 제품은 소량의 누설 자기장이 있으므로 마그네틱카드 등 자기 기록이 있는 물건을 접촉하지 마십시오.
- 본 제품은 내장 배터리가 들어있으므로, 주변 온도가 섭씨 50도 이상의 환경에서 사용하지 마십시오.

- 본 제품을 폐기해야 할 때는 반드시 지정한 적절한 폐기 업체를 통해 처리되어야 하며, 가정을 쓰레기와 엄격히 분리되어야 합니다.
- 추운환경에서 더운환경으로 갑자기 제품을 옮기면 결로 현상에 의해 성능과 수명이 감소할 수 있습니다.
- 제품이 직접 직광선에 닿지 않도록 주의 바랍니다.
- 제품을 닦을때 솔벤트와 같은 용제를 사용하지 않아 주십시오. 또한 먼지가 많은 곳을 피해 주십시오.
- 제품의 분해는 지정된 AS 센터에서만 가능합니다.
- 본 제품은 이물질이 들어있지 않습니다. 규격에 맞지 않는 이물질이 들어있는 경우 지정한 AS 센터에 문의하십시오.
- 물기가 있는 작은 화분이나 이물질, 책갈피, 가방 등 공기의 흐름이 나쁜 곳에서 사용하지 않아 주십시오.
- 전원(USB)케이블 플러그가 손상되거나, 제품위에 액체가 떨어졌거나, 습기나 비에 오랫동안 노출 되었거나, 제품을 임의로 분해한 후에 사용하는 경우 지정한 AS 센터에 문의하여 주시기 바랍니다.
- 본 제품은 소량의 누설 자기장이 있으므로 마그네틱카드 등 자기 기록이 있는 물건을 접촉하지 마십시오.
- 본 제품은 내장 배터리가 들어있으므로, 주변 온도가 섭씨 50도 이상의 환경에서 사용하지 마십시오.

### 기기의 인증정보

**FCCID:2ADLCBTSACCESS**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

**WARNING:** This product contains magnets which can be harmful to pacemaker wearers.

Certified Company : INNO Device Co., Ltd.  
Product Name : Wireless Equipment with specified small power.  
Model : Series of INBTS - FLASK(BK)  
Manufacturer/Country : HAIJEN Co., Ltd. / China

**CAUTION**

THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.

CAUTION TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER OR BACKS. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

SEE MARKING ON BOTTOM / BACK OF PRODUCT

**WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

가정용 방송통신기자재 B급 기기 KC ID : MSP-CDM-1H-FLASK

Class B Equipment (For Home Use Broadcasting & Communication Equipment)

인증받은 자의 상호 : (주)인노디바이스  
기자재의 명칭 : 특정소출력 무선기기 (무선데이터통신시스템용 무선기기)  
모델명 : INBTS-FLASK  
제조자/제조국가 : (주)하젠 / 중국

**문제 해결이 있습니까?**

**Q: 전원이 켜지지 않습니다.**  
A: 제품의 내장 배터리가 방전되어 있을 수 있습니다. 완전히 충전 후 다시 시도해 보십시오. 또는, 전원(USB) 케이블의 플러그가 파손되었는지, PC 또는 어댑터의 USB 포트가 정상인지 확인하십시오.

**Q: 충전이 되지 않습니다.**  
A: 전원(USB) 케이블의 플러그가 파손되었는지 확인하십시오. PC 또는 어댑터의 USB 포트에 정상적으로 결합되어 있는지 확인하십시오.

**Q: 소리가 들리지 않거나 매우 작게 들립니다.**  
A: 블루투스 기기가 잘 연결되고 정상적으로 시작 되었는지 확인해 주십시오. 그리고, 블루투스 기기(스마트폰 등)의 볼륨이 적당한 크기로 조정되었는지 확인해 주십시오.

**Q: 한 번 연결되었던 기기가 자동으로 재 연결되지 않습니다.**  
A: 기기에 등록된 "INNO FLASK"를 리스트에서 지우고 처음부터 다시 등록, 접속해 주시기 바랍니다. 블루투스 기기의 접속 정보가 매다 지워질 수 있기 때문입니다.

페어링 중 일부 기기에서 passkey를 요구할 경우 "0000"를 입력하시기 바랍니다. 그러나, 기기마다 차이가 있을 수 있습니다.

**품질보증**

(주)인노디바이스는 본 제품을 정상적으로 사용한 상태에서 부품 또는 AS센터에서 인정하는 불량에 대해 구매일로부터 12개월 간의 품질보증 초점 구매자에게 보증합니다. 단, 내장 배터리의 경우 6개월 간 보증합니다.

보증 기간내에는 무상수리 또는 교환 가능하며, 수리 및 교환을 위해 구입 시기를 증명할 수 있는 영수증과 불량 제품, 그리고 불량한 상태로 영리한 AS 센터로 배송하시거나 내방하시면 됩니다. 단, 고객 귀책 불량의 경우 택배비는 수리비와 함께 청구됩니다. 본 보증은 고객의 기기의 호환성으로 인한 문제 또는 규격과 맞지 않는 어댑터나 케이블로 인한 문제, 취급 부주의 및 사고, 침수, 오사용 또는 낙하, 임의 분해로 인한 파손에는 적용되지 않습니다. 출고 시 시리얼번호가 떨어져 손실된 제품에 대해서는 적용되지 않습니다.

제품의 복구 가치가 제품의 구입가로 한정됩니다.

본 제한 규정을 변경할 권한은 그 누구에게도 없습니다. 알려 드립니다.

(주) 인노디바이스  
www.innodevice.com

이 보증은 특정 법적 권한을 제공하며, 지역 (관할구역)에 따라 다양한 기타 권한을 제공 받을 수 있습니다. 이러한 권한은 본 보증의 보증에 어떤 영향을 받지 않습니다. 본 보증은 이전 또는 양도할 수 없습니다.

**AS 의뢰 전 확인사항**

제품된 약제서를 포함한 가능한 구입 시 원 포장함을 써서 포장하는 것을 권장합니다.

**저장권 및 등록사항**

본 제품의 저작권은 (주)인노디바이스가 소유합니다. 무단으로 어떠한 방법으로든 복제, 수정, 전달, 저장할 권리가 없습니다. 어떠한 언어로도 수정할 수 없습니다. 또한 다른 형식이나 전자적, 기계적, 자기적, 광학적, 화학적, 임의적 등 어떠한 형태로도 변경할 수 없음을 알려 드립니다.

**사용 및 책임**

(주)인노디바이스는 디자인, 기능, 성능 또는 신뢰성 개선을 위해 본 문서에 수록된 제품의 내용을 사전 통보 없이 변경할 권한이 있습니다.

(주) 인노디바이스  
www.innodevice.com

**INNO Flask**  
Pocket Bluetooth Speaker

**INNO Flask**  
Pocket Bluetooth Speaker

**INNO Flask**  
Pocket Bluetooth Speaker

**INNO Flask**  
Pocket Bluetooth Speaker

**INNO Flask**  
Pocket Bluetooth Speaker

(주) 인노디바이스  
경기도 성남시 분당구 삼평동 670 우스페이스 1A 402호  
TEL : +82 31 724 2590  
CS : +82 31 724 2591  
FAX : +82 31 724 2594  
E-mail : cs@innodevice.com  
www.innodevice.com  
DESIGN BY INNO California  
Manufactured in China