


EBS-706



Bluetooth speaker
EBS-706 User's Manual

Thank you for purchasing our bluetooth speaker, this manual will make you even more easy to it. Please take a closer look at the Bluetooth capabilities of your device before using this speaker.

Product Preview:



Key definition

1. Power key: long press the power button to hear the prompt sound, blue light flashing means that the boot is successful; Press the power button to shut down, light extinguished.

2. Light key: short press to change the light color, long press to turn on/off LED lighting.

3. Play / Pause button:

(1) Bluetooth mode: short press the play / pause button and double-click to call back with an outgoing phone number, short press to hang up, long press to disconnect.

4. Volume up and down: rotate clockwise to make the sound louder, counterclockwise Turn the sound to be quieter.

5. Previous and next key: short press the song to switch, long press the previous key to Switch the following functions: Bluetooth, TF card; Long press a solid song to disconnect Bluetooth from TWS pairing.

Operating Structions:

1. Bluetooth pairing

1.1 Long press power button to start speaker, there will be a voice prompt tone, "Bluetooth

mode", the blue light indicator flashes mean speaker enters the Bluetooth search state.

1.2 Turn on your phone's Bluetooth or other Bluetooth device and search for Bluetooth Name: EBS-706, click to pair, it will play music after connected.

Music playback

1.1 Click the play pause button to play or pause music;

1.2 Turn the knob clockwise to get louder, turn the knob counterclockwise to make the sound quieter; Press the up and down curve keys to switch between up and down songs.

Telephone answering / dialing operation

After the Bluetooth speaker is successfully paired, double-click the pause button will call back the last outgoing number in your phone.

Short-press to Hang up

After the Bluetooth speaker is successfully paired, when a phone calls in, to press pause key to answer; press gain to hung up.

TF card

When inserting the TF card into the card slot, a voice prompt tone will appear, the music in the TF card will be automatically played, and the speaker will automatically read the card within the audio file, the user can control the music playback using the speaker buttons.

TWS pairing mode

1.1 When 2pcs Speaker are not connected, press the pause/playback button and hold to enter the pairing mode, the speaker will automatically search for nearby speakers of the same model to pair them. When they are paired, the main light flashes slowly, and the secondary light is long.

1.2 To unpair the pairing mode, long press the pause playback button to disconnect the pairing mode.

1.3 In pairing mode to disconnect the phone: long press the speaker play button to disconnect

first Secondary; Press and hold the speaker broadcast button again to disconnect the phone.

Charging

Charge using the configuration charging cable, the charging voltage is DCSV, the red light is solid when charging, and the light is off when fully charged.

Colorful lighting effects

Long press the light key to turn the light on or off, click to toggle the light effect, a total of 9 effects.

Mode switch key

When the speaker is plugged in with a TF card, short press the power button to switch Bluetooth, TF card, this function is not available when speaker is not plugged in a TF card.

Important safety information

Before using the Bluetooth speaker, you need to confirm the following basic safety tips to ensure the safe and reliable use of the product:

1. Read and understand all safety guidelines.

2. Please use charging equipment that can provide output voltage DCSV/1A to avoid damage.

3. The product adopts built-in lithium battery, please turn off when not in use.

4. Do not let the product be close to the heat source of high temperature, do not grill or dry at high temperature.

5. Do not let the product fall or be hit hard, or apply heavy pressure on it.

List of packaged items

The box contains the following items, please contact to the seller if item missing:

1. Bluetooth speaker: 1 unit

2. USB charging cable: 1pc

3. Manual: 1 copy

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

* **RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.