

User Manual

Model No.: Beat



CONTENTS

1. Insert SIM card.....	*
2 Remove and install the battery.....	*
3. Call.....	*
4. Locked and unlock the screen.....	*
5. Enter the desktop.....	*
6. Manage contacts.....	*
7. Make a call.....	*
8. Send message.....	*
9. Write Email.....	*
10. Photo and video.....	*
11. Image viewer.....	*
12. Music.....	*
13. Internet.....	*
14. View notifications.....	*
15. Multi task.....	*
16. Change wallpaper.....	*
17. Add desktop widget.....	*
18. File manager.....	*

Thank you for choosing our mobile phones. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

1. Insert SIM card

1. Power off the phone and remove other external power
2. Take off the back cover and remove the battery of the phone
3. Insert SIM card into the SIM card slot in the phone.

2. Remove and Install the battery

The attached Li-ion battery along with the phone can be used after unpacking. For the first three times, please use up the power and charge it fully for new battery to perform well

Install the battery

1. Put the battery in the battery compartment, note that the metal end of the battery should be firstly inserted
2. Put on the back cover.

Remove the Battery

1. Take off the back cover.
2. Put finger on the side finger grip, and then lift up the battery from the finger grip to remove the battery.

3. Call

1. Hold the Power key to power on the phone. The phone will

automatically search for the network

2. When the phone is powered on, hold the Power key to power off the phone

4. Locked and unlock the screen

To lock the screen, you only need to press the power button on the right side of the phone, then the phone enter sleep mode. To unlock the screen, you only need to press the power button again, then the phone enter operating mode.

5. Enter the desktop

Unlock the screen and enter the desktop, all your applications will be displayed on the desktop. You can touch the icon to open the corresponding program, you can also press and drag the icon to sort. If you want to uninstall the application, drag the icon to the trash at the top.

6. Manage contacts

Please select the import contacts mode for the first time, the phone support several import contacts mode. You can import contacts in SIM card or SD card; also you can set the synchronization account, or create a new contact directly.

7. Make a call

You can make calls directly from the desktop which can also be used to search for contacts.

8. Send Message

Write a message, you can add one or more recipients. Text, pictures, facial expressions, contact information, audio and video are supported for the message content.

9. Write email

After you have set your email account, you can write and send you email, and you can get the notification when new email arrived.

10. Photo and video

Launch the camera to take pictures. continuous shooting, timing, effects, etc. are supported. To record video, you just need to switch camera to video mode.

11. Image viewer

Gallery application supports folder path, or you can double-click to zoom through a single picture, you can slide left or right to the next picture.

12. Music

Music application supports online music through the internet.

13. Internet

Browser support double-click or sliding to scale webpage. fast access to frequently used sites through site navigation. Support multi-tab, click the tab to switch pages.

14. View Notifications

When you have a new phone call, message or some other notification information, you can slide down from the status bar to see the notification details.

15. Multi task

Phone supports multiple tasks running simultaneously, you only need to long press the home button in unlock state.

16. Change wallpaper

You can change lock screen wallpaper or desktop wallpaper.

17. Add desktop widget

To add a desktop gadget you can long press the empty area on the desktop.

18. File manager

Through file manager, you can get the current usage of mobile phone memory card. File manager support quick browsing through classified documents, or manage files by path. also, remote file management capabilities are supported through WIFI from the remote computer.

Company: Xwireless LLC

Address: 11426 Rockville pike, Rockville Md.

Contact Person: Paul Greene

TEL: 001-3014124412

E-mail: paulgreene@prepaidwirelessgroup.com

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types mobile phone (FCC ID: 2ADLJBEAT) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory, product specific (wireless router), and simultaneous transmission conditions are 0.77 W/kg, 0.64 W/kg , 1.21 W/kg, and 1.33 W/kg respectively. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.