

User Guide

Contents

Quick User Guide	2
1. Power On/Off	2
2. Turn On /Off Screen	2
3. Lock and Unlock	2
4. Hot Buttons	2
5. Main Menu.....	3
6. Status Bar	3
7. Bluetooth Connection	3
8. WLAN Connection	3
Basic Functions.....	3
1. Alarm.....	3
2. Calculator	3
3. Browser	4
4. Calendar	4
5. Camera	4
6. File Manager.....	4
7. Facebook	4
8. FM Radio	4
9. Gallery	5
10. History	5
11. People	5
12. Phone	5
13. Sound Recorder	5
14. Play Music	5
15. Messaging	6
16. Dialer Interface.....	6
17. Settings.....	7
17.1 Wireless & networks	7
17.2 Device.....	8

17.3 Personal.....	8
17.4 System	9
18. Cursor.....	10

Quick User Guide

1. Power On/Off

In the power-off mode, long press **[Power]** key, it will power on; otherwise. In the power-on, long press **[Power]** key, and choose **Power off**, it will power off. If you set up SIM lock or phone lock, please input the code according to the requirements.

2. Turn On /Off Screen

2.1 Turn Off Screen

Please short press **[Power]** to turn off the screen to save power.

2.2 Turn On Screen

When the screen is off, please short press **[Power]** to wake up the screen.

3. Lock and Unlock

3.1 Lock

In idle screen , Please press **[Power]** to lock this screen to prevent some unexpected operations.

3.2 Unlock

After the screen is off, please press **anykey** to wake up the screen, and then press * and # to unlock the screen

4. Hot Buttons

On the shortcut bar, to touch dial button enters Dialer interface; to touch people button enters Contacts; to touch messaging button enters Messages interface; to touch music button enters music list.

5. Main Menu

In Main Menu interface, you can press [Menu] key to browse all the applications. Touch and choose one, you can enter and run this application.

6. Status Bar

On the LCD top of the idle interface, it is Status Bar. You can't operate the status bar, it displays some relevant information, including: WLAN, Bluetooth, Battery power, System time, etc.

7 Bluetooth Connection

This device supports Bluetooth 2.0, you can listen to music with Bluetooth earphone. About Bluetooth settings and operations, please refer to the section of Bluetooth in System Settings.

Prompt: *Bluetooth function and operations are based on the real product.*

8. WLAN Connection

This device supports "WIFI 802.11 b/g/n". You can access to the local network through WIFI . About WIFI settings and operations, please refer to the WIFI section in System Settings.

Basic Functions

1. Alarm

You can switch on or off alarm. You can customize clock time and ringtone to alert user.

2. Calculator

On Main menu, enter Calculator. It supports four arithmetic operations such as "+", "-", "*" and "/".

3. Browser

On Main menu, enter and run Internet, access to the website.

Press [**Menu**] to display options menu, operate the following:

Refresh, stop, home, save to book, close, share page, find on page, request desktop site, bookmark, setting.



4. Calendar

On Main menu, enter Calendar. You can check the date by navigation key



5. Camera

On Main menu, enter Camera.

5.1 Camera

Press center key or to take photos. Press  to switch between Camera or Video recorder, Press  to preview the photos. Touch setting icons to display the parameters box. Press the flash icon to open or close flash.

5.2 Video Recorder

After switching into Video Recorder, touch  begin to camcorder; touch  to stop. The other operations refer to Camera.

6. File Manager

On Main menu, You can open file or fold in phone or sd card. You can operate the following operation:

Delete, copy, cut, view detail.

7. Facebook

Log into Facebook to start sharing and connecting with your friends, family, and people you know.

8. FM Radio

On Main menu, enter FM Radio interface, insert headset, then you can listen to FM radio.

Prompt: *When the battery of your cell is insufficient, you may not run FM Radio.*

9. Gallery

In the folders list, choose and touch a photo folder to enter, slide from left to right to view pictures list. Touch a picture or photo to enter its view.

10. History

The call log is separated to All call, Miss call, dial Call, Received call. You can view the call time and the date time. You can press the call icon to dial the number in the call log.

11. People




1. The People include contacted and favorites and Group.
- 2 You can store new contact to usim or phone
- 3 You can view the contact information include name, phone, email, address etc.
- 4 If you want to add the contact to favorites. You can follow these step
Press the contact icon that you want to add it into favorites to edit the contact detail.
Press the five-pointed star icon. And you can see the contact in the favorites
- 5 You can create groups to save different class contact

12. Phone

You can input phone number then dial button to make a phone call

13. Sound Recorder

On Main menu, enter Sound Recorder. The format of recording files is *.3gpp, the recording length depends on the size of T-Flash card.

Touch  to record, touch  to stop recording, touch  to play the recording file in the list. Choose and long press a recording file to delete.

14. Play Music

Music player supports various audio formats, including: Midi, MP3, amr and wav, etc

15. Messaging

Press messaging icon into the messaging menu.

You can view all the messages from different contact.

If you want write a message to other people you can follow these steps

1 Press the top right corner icon.

2 Choose new message

3 Input the phone number in the input field or press the contact icon to choose phone number.

4 Input the information into the Text field

5 If you want to send files you can press the add icon to choose what you want to insert to the mms.

6 Press the send icon

16. Dialer Interface

Press the dialer key enter Dialer interface.

Dial a Call

16.1 Calls Category

16.1.1 Emergency Call


You can directly dial an emergency service call without SIM card.

Different network uses different emergency numbers, please consult your network operations company for more details.

16.1.2 Normal Call

Enter a phone number, choose SIM1 or SIM2 to make a call by SIM1 or SIM2. If you're making a long-distance call, please add the area code before the telephone number.

16.2 Answer a Call

When an incoming call arrives, the phone will give out the corresponding prompt (such as vibration, ringtone, and etc.); if network support, the phone screen will show the name and telephone number of the caller, slide  rightward, answer this call.

16.2.1 Refuse a Call


When a call is coming in, slide  leftward, refuse this call.

16.2.2 End a Call


After finishing a call, click  to end this call.


16.2.3 Call Operation


During a call, touch screen to operate the following:

Add Call: Click , enter a phone number, add another call.

Dialpad: Click  to display Dialpad interface.

Mute: Click  to set this call mute.

Speaker: Click , switch call voice to Speaker; click it again to switch call voice to Receiver.

End Call: When finishing a call, touch  to end call.

17. Settings

In settings, you can perform: Wireless controls, Sound settings, Display settings, Security & location, Applications, SD Card and Local disk, Date and time, Accessibility, Speech synthesis, About phone, etc.

17.1 Wireless & networks

In wireless network control, you can set WIFI, Bluetooth, Networks, VPN settings, Airplane mode, etc.

17.1.1 sim management:

In the menu you can view the sim card information and set simcard default setting

17.1.2 Wifi

Touch "WIFI" to switch between "On" and "Off".

Note: Please turn off WIFI to save power when not using.

You can view wifi that your mobile can scan

Choose one wifi you want to connect. Then input the password if it is necessary and press connect key

The mobile will connect the wifi if you input the password is correct or don't need password

The mobile connect with the selected wifi automatically. When you restart your mobile, wifi in the meantime the wifi devices is available

17.1.3 Bluetooth On/Off

Touch "Bluetooth" to switch between "On" and "Off".

Note: To save power, please turn off Bluetooth when not using.

Bluetooth settings

You can set Bluetooth On or off, Device name, Discoverable, Scan for devices and list the scanned devices.

Bluetooth On/Off: Touch "Bluetooth" to switch between "On" or "Off".

Device Name: It displays the factory device name, touch this item to edit its name.

Visible: Touch "visible" to switch between "On" or "Off". If it is "On", The Bluetooth devices nearby can detect this device.

Visibility timeout: Set how long device will be discoverable.

Search for devices: Touch this item to search the Bluetooth devices nearby.

Bluetooth devices List: When this device find other Bluetooth devices nearby, it will display them in this list, you can click one and then input PIN for matching and connection.

17.1.4 Data usage

Activate or disable data access over Mobile network.

17.1.5 Airplane mode

Touch "Airplane Mode" to switch between "On" and "Off". If Airplane mode is On, all the wireless networks will be disconnected automatically in this mode.

Warning: Even if airplane mode is activated, it is forbidden to use (on) in plane or in some *special labs or under hospital equipments, other special environments, etc., so as to prevent the intervention of electronic equipments to the communication or this device, you are advised to power off this device in such environments.*

17.1.6 Tethering & portable hotspot

Share your phone's mobile data connection via USB or as a portable WIFI hotspot.

17.1.7 Mobile Networks

In Mobile Networks, you can set Data enabled or Data Roaming or Access Point Names or Network Operators.

17.2 Device

17.2.1 Audio profiles

In sound settings, you can set Silent Mode, Ringer Volume, Media Volume, Notification Ringtone, Audible Touch Tones, Audible Selection, Feedback etc.

17.2.2 Display Settings

In display settings, you can perform such operations as "Brightness", "Wallpaper", "Sleep", etc.

17.2.3 Storage

17.2.3.1 Phone Storage

View the capacity of ROM.

17.2.3.2 SD Card

View The capacity of sd card.

17.2.4 Battery

Check the electricity consumed by each application.

17.3 Personal

17.3.1 Location

You can set Mode as you need, management your application through this function.

17.3.2 Security

You can set Set up screen lock.

None: Disable screen unlock security.

Key: when you turn on your mobile screen you must Press * key then press #key to unlock screen If you turn on this option.

Owner info

Show text to display on the lock screen.

Set up SIM card lock

You can set up SIM1 or SIM2 card lock.

17.3.3 Language & input

17.3.3.1 Language

You can select language, the default language is English.

17.3.3.2 KEYBOARD & INPUT METHODS

You can check Nikie and android keyboard input method. Meanwhile you can choose which input method is default.

17.3.4 Backup & reset

It includes back up my data, backup account, Automatic restore, DRM reset, Factory data reset.

17.4 System

17.4.1 Date & Time

17.4.1.1 Automatic date & time

Touch this item to switch between “On” and “Off”. If it is set as “On”, it updates the date and time automatically. This function is based on the services provided by the network.

Note: When this item is initiated, “Set Date”, “Select Time Zone” and “Set Time” are not available.

17.4.1.2 Automatic

Use network provided time zone

17.4.1.3 Set date

With time updating “Off”, touch it to display the dialog box of Date Setting.

17.4.1.4 Set time

With time updating “Off”, touch it to display the dialog box of Time Setting, and set system time.

17.4.1.5 Use 24-hour format

Touch this item to switch between “On” and “Off”. If it is “On”, system time is in 24-hour format, otherwise, it is in 12-hour format.

17.4.1.6 Choose date format

Select one item to set date format.

17.4.1.7 Select time zone

Touch this item to enter “Select Time Zone”, touch and select any one of world cities, and set it as

system time zone. The default time is Beijing time.

17.4.2 Scheduled power on & off

Set automatic switch machine on or off.

17.4.3 About phone

17.4.3.1 Status

You can check and view “ Battery status”, “Battery level”, “SIM satus”, “IMEI information”, “Wi-Fi MAC address”, “Bluetooth address”, “IP address”, “Serial number”, “Up time”.

17.4.3.2 Legal information

Check the open source license.

17.4.3.3 Model number

Display the device number.

17.4.3.4 Android version

Display its Android version.

17.4.3.5 Baseband version.

Display its Baseband version.

17.4.3.6 Kernel version

Display its kernel version

17.4.3.7 Build number

Display its device build number.

17.4.3.8 Custom build version

Display its software version.

18. Cursor

Long press 0 can turn on or off cursor function. When you turn on cursor function, you can move cursor to anywhere on the screen by navigation key.

Prompt: *When you turn on the cursor function .you can not page screen*

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types mobile phone / (FCC ID: 2ADLJHOTSPOT) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on - line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the

user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.