

Technical Description

ET-0050TX: The launch uses the remote control car special TX-3E IC Coding IC and the peripheral oscillation modulation amplification circuit is composed. When the function button is pressed by the IC encoded into a set of binary serial code, by the modulation circuit to load the encoded signal into the carrier, amplified by amplification circuit and emitted by the antenna. The frequency range is 27.145MHz.