

Size : 420 x 110 mm

<div data-bbox="198 459 503 582" data-label="Image"> </div> <div data-bbox="152 613 549 684" data-label="Section-Header"> <h2>WALL CLIMBER RC VENOM CAR</h2> </div> <div data-bbox="213 705 503 735" data-label="Section-Header"> <h3>Instruction Manual</h3> </div> <div data-bbox="152 746 549 807" data-label="Text"> <p>Thank you for purchasing the Wall Climber RC Venom Car. This manual provides more information about this RC Car, please read the instructions before using.</p> </div> <div data-bbox="152 848 564 1093" data-label="Image"> </div>	<div data-bbox="518 419 579 470" data-label="Text"> <p>AGES 8+</p> </div> <div data-bbox="595 419 1037 449" data-label="Section-Header"> <h4>Product Overview</h4> </div> <div data-bbox="625 490 1022 735" data-label="Image"> </div> <div data-bbox="640 746 1007 776" data-label="Caption"> <p>Wall Climber Remote Control Venom Car</p> </div> <div data-bbox="656 797 778 1093" data-label="Image"> </div> <div data-bbox="640 1093 808 1124" data-label="Caption"> <p>Remote Controller</p> </div> <div data-bbox="869 970 1022 1093" data-label="Image"> </div> <div data-bbox="869 1093 1037 1124" data-label="Caption"> <p>Instruction Manual</p> </div>	<div data-bbox="1068 419 1510 449" data-label="Section-Header"> <h4>Package Contents</h4> </div> <div data-bbox="1068 459 1510 602" data-label="Text"> <p>Includes: 1(One) Wall Climber Remote Control Venom Car 6.26in. x 2.76in. x 1.77in. (15.9cm x 7cm x 4.5cm). 1(One) Remote Controller 8.27in. x 2.24in. x 1.45in. (21cm x 5.7cm x 3.7cm). 1(One) Instruction Manual</p> </div> <div data-bbox="1068 623 1510 654" data-label="Section-Header"> <h4>Specifications</h4> </div> <div data-bbox="1068 664 1510 807" data-label="Text"> <p>Wall Climber Remote Control Venom Car Power supply: Built in Li-ion Battery 3.7V / 500 mAh Remote Controller: Power supply: 2 x "AAA" 1.5V Batteries (alkaline type preferred, not included) Frequency: 27 MHz</p> </div> <div data-bbox="1068 858 1510 889" data-label="Section-Header"> <h4>Remote Controller</h4> </div> <div data-bbox="1113 899 1464 1134" data-label="Image"> </div>	<div data-bbox="1541 419 1983 449" data-label="Section-Header"> <h4>Standard Control</h4> </div> <div data-bbox="1541 459 1983 511" data-label="Text"> <p>Note: To avoid losing control, always pay attention when controlling the Remote Control Car.</p> </div> <div data-bbox="1587 521 1938 756" data-label="Image"> </div> <div data-bbox="1587 735 1938 807" data-label="Caption"> <p>Forward Button Control Wall Climber Remote Control Venom Car to move forward</p> </div> <div data-bbox="1587 817 1938 1073" data-label="Image"> </div> <div data-bbox="1587 1042 1938 1124" data-label="Caption"> <p>Backward Button Control Wall Climber Remote Control Venom Car to move backward-right</p> </div>	<div data-bbox="2014 419 2456 449" data-label="Section-Header"> <h4>Power On/Off</h4> </div> <div data-bbox="2014 459 2456 960" data-label="Image"> </div> <div data-bbox="2014 970 2456 1124" data-label="Text"> <p>Power On/Off Slide the FLOORS/OFF/WALLS Switch to "FLOORS" to turn on the Wall Climber RC Venom Car for normal running. Slide the FLOORS/OFF/WALLS Switch to "WALLS" to turn on the Wall Climber RC Venom Car for wall climbing. Slide the FLOORS/OFF/WALLS Switch to "OFF" to turn off the Wall Climber RC Venom Car.</p> </div>	<div data-bbox="2487 419 2929 449" data-label="Section-Header"> <h4>Charging the Remote Control Venom Car</h4> </div> <div data-bbox="2487 459 2929 827" data-label="Image"> </div> <div data-bbox="2487 838 2929 981" data-label="Text"> <p>△ For your safety, please always use appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick-Charging USB Adapter to charge the product, as it might damage the product. 1. Use the Micro USB charging cable. (Not Included) 2. Connect the Micro USB plug to Micro USB charging port on the Wall Climber RC Venom Car, then connect the USB plug to a USB port on a computer or wall adapter to begin charging. 3. The LED Indicator will turn red while charging and will turn off once fully charged.</p> </div> <div data-bbox="2487 991 2929 1062" data-label="Text"> <p>NOTE: • You must select a qualified charger from a regular manufacturer. • You must charge the Wall Climber RC Venom Car if it has been not used for more than 6 months.</p> </div> <div data-bbox="2517 1073 2899 1134" data-label="Image"> </div>
<div data-bbox="137 1154 564 1185" data-label="Section-Header"> <h4>Batteries Installation For Remote Controller</h4> </div> <div data-bbox="137 1257 564 1696" data-label="Image"> </div> <div data-bbox="137 1706 564 1778" data-label="Text"> <p>To install batteries into the Remote Controller, unscrew the screw on the battery box cover to open the cover. Insert 2(Two) X AAA 1.5V Alkaline Batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace the battery box cover and tighten the screw.</p> </div> <div data-bbox="137 1788 564 1849" data-label="Text"> <p>Notice: When inserting the batteries, you must insert according to the correct polarity, the Remote Control won't function if batteries are reversed.</p> </div>	<div data-bbox="595 1154 1037 1185" data-label="Section-Header"> <h4>We Can Play the Car On</h4> </div> <div data-bbox="595 1257 1037 1533" data-label="Image"> </div> <div data-bbox="595 1563 1037 1849" data-label="Image"> </div>	<div data-bbox="1068 1154 1510 1185" data-label="Section-Header"> <h4>Performance Tips</h4> </div> <div data-bbox="1068 1195 1510 1297" data-label="List-Group"> <ol style="list-style-type: none"> Do not drive the Wall Climber Rc Venom Car on grass, sand or go through water. Do not drive the Wall Climber Rc Venom Car in windy or rainy weather. Do not drive the Wall Climber Rc Venom Car into any sharp object. Keep fingers, hair and loose clothing away from Wall Climber Rc Venom Car. </div> <div data-bbox="1068 1318 1510 1349" data-label="Section-Header"> <h4>Care and Maintenance</h4> </div> <div data-bbox="1068 1359 1510 1533" data-label="Text"> <p>Always use dry and soft cloth to clean this product. Avoid this product from being exposed to sunlight or heat. Avoid immersing these toys in water, otherwise, the electronic parts may be damaged. Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired in good working condition.</p> </div> <div data-bbox="1068 1563 1510 1594" data-label="Section-Header"> <h4>IMPORTANT: BATTERY INFORMATION</h4> </div> <div data-bbox="1068 1604 1510 1849" data-label="List-Group"> <p>△ CAUTION:</p> <ol style="list-style-type: none"> TO AVOID BATTERY LEAKAGE <ol style="list-style-type: none"> Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries. Remove exhausted or dead batteries from the product. Remove batteries if product is not to be played with for a long time. Do not short-circuit the supply terminals. Should this product cause, or be affected by local electrical interference, move it away from other electrical equipment. Reset (switching ON & OFF again or removing and re-inserting batteries) if necessary. </div>	<div data-bbox="1541 1154 1983 1185" data-label="Section-Header"> <h4>IMPORTANT: BATTERY INFORMATION</h4> </div> <div data-bbox="1541 1195 1983 1349" data-label="List-Group"> <p>△ CAUTION:</p> <ol style="list-style-type: none"> TO AVOID BATTERY LEAKAGE <ol style="list-style-type: none"> Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries. Remove exhausted or dead batteries from the product. Remove batteries if product is not to be played with for a long time. Do not short-circuit the supply terminals. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES. Should this product cause, or be affected by local electrical interference, move it away from other electrical equipment. Reset (switching ON & OFF again or removing and re-inserting batteries) if necessary. </div> <div data-bbox="1541 1359 1983 1389" data-label="Section-Header"> <h4>For AAA Batteries</h4> </div> <div data-bbox="1541 1400 1983 1676" data-label="List-Group"> <p>△ WARNING: TO AVOID BATTERY LEAKAGE</p> <ol style="list-style-type: none"> The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222). Always purchase the correct size and grade of battery most suitable for intended use. Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries. Clean the battery contacts and those of the device prior to battery installation. Ensure the batteries are installed correctly with the regard to polarity (+ and -). Always remove batteries if consumed or if product is to be left unused for a long time. </div> <div data-bbox="1541 1686 1983 1716" data-label="Section-Header"> <h4>Li-ion battery charging warning statement:</h4> </div> <div data-bbox="1541 1727 1983 1849" data-label="Text"> <p>The input to the USB Charging Adapter is 5V 1A. In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/104 deg °F. Do not heat above 70 deg °C/158 deg °F. Do not expose to sunlight or throw into fire. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.</p> </div>	<div data-bbox="2014 1154 2456 1185" data-label="Section-Header"> <h4>Warning</h4> </div> <div data-bbox="2014 1195 2456 1246" data-label="Text"> <p>This product is suitable to be used by people who has operating experience in remote toy or aged no less than 8 years old.</p> </div> <div data-bbox="2014 1257 2456 1287" data-label="Text"> <p>Please do not put the product in your mouth to prevent choking hazard of small parts.</p> </div> <div data-bbox="2014 1297 2456 1328" data-label="Text"> <p>Please do not put the finger into available interspaces.</p> </div> <div data-bbox="2014 1338 2456 1369" data-label="Text"> <p>Please do not play the product in a brutal way such as throwing, crashing or twisting it.</p> </div> <div data-bbox="2014 1379 2456 1410" data-label="Text"> <p>Please store the smaller-sized product accessories in places that are out of reach of children, in order to avoid the occurrence of accidents.</p> </div> <div data-bbox="2014 1420 2456 1451" data-label="Text"> <p>Avoid placing the batteries in places in high temperatures and avoid exposure to heat.</p> </div> <div data-bbox="2014 1461 2456 1522" data-label="Text"> <p>When young children are operating the product, it shall be ensured that the adults are guiding and making sure the product control is within the viewing range of the controller (or instructor) so that it makes the control of the toy more convenient.</p> </div> <div data-bbox="2014 1533 2456 1584" data-label="Text"> <p>When the product is not in use, please switch off the power supplies of the toy, and remove the batteries from the product.</p> </div> <div data-bbox="2014 1594 2456 1655" data-label="Text"> <p>Please note that we won't take any responsibility for any wrong operation as this may result in severe injury or loss of property, and we cannot control the operating process during the time when the user assembles or uses this product.</p> </div> <div data-bbox="2014 1665 2456 1716" data-label="Text"> <p>Once this product is sold, we won't be responsible for any safety responsibility during the time the user operates or uses controls this products.</p> </div>	<div data-bbox="2487 1154 2929 1185" data-label="Section-Header"> <h4>FCC Statement</h4> </div> <div data-bbox="2487 1195 2929 1277" data-label="Text"> <p>This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> </div> <div data-bbox="2487 1287 2929 1318" data-label="Text"> <p>Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> </div> <div data-bbox="2487 1328 2929 1584" data-label="Text"> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or experienced radio/ TV technician for help.</p> </div> <div data-bbox="2487 1594 2929 1655" data-label="Text"> <p>RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> </div> <div data-bbox="2487 1665 2929 1696" data-label="Text"> <p>FCC ID: 2ADM5-ET-0454</p> </div> <div data-bbox="2487 1706 2533 1737" data-label="Image"> </div> <div data-bbox="2487 1768 2929 1829" data-label="Text"> <p>Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106</p> </div> <div data-bbox="2487 1839 2929 1870" data-label="Text"> <p>Keep All Relevant Information for Future Reference Item# ET-0454</p> </div>