KID SAFE WIRFIESS HEADPHONES INSTRUCTION MANUAL 4.2. Pairing to Mobile phone or other device To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile

phone, they will remain paired and

they are within range.

function is activated

to select this pairing.

information.

press Yes/OK.

automatically recognize each other whenever

Pairing to a phone and Entertainment:

• Turn on your phone and ensure the Bluetooth

· Search your Bluetooth devices on your phone

by following the phone's instructions. Refer

to your phone's user manual for more

· After a few seconds the phone will list the

"BT AVENGERS HP" as a discover device.

Select it and follow your phone's instructions

Your phone will confirm the pairing, and then

. Finally, select to connect with Kid Safe Wireless

· Turn on the headphones, enter the pairing mode.

4.2 Pairing To Mobile Phone 4 4.3 Charging Your Product 5 5 Product Specification 6 6 FAO...... 6 Statement 7 7 FCC Statement ····· 8

Table of contents

1 Introduction------1

2 Packaging Contents 2

3 Connection Diagram ····· 2

4 How To Use 3

4.1 General Function 3

AGES

4.3. Charging your headphones Use the Micro USB cable accessory provided with this headphones. Connect the Micro USB plug to the Micro USB charging port on the headphones positioned at (1) in headphones diagram on page 2.

Connect the USB plug to a USB port on a computer or wall adapter to activate for a minimum of 2 hours before initial use. A For your safety, please always use appropriate 5V input

**Make sure to keep the headphones charging

charging.

· You must select a qualified charger from

· You must charge the Bluetooth headphones

if it has not been used for more than 6 months.

a regular manufacturer.

USB Plug

charger/Adapter to charge the product.

DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.

Micro USB Plug

Playing Time 2 - 3 Hours

6.FAQ 1. Why is there no power even when the headphones

1. Introduction

Safety Rules

Congratulations, and thank you for choosing

Kid Safe Wireless Headphones, but firstly

the Kid Safe Wireless Headphones.

This manual will help you operate the

you should familiarize yourself with the

Bluetooth functionality of your mobile

phone or other devices before using

the Kid Safe Wireless Headphones.

Please follow the rules depicted in this

Before using this Bluetooth headphones, we would strongly encourage you to read through this user manual.

manual closely to ensure your safety.

Be more wary of any edges, uneven

its packaging so as to prevent any possible injury or damage.

surfaces, metal parts, accessories and

Do not modify, repair or dismantle this

Bluetooth headphones. Doing so may

result in fires, electric shocks, compléte

Do not use an diluent or volatile liquid to clean the Bluetooth headphones Do not use the Bluetooth headphones in a

hazardous location.

5. Product Specification

Driver Diameter 40 mm

Sensitivity

Frequency Range 20 Hz - 20 KHz

Impedance 32 Ohms

Voltage 3.7V

Battery Capacity 180 mAh

Receiver Distance ≤32.8 Feet

Charging Time 2 Hours

Power Supply Li-ion Battery

< 85 dB

breakdown of this Bluetooth headphones, etc. All are not covered under warranty.

is turned on ? Ans: Ensure the battery has been charged up to 1 hour for initial use.

please connect again. Make sure the headphones is

phone or computer, if the connection is not established,

Ans: Check the connection between headphones with

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

-Only charge the product at ambient temperatures between

adapter for charging the product.

⚠ Safety instructions for the lithium battery and charging the product 7. FCC Statement

1 X Micro USB Cable

X Instruction Manual

Micro USB

On / Off Butto

and 40 deg °C/104 deg °F. - Do not heat above 70 deg °C/158 deg °F, e.g. Do not expose

to sunlight or throw into fire.

-Switch off the product after use.

-Please note that we won't take any responsibility for any

wrong operation (e.g. Voltage higher than 5V) as this may

result in severe injury or loss of property, and we cannot

control the operating process during the time the user using

-In extreme cases, abuse or misuse of Lithium battery pack

RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

4. How to use

Desired Result

Enter the pairing

Turn on &

mode

Pairing

Turn off

Charging

Answering

Play / Pause

subject to the following two conditions:

operate the equipment.

following measures:

(1) This device may not cause harmful interference.

instructions, may cause harmful interference to radio

Reorient or relocate the receiving antenna.

that to which the receiver is connected.

communications. However, there is no guarantee that interference

can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from

Consult the dealer or an experienced radio/TV technician for help.

will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which

a Call

Music

4.1.General Functions

Required Action

Press and hold the On / Off Button

for 3 seconds. After turning on, the

Use a mobile phone with Bluetooth

function or other Bluetooth devices

to perform necessary pairing action.

Press and hold the On / Off Button

Plug the Micro USB to the Micro USB port. When charging, the LED

the LED indicator turns off

Double click to redial last call

indicator turns red. After full charging.

Press On / Off button to answer phone

Press and hold 2 seconds to reject call

Press On / Off button to play music

and press it again to pause music.

call, press On / Off button again to end call.

blinks with blue

for 3 seconds

1. This device complies with Part 15 of the FCC Rules. Operation is

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to

After pairing the LED indicator slowly

LED indicator flashes red/blue

FCC ID: 2ADM5-HP0063

Distributed by 1616 Holdings, Inc 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China

Item# HP-0063-BT AVENGERS

2. There is no sound when playback.

master device

paired and connected with your target phone or other

2. Packaging Contents

1 X Kid Safe Wireless Headphones

3.Connection Diagram

-The input voltage to the product is 5V 1A.

10 deg °C/50 deg °F

smoke development.

G

-In order to charge the product in safe manner and reliable

conditions, please only adopt certified appropriate charger/

can lead to explosion, heat generation, fire development or

Keep all relevant information for future reference

Headphones from your phone.