

WIRELESS USB ADAPTER

HIGH SPEED CONNECTION


INSTRUCTION MANUAL

Thank you for purchasing

This manual provides more information about the adapter. please read the instructions before using.



Product Overview



Package Contents

Wireless USB Adapter x 1 Instruction Manual x 1

Specifications

Wireless Standards IEEE 802.11n (draft) IEEE 802.11g IEEE 802.11b

High Speed USB 2.0

802.11n; up to 150Mbps (downlink) and 150Mbps (uplink) 802.11g: 54 /48/36/24/18/12/9/6 Mbps auto fallback 802 11b: 11/5 5/2/1 Mbps auto fallback

Frequency Band

2.4GHZ ISM (Industrial Scientific Medical) Band 2412 - 2472 MHz

RF Frequency

- 13 channels (Universal Domain Selection) Radio Channel Range Coverage Up to 3 times farther range than 802.11g

Antenna Type Integrated Antenna

Full mobility and seamless roaming from cell to cell Roaming

Data Security

64/128-bit WEP WPA, WPA-PSK, WPA2, WPA2-PSK, TKIP/AES CSMA/CA with ACK

Windows XP, Vista, WIN7, WIN8, WIN10, Linux and MAC OS x

Operating Temperature: 0°C to 40°C

Environment

Storage Temperature: -20 °C to 75 °C Operating Humidity: 10% - 90% (Non Condensing) Storage Humidity: 5% - 95% (Non Condensing)

How To Use

Step 1: Hardware installation:

1. Install the antenna attached on the USB Adapter.



2. Insert USB adapter into USB socket of your PC or Notebook.



Note: Suggest to use the rear side of USB socket on your PC to get better performance.

Step 2: Software installation

1. Visit website: http://120.77.216.242/drivepy/ to download the driver.



2. Select the correct driver for your computer operation system.

Download Drivers





3. The driver saved in the folder after download. Install the driver by double click it.



Organize * 🚍 Oper	Share with ▼ E-mail Burn New folder				# · []	
🔅 Favorites	Name	Date modified	Type	Size		
	Linux Setup tar.bz2	5/1/2021 10:44	822 File	1,151 KB		
Up Libraries	Mac Os Setup dma	5/1/2021 10:44	DMG File	4,719 KB		
□ Documents	ER Win Setup	5/1/2021 10:34	Application	43,916 1/8		

4. Select "Laccept...." then Click Next.



Select either one to install.




Click Finish to complete installation of driver.



Step 3: Wireless Network Connection

- 1. Click the Wi-Fi icon in the task bar from your computer.
- 2. Select the Wi-Fi to connect it.



SAFETY INFORMATION

In order to keep the safety of users and your properties, please follow the following safety instructions:

- 1. This wireless USB adapter is designed for indoor use only. DO NOT expose this wireless USB adapter to direct sun light, rain, or snow.
- 2. DO NOT put this wireless USB adapter at or near hot or humid places, like kitchen or bathroom. Also, do not left this wireless USB adapter in the car in summer.
- 3. This wireless USB adapter is small enough to put in a child's mouth, and it could cause serious injury or could be fatal. If they throw the wireless USB adapter, the card will be damaged. Please keep this wireless usb adapter out the reach of children!
- 4. This wireless USB adapter will become hot when being used for long time (This is normal and is not a malfunction). DO NOT put the wireless USB adapter on a paper, cloth, or other flammable objects after the wireless USB adapter has been used for a long time.
- 5. There's no user-serviceable part inside the wireless USB adapter. If you found Connect the equipment into an outlet on a circuit different from that to which the that the wireless USB adapter is not working properly, please contact your dealer receiver is connected. of purchase and ask for help. DO NOT disassemble the wireless USB adapter by Consult the dealer or an experienced radio/TV technician for help. your self, warranty will be void.
- 6. If the wireless USB adapter falls into water, do not use it again. The device has been evaluated to meet general RF exposure requirement. The Before you send the wireless usb adapter to the dealer of purchase for inspection. device can be used in portable exposure condition without restriction.
- 7. If you smell something strange or even see some smoke coming out from the wireless USB adapter, switch the computer off immediately, and call dealer of purchase for help.

Microsoft® and Windows® are either registered trademarks of Microsoft Corporation in the United States and/or other countries. Mac OS® is a trademark of Apple Inc., registered in the U.S. and other countries. ITEM# WR-0002

RF warning statement:

FCC STATEMENT

following two conditions:

may cause undesired operation.

(1) This device may not cause harmful interference.

FCC ID: 2ADM5-WR-0002



Keep all relevant information for future reference

Made in China

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the

(2) This device must accept any interference received, including interference that

2. Changes or modifications not expressly approved by the party responsible for

NOTE: This equipment has been tested and found to comply with the limits for a

frequency energy and, if not installed and used in accordance with the instructions,

guarantee that interference will not occur in a particular installation. If this equipment

Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates uses and can radiate radio

may cause harmful interference to radio communications. However, there is no

does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to

compliance could void the user's authority to operate the equipment.

correct the interference by one or more of the following measures:

Increase the separation between the equipment and receiver.

Reorient or relocate the receiving antenna.

701 Market Street, Suite 200 Philadelphia, PA 19106