



C30



align center and silkscreen on the button

丝印绿色和白色

Center Horizontally




silkscreen letter in white C
丝印颜色白色



align center and silkscreen on the button

底壳丝印颜色Silver877C
(银色877C)

Center Horizontally



silkscreen letters in Silver877C

