

- Print in PMS4695 U ■ (SOY-BASED INKS)
- Print MONOTONE High Resolution picture as PMS4695 U
- Print on 128 g 100% Recycled Woodfree Paper
- Don't print dieline & PMS7500 U

B.

Symphony No. 2™

You're the conductor! Choose up to 6 instruments to put in the orchestra pit and hear them play together. Then change up the instruments and hear the musical transformation.


FUNCTIONS

1. ORCHESTRA PIT

This is where the magic happens. Choose up to 6 instruments to place in the pit, then press PLAY. If you choose the flute, drums, xylophone, piano, cymbals and violin to play Alouette, that's exactly what you'll get. Switch the piano for the trumpet and the same song will sound totally different. Try playing Twinkle Twinkle with xylophone and piano for a relaxing lullaby, or if you prefer to go marching around the house, use the trumpet, drums and flute instead. There are 7 instruments and 15 songs—tons of musical combinations!

2. ON/OFF SWITCH

Press to turn on or off. If you don't keep playing after a song is over, the symphony goes to "auto-off" sleep mode — to save the artistic mind that's too wrapped up in the music (and save the batteries, too).



3. VOLUME CONTROL

Play fortissimo or pianissimo—the volume is up to you.

4. PLAY SONG CONTROL

Press to play the next song. And the next. And the next. Toggle from song to song. See included Lyric Playbill for song order.

5. STOP SONG CONTROL

Stop the current song and queue the next. You're the boss.

6. REPLAY BUTTON

Press replay and play it over and over again, little Beethoven.

7. DEMO


Plays a loop of songs illustrating the beautiful music you can make with Symphony No. 2.

8. EARPHONE JACK

Hit the earphones, Jack! Moms need a little peace and quiet now and then.

8.125" x 5.75"

- Print in PMS4695 U ■ (SOY-BASED INKS)
- Print MONOTONE High Resolution picture as PMS4695 U
- Print on 128 g 100% Recycled Woodfree Paper
- Don't print dieline & PMS7500 U



B.
Symphony No. 2™
3 YEARS TO INFINITY

REPLACING BATTERIES

Shouldn't happen too often thanks to "auto-off", but with a passionate conductor it's bound to happen eventually.

6 AA (1.5V) BATTERIES INCLUDED

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Dead batteries? Check out earth911.com to quickly find the recycling center nearest you.

Hear the magical music of the mystical worlds of B.

at mybtoys.com. If you have questions or comments or suddenly need the name of a good violin teacher, call us (toll free).
1-866-665-5524

Speaker Selection
For normal playing, slide to "Speaker & AUX."
If the earphone jack becomes damaged, simply slide to "Speaker Only."

© 2014 Maison Joseph Battat Ltd.
B. and Symphony No. 2 and Just B. Just You. B. You are trademarks of Maison Joseph Battat Ltd.

Manufactured for
Maison Joseph Battat Ltd.
8440 Darnley Road,
Montreal, P.Q. H4T 1M4
Designed by
Maison Joseph Battat Ltd.
Consumer Information Line:
1-866-665-5524

100% RECYCLED
WOOD-FREE PAPER
PRINTED WITH
SOY-BASED INKS

8.125" x 5.75"

- Print in PMS440 U (SOY-BASED INKS)
- Print on 128 g 100% Recycled Woodfree Paper
- Don't print dieline

