

Introduction

Congratulations, and thank you for choosing the Sport Wireless Stereo Earphone. This manual will help you operate the Sport Wireless Stereo Earphone, but you should first familiarize yourself with the Wireless functionality of your mobile phone or other devices before using the Sport Wireless Stereo Earphone Safety Rules.

1.Please follow the rules depicted in this manual closely to ensure your safety.Before using this Sport Wireless Stereo Earphone, We would strongly encourage you to read through this user manual.

Be more wary of any edges, uneven surfaces, metal parts; accessories and its packaging so as to prevent any possible injuy or damage.

3. Do not modify, repair or dismantle this Wireless Stereo Earphone. Doing so may result in fires, electric shocks, complete breakdown of this Sport Wireless Stereo Earphone, etc. All of which, are not covered under warranty.

 Do not use any diluents or volatile liquid to clean the Sport Wireless Stereo Earphone.

5. Do not use the Sport Wireless Stereo Earphone in a hazardous location.

Accessories List

1xWireless Earphone 1xUser Manual 1xUSB charger Cable 1xEva Case

General Functions

Power On: Press the "

(blue LED slowly flashes and a "power on " voice beep).

Play/pause: Press " (> " to play when the device is pausing and press

" / I to pause when the device is playing.

Volume up: Press " + " is for volume up.

Volume down: Press " - " is for volume down.

Playback/Previous: long Press " - " is for previous music, long press

"+" is for the next music.

Power off: Press the " button for 3 seconds when the device is off (a " power off " voice beep and all LED is off).

Low battery warning: (a "battery low" voice beep and the red LED flash) Charging: Charging via USB charging cable connected to a computer USB port (red LED is on).

Answer call: Press the " / button once while the call is coming.

End call: Press the " [] | " button once to end call.

Transfer call voice: Press the "

Reject call: Press the " "button for 2 second to reject call when the call is ringing.

Connect two mobiles simultaneously: Firstly, find the earphone name on the first mobile phone, then press the name for pairing and connecting. Secondly, close the Bluetooth device of the first mobile phone, and find the earphone name on the second mobile phone then connect it. Finally, Open the Bluetooth device of the first mobile phone and connect it, at that time your earphone is connecting with two mobile phone. Connecting successfully: When there is a call from the first mobile phone,

Transfer calls between two mobile phones: Double press the "

Replay the phone: In stand-by mode or playing music, double press the "

Mute: When talking, double press the "

Charging your device

- 1. Connect the charger to the charging socket on the headset.
- 2. during charging, the indicator light will turn red.
- When the headset is fully charged, the red indicator light changes to blue Unplug the charger from the headset.

Technical specification

Wireless Specification: 3.0 Wireless Profile: HFP 1.6, HSP1.2, AVRCP 1.4, A2DP 1.2 RF Range: 10m Noise reduction: CVC6.0 Stand-by time: about 175 hours Calculating Conversation Time: about 7 hours Charging time: About 2 hours

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Shenzhen Kingstar Industrial Co.,Ltd. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.