



朗琴



T600 Manual

LED Themes

Short press the ***** button to switch the LED Themes, there are five different LED themes



Micro SD Card Music Playing

Inserting the Micro SD Card into the speaker to enter the memory card mode, the speaker will play the Micro SD card music directly. (Speaker will voice "memory card mode"). The speaker support music format at WAV,MP3,WMA,APE,FLAC .

AUX in

Use the 3.5mm audio cable included to connect the speaker to an audio source (MP3/MP4, mobile phone). Short press the M button to enter "AUX IN" mode (the speaker will voice "Aux in" mode). The speaker will play the music from the audio source. Please note: Low battery will affect the music

Dear customer,

Thank you for purchasing the LED Light Bluetooth speaker T600. To ensure correct operation, please read this user manual carefully before operation.

Features

1.Five Multi-colored LED Themes

Full spectrum light themes matching with your music

2.Bluetooth Music play,4.0 version

Bluetooth 4.0 stereo music playing

3.NFC(Near Field communication)

One touch easy pairing with your NFC Smartphone

4.Mobile Hands-free Function

support mobile hands-free communication

5.Micro SD Card Music Playing

Support the entire MP3/WMA/WAV/APE/FLAC coding rate

6.USB Sound card


USB Sound Card and charging functions can be achieved via the same USB cable

Package Contents

Speaker, USB Cable, 3.5mm Audio Cable, User Manual, Hook

SLOT AND KEYS

KEYS



1. **▶▶**

Short press: Pause/Play/Mute/Hang off/Answer the Call
Double click: Dial Back the last call

2. **◀◀/▶▶**

Short Press: previous/Next song
Long Press: Volume decrease/increase

3. *****

Short Press to Switch The LED Themes


4. **M**

Short Press to change different mode

5. *** + ◀◀** : Reduce the lighteness

6. *** + ▶▶** : increase the lighteness

Slot



1. AUX in slot : insert 3.5mm audio cable , Press **M** button to "Aux in mode" work as the external speaker of audio source of PSP/MP4 Etc.

2. Power/Working status indictor: blue color—normal working, Charging—Orange, lower Power—Twinkle (orange)

3. Micro SD (TF) Slot: insert the Micro SD card to play the music.

4. ON/OFF:Power on/off

Instructions

Power on/off

Switch the button to power on/off the speaker


Bluetooth

1. Bluetooth Paired: Press the **M** button to enter the Bluetooth mode, now please turn on the Bluetooth function of your mobile/other devices. And start to search for Bluetooth devices,

the "T600" will be found, please connect it. (The speaker will voice "Device paired" when connect).

2. NFC function: NFC Function (It requires the mobile has the NFC function and the speaker need under Bluetooth mode)

Turn on the mobile's NFC function and make the mobile touch the speaker's NFC area. The mobile will remind you to pair with the Bluetooth device. Choose yes to complete the pairing.



3. Bluetooth/NFC Music Play: Please turn on the mobile or other devices' music player, and speaker will play the selected music.

4. Mobile Hands-free communication:

① Answer the call
Short press the **▶▶** button to answer the call.

② Hang off
Press the **▶▶** button again to hang off the call

③ Dial Back the call
Double click the **▶▶** button to dial the last call back

Important safety instructions

• This product is designed to protect against splashing water sprayed at all angles. Dropping the whole unit in body of water may damage the product.

• Keep speaker away from any source of heat.

• Adjust the volume to a suitable level so as to avoid damaging your hearing, or the unit itself.

• If does not use this speaker for long time, please charge at lease once within three month, in order to prevent the lithium battery from causing and damaging because of excessive consumption.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.