

# RIVERSONG

## USER MANUAL



### WIRELESS EARBUDS

TWS Earbuds  
Before using this product, please read these instructions carefully and keep them.  
FCC ID:2ADR3EA173



[www.riversongtech.com](http://www.riversongtech.com)

### RIVERSONG TECHNOLOGY CO., LTD.

Address: No. 1108 Tower B, Tian'an High-Tech Plaza Phase 1, Futian District, Shenzhen, Guangdong  
Official website: [www.riversongtech.com](http://www.riversongtech.com)

### WELCOME

Thank you for choosing RIVERSONG Product. Our wireless earphones come with light weight and fashionable design, along with on-the-go controls for your music and calling experience.

### WIRELESS TECHNOLOGY

With the latest BT 5.3 wireless technology, you can enjoy hassle free music without any interruption and you don't have to face wire tangling issues.

Wireless connection allows you to enjoy your music experience or calls without holding your mobile phone but the maximum distance between them shall be within 10 meters (about 30 feet). The wireless connection may be interfered by obstacles (such as walls) or other electronic devices.

### WIRELESS EARBUDS

Before using this product, please read these instructions carefully and keep them.  
FCC ID:2ADR3EA173

### FAQ

Why can't I find the earphones model on my phone?

It might be because the earphones are power off; or the wireless connection function of your mobile phone encounters some issues.

1. Press on "MF" button: when battery case fully charged, indicator light turns green.

2. Take out earbuds from the charging case, fast tap "MF" button for 6 times to reset. You will hear a "Di" sound when it reset succeed.

Insert the earbuds into the charging case and close it, Then, open the charging case again to enter Bluetooth pairing mode.

### NOTE

When the earphones are under pairing status, the wireless connection pairing with your mobile phone should be done within 5 minutes, otherwise your earphones will automatically power off.

Why the earphones cannot be linked with my mobile phone using the wireless connection function?

It might be because the wireless connection function on your device is not turned on; your earphones are connected to another device; or the earphones are still in pairing mode.

1. Please check if the wireless connection function on your device is turned on.

### CONNECT YOUR DEVICE

- Please keep your earbuds near your phone within 1m.
- Open the charging box and the headset will automatically turn on, you can hear "Poweron", in 2 seconds. It is search-pairing mode.
- Turn on your mobile Bluetooth function, and search Bluetooth name "RS Air X26", click Bluetooth name "RS Air X26" to connect.
- Upon successful pairing, you'll hear a "connected" sound from the earbuds and the light will turn off.

### OPERATING GUIDE


In below instruction, Touch button refers to the multi-function button (please refer to FUNCTION KEY DESCRIPTION)

Open the charging box, the headset will automatically turn on, put it in the charging box and close the charging box cover to shut down.

- Play/Pause: Tap on once on the MFB (L/R) or putting on
- Last song: Short press three times on multi-function button (L/R)
- Next song: Short press twice on multi-function button (L/R)
- Answer phone call: Short press once on the MFB button
- End phone call: Short press once on the MFB button
- Reject phone call: Long press on the MFB button for 3 seconds
- AI voice assistant: Long press on the MFB button for 3 seconds

### FUNCTION KEY DESCRIPTION

1. Multi-function Button
2. Microphone
3. Indicator Light
4. Type-C Charging Port



### CHARGING THE EARPHONES

1. Use the Type-C charging port to charge your Box.
2. It should take 2 hours to get fully charged.
3. It performs best after being fully charged. Please use DC-5V power to charge it.

Cautions: Please note that the maximum voltage cannot exceed DC-5V.

### THE EARPHONES LED INDICATOR GUIDE

Low power: a vocal message reminds "Battery low" and the blue light is flashing.  
Charging: the blue light is on.  
Fully charged: the light turns off.

### THE CHARGING BOX DISPLAY GUIDE

Low power: green light is flashing.  
Charging: The orange indicator blinks.  
If the orange indicators are steady on, the battery is fully charged.

### RECONNECTION

1. The earphones will reconnect with your mobile phone automatically.
2. If it doesn't, please find previous paired Bluetooth name to click, it will be connected.

### FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

### SPECIFICATION

Product Name: WIRELESS EARBUDS  
Model: EA173  
Bluetooth version: V5.3  
Connection distance: 10m  
Frequency response: 20Hz-20kHz  
Speaker size: Ø13mm  
Impedance: 32Ω±15%  
Input voltage: 5V±300mA  
Earbuds battery: 30mAh  
Charging battery: 300mAh  
Playback time: ~5h (volume at 70%)  
Charging port: Type-C  
Net weight: ~36g  
Gross weight: ~125g

**NOTE**  
Overcharging or placing the earphones under high temperature atmosphere will cut down the battery capacity and lifetime.

Why the earphones call quality is not good?

It might be because the mobile network is not good enough; or the earphones are not in the wireless connection working range.

1. Confirm whether the mobile network is strong enough.
2. Please confirm that the earphones are within the effective working distance of 10 meters from your mobile phone, also check if no major obstacle is causing interference to connection.

When the music is playing, why the music cannot be controlled with the play/pause, previous/next song and volume up/down buttons?

It might be because the mobile phone doesn't support the AVRCP (Audio/Video Remote Control Profile) protocol.

This feature requires the mobile device to be paired with the earphones to support the AVRCP (Audio/Video Remote Control Profile) protocol.