





# Brydge 12.3 Pro+ User Manual

Mode d'emploi




## INSERT/REMOVE

**TO INSERT:** Place your Brydge on a flat surface and set the hinges upright to 90 degrees. Insert your Surface Pro into the hinges, one side at a time, with the Wake and Volume Buttons on top.



**TO REMOVE:** Ensure your Brydge is on a flat surface.

Place your hand towards the back of the keyboard and pull up on your Surface Pro, one side at a time.




## POWER



To manually power on, press and hold Fn + Delete keys. The light will turn green for 2 seconds to indicate power.



To manually power off, press and hold Fn + Delete keys for 2 seconds. The light will blink red momentarily to indicate it's powered off.



## PAIR

1. Turn on your Brydge 12.3 Pro+ (Fn+Del), then press and hold the Bluetooth key for three seconds. The Delete key light will flash blue confirming your Brydge is in pairing mode.
2. On your Surface Pro, select:
  - Start 
  - Settings 
  - Devices
  - Bluetooth & other devices
  - Add Bluetooth or other device
  - Bluetooth
  - Brydge 12.3 Pro+
3. Type in the PIN on your Brydge 12.3 Pro+ and hit Enter.



**NOTE:** If pairing takes longer than three minutes, the blue light will stop flashing and you will need to press the Bluetooth button again.


## CHARGE

**TO CHECK BATTERY LIFE:** go to Windows > Settings > Devices > Bluetooth & other devices, and check the battery level on 'Brydge 12.3 Pro+'.

**NOTE:** If battery life is below 15%, the backlit key functionality will be disabled to conserve remaining battery life and the light on the Delete key will blink red.

**TO CHARGE:** Insert the charging cable into the keyboard and plug the other end into a power source. A solid red LED on the delete key indicates the Brydge is charging.

When the keyboard is fully charged, the red LED will turn off. A full charge can take up to three hours.




## SLEEP/WAKE

To conserve battery, your Brydge will enter sleep mode after 15 minutes of non-use. Press any key to wake it.

When you close your devices together, your Brydge will put your Surface Pro into sleep mode. When you open your devices, your Brydge will wake your Surface Pro.

**NOTE:** Your Brydge will not put your Surface Pro to sleep or wake it after 15 minutes of non-use.

## PRECISION TOUCHPAD

The Brydge 12.3 Pro+ touchpad pairs with your Windows device as a Precision Touchpad, and therefore utilizes all of the Windows touchpad gesture capabilities. To adjust the settings and gestures of your touchpad, select Start  > Settings > Devices > Touchpad. The Touchpad can be turned on and off by pressing Fn + Alt.

**Left Click** | Click on left side of touchpad or 1 finger tap  
**Right Click** | Click on right side of touchpad or 2 finger tap



**Zoom In**  
2 finger stretch



**Zoom Out**  
2 finger pinch




**Scroll**  
2 finger swipe (up, down, left, right)



**Task View**  
3 finger swipe (left or right)



**See Open Windows**  
3 finger swipe up



**Show Desktop**  
3 finger swipe down



**Open Cortana**  
3 finger tap



**Switch Virtual Desktop**  
4 finger swipe (left or right)



**Open Action Center**  
4 finger tap

## KEYBOARD SHORTCUTS

### Touchpad Disable/Enable

Fn + Alt (Hold Fn & tap Alt to disable. Hold Fn & tap Alt again to enable.)

### Language Switch

Win + Spacebar (Use spacebar to toggle through available languages.)

#### Help

Fn + F1

#### Copy

Ctrl + C

#### Cut

Ctrl + X

#### Paste

Ctrl + V

#### Underline

Ctrl + U

#### Italic

Ctrl + I

#### Undo

Ctrl + Z

#### Task View

Alt + Tab

#### Page Up

Fn + Up Arrow

#### Page Down

Fn + Down Arrow

#### Home

Fn + Left Arrow

#### End

Fn + Right Arrow

## WARRANTY

Thank you for purchasing a Brydge product. This product comes with a 1-year limited hardware warranty on the terms and conditions set out in this document and at [www.brydge.com/warranty](http://www.brydge.com/warranty). All Brydge warranties are non-transferrable and are only available to the original end-user of the product. Warranties do not apply to products purchased from online vendors unauthorized to sell Brydge-branded product. If a defect arises during the warranty period, cease using the product and contact Brydge. To obtain warranty service, visit [www.brydge.com/support](http://www.brydge.com/support) or call +1 (435) 604-0481. Brydge, at its sole discretion and option, will (1) repair the product at no charge using new parts or parts that are equivalent to new in performance and reliability, or (2) replace or exchange the product with a product of equivalent functionality and value. Brydge offers free return shipping on any approved warranty claims. A shipping label will be provided to you if you are within the United States. If you are outside the United States, Brydge will reimburse your return shipping to a maximum of US\$15.00 after providing a copy of the shipping receipt.


Australia Only: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Brydge Technologies LLC | 1912 Sidewinder Dr., Suite 104, Park City, UT 84060 USA

HAVE A QUESTION? Visit [www.brydge.com/support](http://www.brydge.com/support)


## INSÉRER / RETIRER

**INSÉRER :** Placez votre Brydge sur une surface plane et réglez les charnières à 90 degrés. Insérez votre Surface Pro dans les charnières, un côté à la fois, avec les boutons de Réveil et de Volume positionnés sur le dessus.




**RETIRER :** Assurez-vous que votre Brydge est sur une surface plane.

Placez votre main vers l'arrière du clavier et tirez sur votre Surface Pro, un côté à la fois.




## MISE EN MARCHÉ

Pour allumer manuellement, maintenez enfoncées les touches Fn + Supprimer. Le voyant deviendra vert pendant 2 secondes pour indiquer la mise en marche.



Pour éteindre manuellement, maintenez enfoncées les touches Fn + Supprimer pendant 2 secondes. Le voyant clignotera momentanément en rouge pour indiquer la mise hors tension.



## APPAIRER

1. Allumez votre Brydge 12.3 Pro+ (Fn + Supprimer), puis appuyez et maintenez enfoncée la touche Bluetooth pendant trois secondes. Le voyant de la touche Supprimer clignotera en bleu confirmant que votre Brydge est en mode d'appairage.
2. Sur votre Surface Pro, sélectionnez :
  - Démarrer
  - Paramètres
  - Appareils
  - Bluetooth et autres appareils
  - Ajouter Bluetooth ou un autre appareil
  - Bluetooth
  - Brydge 12.3 Pro+
3. Tapez le code PIN sur votre Brydge 12.3 Pro+ et appuyez sur Entrée.



**REMARQUE :** Si l'appairage dure plus de trois minutes, le voyant bleu cessera de clignoter et vous devrez appuyer à nouveau sur le bouton Bluetooth.


## CHARGE

**POUR VÉRIFIER LA DURÉE DE VIE DE LA BATTERIE :** accédez à Windows > Paramètres > Appareils > Bluetooth et autres appareils, et vérifiez le niveau de la batterie sur « Brydge 12.3 Pro+ ».

**REMARQUE :** Si la durée de vie de la batterie est inférieure à 15%, la fonctionnalité de rétro-éclairage des touches sera désactivée afin de conserver la durée de vie restante de la batterie et le voyant de la touche Supprimer clignotera en rouge.

**CHARGER :** Insérez le câble de charge dans le clavier et branchez l'autre extrémité dans une source d'alimentation. Une DEL rouge fixe sur la touche de suppression indique que le Brydge est en charge.

Lorsque le clavier est complètement chargé, la DEL rouge s'éteindra. Une charge complète peut prendre jusqu'à trois heures.



## VEILLE / RÉVEIL

Pour économiser la batterie, votre Brydge passera en mode veille après 15 minutes de non-utilisation. Appuyez sur n'importe quelle touche pour le réactiver.

Lorsque vous fermez vos appareils, votre Brydge met votre Surface Pro en mode veille. Lorsque vous ouvrez vos appareils, votre Brydge réveille votre Surface Pro.

**REMARQUE :** Votre Brydge ne mettra pas votre Surface Pro en veille ou ne la réveillera pas après 15 minutes de non-utilisation.

## PAVÉ TACTILE DE PRÉCISION

Le pavé tactile Brydge 12.3 Pro+ s'apparie à votre appareil Windows en tant que pavé tactile de précision, et utilise donc toutes les fonctionnalités gestuelles du pavé tactile Windows. Pour régler les paramètres et les gestuelles de votre pavé tactile, sélectionnez Démarrer > Paramètres > Appareils > Pavé tactile. Le pavé tactile peut être activé et désactivé en appuyant sur Fn + Alt.

**Clic gauche** | Cliquez sur le côté gauche du pavé tactile ou tapez avec 1 doigt

**Clic droit** | Cliquez sur le côté droit du pavé tactile ou tapez avec 2 doigts



**Zoom avant**  
Étirement à 2 doigts



**Zoom arrière**  
Pincement à 2 doigts




**Faire défiler**  
Balayage à 2 doigts  
(haut, bas, gauche, droite)



**Afficher les tâches**  
Balayage à 3 doigts  
(gauche ou droite)



**Voir les fenêtres ouvertes**  
Balayage à 3 doigts vers le haut



**Afficher le bureau**  
Balayage à 3 doigts vers le bas



**Ouvrir Cortana**  
Taper avec 3 doigts



**Changer de bureau virtuel**  
Balayage à 4 doigts  
(gauche ou droite)



**Ouvrir le centre d'action**  
Taper avec 4 doigts

## RACCOURCIS CLAVIER

### Désactiver / Activer le pavé tactile

Fn + Alt (maintenez Fn et appuyez sur Alt pour désactiver. Maintenez Fn et appuyez à nouveau sur Alt pour activer.)

### Changer de langue

Win + barre d'espace (utilisez la barre d'espace pour basculer entre les langues disponibles.)

#### Aide

Fn + F1

#### Copier

Ctrl + C

#### Couper

Ctrl + X

#### Coller

Ctrl + V

#### Souligner

Ctrl + U

#### Italique

Ctrl + I

#### Annuler

Ctrl + Z

#### Afficher les tâches

Alt + Tab

#### Haut de page

Fn + Flèche vers le haut

#### Bas de page

Fn + Flèche vers le bas

#### Accueil

Fn + Flèche gauche

#### Fin

Fn + Flèche droite

## GARANTIE

Nous vous remercions d'avoir acheté un produit Brydge. Ce produit est accompagné d'une garantie matérielle limitée d'un an aux conditions prévues dans ce document et sur [www.brydge.com/warranty](http://www.brydge.com/warranty). Toute garantie Brydge ne peut être transférée et est applicable seulement à l'utilisateur initial du produit. Les garanties ne s'appliquent pas aux produits achetés auprès de vendeurs en ligne non-autorisés à vendre des produits de la marque Brydge. Pour bénéficier d'un service sous garantie, visitez le site [www.brydge.com/support](http://www.brydge.com/support). Une preuve d'achat peut être exigée pour vérifier l'éligibilité.

VOUS AVEZ DES QUESTIONS ? Visitez [www.brydge.com/support](http://www.brydge.com/support)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2020 Brydge. All Rights Reserved.

© 2020 Microsoft. Microsoft, the Microsoft logo, Microsoft Surface, Surface, and the Microsoft Surface logo are trademarks of the Microsoft group of companies. All other trademarks are the property of their respective owners.

The Bluetooth word mark, and logos are owned by Bluetooth SIG, Inc. Use of such marks by Brydge is under license. Brydge is a trademark of Brydge Global Pte. Ltd. Other trademarks and tradenames are those of their respective owners.

---

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L' appareil ne doit pas produire de brouillage;

(2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

REMARQUE : Cet équipement a été testé et déclaré conforme aux limites d'un appareil numérique de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, peut provoquer des interférences nuisibles aux communications radio. Cependant, il n'y a aucune garantie qu'aucune interférence ne se produira dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception radio ou télévision, ce qui peut être déterminé en éteignant puis en rallumant l'équipement, l'utilisateur est encouragé à essayer de corriger les interférences par une ou plusieurs des mesures suivantes :

- Réorientez ou déplacez l'antenne de réception.
- Augmentez la distance entre l'équipement et le récepteur.
- Connectez l'équipement à une prise sur un circuit différent de celui auquel le récepteur est connecté.
- Consultez le revendeur ou un technicien radio/TV expérimenté pour obtenir de l'aide

Les changements ou modifications non expressément approuvés par la partie responsable de la conformité peuvent annuler le droit de l'utilisateur à utiliser l'équipement.

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes :

(1) Cet appareil ne doit pas provoquer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.

© 2020 Brydge. Tous les droits sont réservés.

© 2020 Microsoft. Microsoft, le logo Microsoft, Microsoft Surface, Surface et le logo Microsoft Surface sont des marques commerciales du groupe de sociétés Microsoft. Toutes les autres marques sont la propriété de leurs propriétaires respectifs.

Le nom de marque et les logos Bluetooth sont la propriété de Bluetooth SIG et toute utilisation de marqueurs par Brydge est subordonnée à une licence. Brydge est une marque commerciale de Brydge Global Pte. Les autres marques et noms commerciaux sont ceux de leurs propriétaires respectifs.