Below 1G--The EUT is placed on the center of turntable

Above 1G--The EUT is placed on the center of turntable