

封面封底

70\*75mm,80g书纸, 骑马钉

cannice

Thrilling Emotion and Sound.

M812

CANNICE IMPULSE INSTRUCTION

[www.cannice.com](http://www.cannice.com)

## PRODUCTS OVERVIEW

1. Volume + / Track forward
2. Charge jack
3. Status indicator
4. Multifunction button
5. Volume - / Track back



## BASIC OPERATION

	Status indicator	
Instruction	LED Status	Voice prompts
Power on	Stay blue about one second	Power on
Power off	Stay red about two second	Power off
Standby	Blink blue once every 5 seconds	/
Pairing	Flashes red and blue alternately	/
Incoming call	Flashes blue quickly	/
Battery low	Blink red	Battery low
Charging	Stays on red while charging Stays on blue after fully charged	/

### Volume up/down

Press the volume "+" to turn volume up  
Press the volume "-" to turn volume down

### Power on

Press and hold Multifunction button for about 3 seconds. The earphone says "power on" and the LED Stay blue about one second.

### Power off

Press and hold Multifunction button for about 5 seconds. The earphone says "power off" and the LED Stay red about one second.

Enable voice prompts: enter pairing mode, Press the volume "+" button for 3 seconds, the blue LED lights flash 3 times.

Disable voice prompts: enter pairing mode, Press the volume "-" button for 3 seconds, the red LED lights flash 3 times.

## BASIC OPERATION

### Clear paired list

1. When the earphone is connected to the phone, then disconnected the phone, at the same time the earphone will enter into pairing mode.
2. Press volume "+" and volume "-" button at the same time until LED flashes blue, then LED flashes red and blue alternately, the paired list was cleared, the earphone will enter pairing mode after power on next time.

### Hard reset

If the earphone cannot be turned on even when fully charged or does not respond during use, follow the instructions below to reset it.

1. While holding the multifunction button, connect the earphone to your PC's USB port or USB power adapter with the charging cable.
2. Keep pressing and holding the Multifunction button until the earphone turns on until the earphone turns on. Then the earphone is reset.

## PAIRING

### Pair one phone

Note: When the earphone and phone have been paired once, they will automatically connect next time when the earphone is on and Bluetooth is activated on the phone.

1. After power on, if has PDL, it will reconnect, if fail, earphones automatically enter pairing mode (the LED indicator flashes red and blue alternately).
2. Activate Bluetooth on your phone (See below for more details).

#### iPhone

- a. On your phone, open the Settings menu.
- b. Select Bluetooth. If Bluetooth is off, turn it on. The iPhone will search for new devices automatically.


#### Android phone

- a. On your phone, open the Settings menu.
- b. Select Bluetooth (For old Android phone, Bluetooth is found in the Wireless & Networks). If Bluetooth is off, turn it on. Select Search for Devices if your phone does not automatically search for new devices.

• PAIRING

### Windows Phone 8

- On your phone, open the Settings menu.
- Select Bluetooth. If Bluetooth is off, turn it on.  
The Phone will search for new devices automatically



PAIRING •

- Select "JPRiDE 708". If your phone asks, enter 0000 (four zeros) for the Pass code or accept the connection. The LED indicator stops flashing red and blue once successfully paired, you hear "Connection successful". Some phone list an option to "Play through earphone", select to use the earphones.



## PAIRING

### Pair another phone


Multipoint technology enables you to pair another phone and take a call from either.

To pair first smart phone , power off the headset , then power on and pair the second phone and power off it and restart the headset. It will reconnect to second paired phone automatically for the first pairing. you shall manually operate from the 1st smart phone's bluetooth paired list menu and select and click the "JPRIDE 708"

Calling switch When the first phone call rings, press the Multifunction button once to answer the call, if the seconds call rings at this moment, you can answer the second phone by double click Multifunction button, and on hold the first phone call.



## FOLLOWING ITEMS ARE INCLUDED



USB Cable




Ear Tips

## • CHARGING

Your new earphone has enough power to pair and make a few calls. It takes 2 hours to fully charge the earphone; while charging, the battery indicator light is red, the indicator light flashes blue once charging is complete.

Note: The lifetime of the battery will be significantly reduced if your earphone is left uncharged for a long period. We recommend that you recharge your earphone at least once a month.



## • CALL

### Answer a call

Press the Multifunction button or Volume "+" or Volume "-" once.

### Reject a call

Press and hold the Multifunction button for about 2 seconds.

### End a call

Press the Multifunction button once.

### End current call and answer new call

When a new call comes in during your current call, press the Multifunction button once to answer new call and end current call simultaneously.

### On hold current call and answer new call

When a new call comes in during your current call, Double press the Multifunction button to hold your current call and answer new call.

## CALL

### **Reject the new call hold the current call**

During the call there is a new call, press and hold the multifunction button for about 2 seconds to reject a new call, keeping the active call.

### **Mute on/off**

Press the Volume "-" for about 2 seconds to mute on/off.

### **Switch between the earphone and phone**

Press the multifunction button for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone.

### **Voice dial (Need phone support)**

In standby mode double press the multifunction button wait for phone prompt and then tell the phone to dial the name of a stored contact.

## MUSIC

(Need media player support)

### **Music Play/Pause**

Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first).

### **Track back/forward**

Press the Volume "-" for 2 seconds once to skip track backward, press Volume "+" for 2 seconds once to skip track forward.

### **Switch Music and Call**

When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.

## SAFETY AND CARE

Using earphone at high to moderate volumes for extended periods of time may result in permanent hearing damage. It is advised you keep volume levels moderate to low at all times for your safety.

Do not use while driving a car, cycling, operating machinery, or performing other activities that require hearing surrounding sounds.

Do not use earphone in thunderstorm weather, the earphone may not work properly in the condition, and increase the risk of being hit by lightning .

Earphone may not work properly under high temperature or high humidity conditions.

Do not use any corrosive cleaner/oil to clean the earphone.

If the earphone comes in contact with liquids, quickly wipe away .If submersed in water, do not turn the earphone on until completely dried.

Tips: liquid submersion voids the warranty.

Keep the earphone and packaging out of reach of children .

## FREQUENTLY ASKED

- Pair first device by regular procedure, then switch off headset.
- Turn headset back on and enter its pairing process (enable bluetooth function on second device), and pair the second device as usual.
- Switch off headset one more time, and simply switch it back on without entering pairing process this time.
- Headset will automatically re-connect to last connected device, so for now, hand select to connect headset on first device then both of your devices should be paired to headset.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.