



Switch between the earphone and phone

Press the Volume "+" for about 2 seconds during a call, the call will be switched to the mobile phone, redo this operation again, the call will be switched to the earphone.

End current call and answer new call

When a new call rings during a call, press the Multifunction button once to answer new call and end current call simultaneously.

On hold current call and answer new call

When a new call rings during a call, hold the Multifunction button for 2 seconds to hold current call and answer new call. To switch between held call and active call, Hold the multifunction button for 2 seconds.

Music -

Track back/forward

Switch Music and Call

Press the Volume "+" for 2 seconds once to skip track forward, press Volume "-" for 2 seconds once to skip track backward.

When a call rings during a music playing, the music automatically pauses to allow you to answer or ignore the call. Once the call is ignored or ends, the music is resumed.

Music play / pause

Press Multifunction button once to play / pause music. (Some phones may require you to start a media player first)

When the earphone is connected to a device with iOS system, a battery indicator will appear at the upper right of the system, indicating battery status of the earphone.



More features -

Battery Indicator

Auto power-off

When the distance between the earphone and the mobile phone is beyond effective range, a voice prompt 'Connection lost' and earphone disconnects with the mobile phone, the earphone will power off automatically once no active for 10 minutes.



When the earphone and phone have been paired once, they will automatically connect when the earphone is on and Bluetooth is activated on the phone.

Automatic connection after powering on

Connection standby

After successful pairing and connection, you will hear the voice prompt "Connection successful". the earphone will be in turning on mode or standby mode automatically and the blue LED will flash once every 5 seconds, when the earphone disconnect the phone, you will hear the voice prompt "Connection lost".

Charging

Your earphone has enough power to complete the pairing and a few calls. When battery is low, you will hear the voice prompt "Battery low". It takes 1.5 hours to fully charge the earphone. The red LED turns on during charging. The red LED will turn off and the blue LED will turn on after being fully charged.

lote: The lifetime of the battery will be significantly reduced our earphone is left uncharged for a long period. We recomm

Hard reset

In turning on mode, press and hold the Multifunction button with the charger plugged to reset the earphone and power off(you can release the Multifunction button 2 seconds after mounting the charger).

cannice

Bluetooth Headset

FCC ID:2ADTV-MS05
Muses 5B Instruction

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.