


144mm

<p>* Skip Forward Track: Press one time on the “Increase Volume/ Skip-Forward” button.</p> <p>* Skip Backward Track: Press one time on the “Increase Volume/ Skip-Forward” button.</p> <p>* Pause: Press the “Play/ Pause” button one time to pause the music. Press again one time to resume the music.</p> <p>* Answer Call: Press “Play/ Pause” button one time to answer the call when you get the incoming call.</p> <p>* End Call: Press “Play/ Pause” button one time to end the call once you desire to end the call. If you were listening to music prior to receiving the call, then the music would resume once you end the call.</p>	<div><div>53202BT</div><div>Bluetooth Speaker</div></div> <div><div>INSTRUCTION MANUAL</div><div></div></div> <div>Please read all instructions carefully & retain for future use.</div>
--	---

The back cover

The Cover

<p>Getting Started</p> <p>Remove product from the packaging. Retain packaging for storage purposes or future reference or dispose of safely.</p> <p>In the Box</p> <ul style="list-style-type: none">* Rechargeable Bluetooth Speaker with Mic* USB cable (For Charging Purpose)* with carabiner hook* Instruction manual <p>Features</p> <ul style="list-style-type: none">* Compatible with Bluetooth devices.* Use in a variety of electronic devices, indoors or outdoors.* Use as Hands-Free speaker phone device, with a built-in microphone.* Deep rich sound in a portable compact size that goes anywhere.* USB rechargeable built-in battery. <p>Instructions for Use</p> <p>Charging the internal battery –</p> <p>Fully charge the unit before use. Connect the USB cord to the port on the top of the speaker and insert the other end into a port on your computer or other suitable USB outlet. The LED on the top will show that the battery is charging. It will take 3-4 hours to fully charge the Battery.</p> <p>LED indicator –</p> <p>There is an LED light located in the middle of the front speaker.</p> <ul style="list-style-type: none">* LED off – Power off* Flashing BLUE – Power ON* Flashing BLUE – Pairing mode* RED – Low Battery Level* BLUE – Battery almost drained* RED – Battery is recharging <p>Turn the speaker to Bluetooth pairing mode –</p> <ul style="list-style-type: none">* Switch on the main power to the “ON” position from the speaker underside.* Wait 2-3 second until the light on the front starts blinking blue . This indicates that it is in pairing mode. <p>Note: Bluetooth speaker will stay in pairing mode for 1 minute. If you are not fast enough to complete the next step, simply turn “OFF” the speaker and then back to “ON” position, and repeat step 2.</p> <p>Pairing your device with Bluetooth Speaker –</p> <p>Your Bluetooth Boom Speaker can wirelessly stream audio from any Bluetooth enabled device within 10m (33 Feet). Simply follow the below steps.</p>	<ul style="list-style-type: none">* Turn ON LED lights while flash Blue lights.* Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.* It will search for various devices.* The name of our Bluetooth Speaker is “2BOOM-BTO500”, pair it with this device.* Once paired, the LED light will stay on BLUE Color <p>Taking calls on connected to Bluetooth speaker –</p> <ul style="list-style-type: none">* When you receive an incoming call, an alert will sound from the speaker.* If you are listening to music from your phone, the music will automatically pause.* To accept a call: You can accept a call as you usually do, using your phone to control or press the “ Model ” button at the top of speaker. Speak normally, your call will come through the speaker and your voice picked up through the built-in microphone of the speaker.* To end a call: Use your phone to control or press the “ Model ” button at the top of the speaker. <p>Controlling playback when connected via Bluetooth –</p> <ul style="list-style-type: none">* Volume Increase: Using the volume controls on the top of speaker, Long press and hold the “Increase Volume/ Skip Forward ” button to increase volume .* Volume Decrease: Using the volume controls on the top of speaker, Long press and hold the “Increase Volume/ Skip Forward” button to decrease volume. <p>Warning</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none">-- Reorient or relocate the receiving antenna.-- Increase the separation between the equipment and receiver.-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-- Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction</p>
---	--

¹
103mm

²
103mm