

# Cabela's

# MAXX ACTION

HUNTING SERIES

Walkie Talkies

L'Ensemble de la Classe Talkie Walkie



**PUSH TO TALK  
APPUYEZ  
ET PARLEZ**

**ON/OFF  
ALLUMEZ/ARRÊTEZ**

**FLEXIBLE SAFETY  
ANTENNA  
ANTENNE FLEXIBLE  
DE SECURITE**

**DURABLE  
Construction!  
Construction  
Durable**

**BELT CLIP  
BOUCLE DE  
CEINTURE**

**MORSE CODE  
CODE DE MORSE**

**\*PRESS AND HOLD THE TALK BUTTON  
WHILE PRESSING THE MORSE CODE BUTTON.  
\*APPUYEZ ET MAINTENEZ ENFONCÉ LE BOUTON DE  
CONVERSATION TOUT EN APPUYANT SUR  
LE BOUTON DE CODE MORSE**

**Levier de commutateur On/Off**  
Inclinez-le vers le haut pour allumer l'appareil. Inclinez-le vers le bas pour l'éteindre.

**Ne pas mélanger des piles alcalines, piles rechargeables (type NiMH), piles pour piles bouton (type bouton) ou piles rechargeables de type NiMH.**  
Ne pas utiliser des piles rechargeables et des piles bouton ensemble.

**Si vous gérez votre batterie, veuillez consulter le manuel d'instructions pour plus de détails.**

**Battery Warning**

**Improper Use**  
Do not use rechargeable batteries in the device.  
Do not use alkaline batteries in the device.  
Do not use different types of batteries together.

**Remove batteries from the product before extended storage.**  
Batteries can be inserted with correct polarity.  
The supply terminals can be short-circuited.  
Please keep this information for future reference.



**Sunny Days**  
ENTERTAINMENT, LLC

Distributed by  
Sunny Days Entertainment, LLC  
PO BOX 80644 Simpsonville, SC 29680  
Made in CHINA  
[www.sunnydaysemt.com](http://www.sunnydaysemt.com)

SDE Shantou/China F 07-20

ITEM# BP10002

