



Below 30MHz
The EUT is placed at the center of turntable





Up to 1GHz

The EUT is placed at the center of turntable