










<p style="text-align: center;">POWER BANK QUICK START GUIDE OBFTC-0044-A</p>	<p>FULLY CHARGE FOR FIRST USE While charging display continually shows (Fig. 1):</p> <ul style="list-style-type: none"> • 1 flashing LED – < 25% capacity • 1 solid LED, 1 flashing LED – 25-50% capacity • 2 solid LEDs, 1 flashing LED – 50-75% capacity • 3 solid LEDs, 1 flashing LED – 75-99% capacity • 4 solid LEDs – 100% capacity <p>FIG. 1 </p>	<p>WIRELESSLY CHARGE DEVICES (IF APPLICABLE) Press button and place your device flat on the side of the Power bank featuring the OtterBox logo. An orange light blinks while detecting your device and stops blinking if the device is not detected. The orange light blinks when a device is connected and charging.</p> <p>CARE & MAINTENANCE Cleaning 1. Wipe with a dry cloth. 2. Do not use solvents, chemicals, cleaning solutions, alcohol, ammonia or abrasives.</p>
<p>CUSTOMER SERVICE 1-855-688-7269 USA + Canada - Toll Free support@otterbox.com otterbox.com/support</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p>	<p>When not charging, press button to view capacity (Fig. 2):</p> <ul style="list-style-type: none"> • No LEDs – 0% capacity • 1 flashing LED – 0-10% capacity • 1 solid LED – 10-25% capacity • 2 solid LEDs – 25-50% capacity • 3 solid LEDs – 50-75% capacity • 4 solid LEDs – 75-100% capacity <p>FIG. 2 </p> <p>CHARGE DEVICES Power bank automatically starts charging most devices.</p>	<p>COMPLETE USER MANUAL MODE D'EMPLOI COMPLET OTTERBOX.COM/SAFETY-INSTRUCTIONS</p> <p>DE Gesamtes Benutzerhandbuch IT Manuale Utente Completo ES Manual de Usuario Completo PT Manual do Utilizador Completo JA ユーザーマニュアル KO 사용 설명서 ZHT 完整版使用者手册 ZH 完整版用户手册</p> <p style="text-align: right;">20-55265_A</p>

<p style="text-align: center;">CHARGEUR PORTATIF GUIDE DE DÉMARRAGE RAPIDE</p>	<p>changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p>	<p>ISED compliance statement This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :</p>
<p>SERVICE À LA CLIENTÈLE 1-855-688-7269 É.-U. + Canada - Gratuit support@otterbox.com otterbox.com/support</p> <p>Cet appareil est conforme à la section 15 des réglementations de la FCC. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférences nuisibles ; (2) cet appareil doit accepter toute interférence reçue, notamment les interférences susceptibles d'occasionner un fonctionnement indésirable.</p>	<p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. 	<p>(1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.</p> <p>Radiation Exposure statement This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body. Cet équipement est conforme aux limites d'exposition aux radiations FCC/IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.</p>

Project Name: INSERT CARD POWER BANK QUICK START GUIDE		Designer: Rowell	
Part #: 20-55265 Rev: A	Date: 4.28.2020	Dieline and material shall follow: 23-84697	
Colors Coatings and Treatments:	Notes:		
<p> Process Black</p> <p> PMS 109</p>	Accordian Fold		
NOT FOR PRINT – FOR REFERENCE ONLY	<p>Confidential property of Otter Products LLC Reproduction and unauthorized use is prohibited Otterproducts LLC: 209 South Meldrum Street, Fort Collins, CO 80521</p>		
<p> Dielines- do not print</p> <p> Folds- do not print</p>			
 		OTTER PRODUCTS	