Item 1278-6 / N4T--- 204/4328 NIGHT SCOPE BINOCULARS/WALKIE TALKIE

BATTERY INSTALLATION

The product requires 2 x 9V batteries (not included). Please use alkaline batteries for better performance.

- 1. Open the battery compartment door.
- 2. Insert 1 new 9V battery into the battery compartment of each Night Scope Binocular, observing the polarity markings.
- 3. Close the battery cover.
- 4. To use, turn the power switch to "ON" position.

Notes:

- Weak batteries cause erratic product operation. Please replace with new batteries when the sound is getting weak.
- Always turn the power switch to "OFF" position when not in use.

HOW TO OPERATE

- 1. Turn the ON/OFF switch to 'ON' position.
- 2. Press the "PUSH TO TALK" button for transmitting, and speak in a normal voice level into the speaker / microphone grille.
- 3. Release the "PUSH TO TALK" button for receiving.
- 4. Best transmission & reception are obtained when the Flexible Antenna is placed in vertical position.

BATTERY CAUTIONS

IMPORTANT: Only adults should replace batteries

Follow the battery guideline in this section.

Otherwise battery life may be shortened or the batteries may leak or rupture:

- Always keep batteries away from children
- Do not mix old and new batteries or batteries of different types: alkaline, standard or rechargeable
- If rechargeable batteries are used, they are only to be charged under adult supervision
- Only batteries of the same or equivalent type as recommended are to be used
- Insert batteries as indicated inside the battery compartment
- Never short-circuit the battery terminals
- Do not charge non-rechargeable batteries
- Remove rechargeable batteries from the product before charging
- Dispose of batteries safely
- Weak batteries cause erratic product operation.
- Please replace the batteries when any function fails to operate
- Always remove exhausted or dead batteries from the product
- Remove batteries from the product before extended storage

WARNINGS:

FCC ID: 2AEJP-SYN-2018-WKT

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.

We, Synergistic Industrial Ltd, hereby declares that this Night Scope Binocular Walkie Talkie is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.