


# Internal Photos


OPEN VIEW OF EUT-1



OPEN VIEW OF EUT-2



OPEN VIEW OF EUT-3




OPEN VIEW OF EUT-4




VIEW OF BATTERY




INTERNAL VIEW OF EUT-1




INTERNAL VIEW OF EUT-2



INTERNAL VIEW OF EUT-3




INTERNAL VIEW OF EUT-4




INTERNAL VIEW OF EUT-5

Antenna for NRF51822




INTERNAL VIEW OF EUT-6

Antenna for AB1522S



INTERNAL VIEW OF EUT-7(AB1522S)



INTERNAL VIEW OF EUT-8(NRF51822)

