Technical Support

Online: www.jadootv.com/support Email Support: support@jadootv.com

USA: 619-523-6688 UK: +44 (0) 203-603-1563 Germany: +49 69-5780-1985 Hong Kong: +852 58086546

Canada: +1 289-466-1005 Australia: +61 2 8607-8110 New Zealand: +64 99518398

Japan: +81 3457-82035

ТΜ


Quick Setup Guide



www.jadootv.com

www.jadootv.com

Quick Setup Guide



A/V Cable

AC Adapter

Remote Control

- Select the "Join Google+" button and get socialized or select the "Not Now" button (Fig 7g).
- Select the "Arrow" button at bottom right to finish (Fig 7h).
- Enter the text shown on the screen using the soft keyboard to authenticate the account and select the "Arrow" button at bottom right (Fig 7i).
- This step may take a few minutes as Google saves your account information (fig 7j).



(Fig 7g)

(Fig 7h)



Savarg poccent. Voor to on a contracting Google In and differenties in our account. The can table up to 1 months: Cancel Cancel

Jadoo4™

- In this step, Google will check the availability of the username you entered (Fig 7d).
- Enter the "Password" twice using the soft keyboard and select the "Arrow" button at bottom right. The password should consist of at least 8 characters including special characters and numbers (Fig 7e).
- Select the security question, enter its answer and any other email address to retrieve the account information in case you lose your password (Fig 7f).





(Fig 7e)


(Fig 7d)





Step A: Connecting the Audio & Video

(using the HDMI Cable -or- A/V Cable)




Step C: Connecting to the Router

(using the Ethernet Cable or a Wireless Connection)

Option (i): Ethernet Cable Connection

(using the Ethernet Cable - Cable not included in the package)



(Using the WiFi antenna)



Jadoo4 ™

Jadoo4 ™

Configuring New Google Account

- If you want to create a new Google account then go to Setup-> Advance Options-> Accounts -> Google and then select "New" button (Fig 7a)
- Enter your First and Last name by using the soft keyboard and select the "Arrow" button at bottom right (Fig 7b).
- Similarly, enter the username and select the "Arrow" button at bottom right (Fig 7c).





(Fig 7a)

(Fig 7b)

						Signation
<		1	-			Þ
₹.						Þ

(Fig 7c)

Configuring Existing Google Account

- To add your existing Google account, go to Setup-> Advance Options-> Accounts and then select "Google" using the "OK" button on remote. Select the "Existing" button as shown in Figure 6a.
- Enter your Google "Email" & "Password" and select the "Arrow" button at the bottom right (Fig 6b).
- Signing in process can take few minutes. You can cancel it by selecting the "Cancel" button (Fig 6c).
- You can enjoy lots of free apps on App Market



(Fig 6a)

(Fig 6b)





Home Screen


Once your box is powered ON, it will show you the Home Screen as shown below.








Remote Control Guide





45. Next

Note: You may see different label for few keys but the actual function is same as mentioned above.

Similarly enter your Last Name, Email, Password, Confirm Password and Phone Number (Fig c).

O Unit Data O Cont Providen	
	TIPS
Info@abcsdcom	
and the second se	
Register	

- (Fig c)
- Select the "Register" button to go to next step.
- You will receive an email that contains the verification code. You need to enter the verification code by using the keyboard as shown in Figure d.



Registration

You will be required to register your Jadoo4[™] box, the first time you launch any Jadoo4[™] application (Live TV, Movies, VOD) from the home page. The registration form is shown in Figure a.

	O User Data		
		D	
			TIPS
	تو		
	Register.		

(Fig a)

With "First Name" selected, press "Enter" button on the remote control, a soft keyboard will show up on the screen as shown in Figure b. Using the remote, enter your first name and select the "Next" button when done. This will take you to the next field on the registration form.





Air Remote Control (Optional)

Air Mouse Key Funtions:

1 - Infrared Sensor

2 - Power

- 3 Indicator LED
- 4 SET: To activate remote control learning
- 5 Volume Down: Programmable
- 6 Volume Up: Programmable
- 7 TV/AV: Programmable
- 8 Channel Down: Programmable
- 9 Channel Up: Programmable
- 10 Home
- 11 Menu
- 12 Return Key
- 13 Select Key / Enter
- 14 Task Manager
- 15 Previous
- 16 Play/Pause
- 17 Next

Installation

Open the back cover of the air mouse, take out the USB nano receiver. (Fig a)







- Plug Nano receiver into the USB port on the box.
 System will automatically install the driver software. (Fig b)
- Install 2*AAA batteries according to the polarity.
- Put the back cover on, the air mouse is ready to be used.

Wireless USB Nano Receiver

How to use

- Press any key on the remote to turn it on.
- You will see the pointer on TV screen when the air mouse is on.
- Hold the Air Remote in your hand and move it in the desired direction (Up, Down, Left or Right). The mouse
 cursor on the TV screen will move in the same direction.

Infrared remote control learning function:

You can program the V-, V+, CH-, CH+, TV/AV keys on the Air remote to work with your TV. Follow the steps below to set up these keys:


- 1. Press "SET" key for 3 seconds, indicator light will turn on showing that the remote has entered into learning mode.
- 2. Point the infrared sensor of your TV remote at the infrared sensor of the Air mouse and keep the distance about 1cm.
- 3. Press any custom key (V-, V+, CH-, CH+, TV/AV) on the Air Mouse. If the indicator starts blinking, this means that the particular key can be programmed to work with your TV.
- 4. Press any key on your TV remote that you want to program on the Air Mouse for 2 seconds. The indicator will stop blinking. The particular key is now re-programmed on your Air Mouse.
- 5. Repeat steps 3-4 to learn / reprogram more functions / keys.
- 6. To save the settings and exit learning mode, press "SET" key on the Air Mouse. The indicator will be turned off.
- 7. The learning mode will automatically exit if reprogramming the key takes more than 2 minutes. The indicator will blink twice before exiting the learning mode.

VPN

- You can set up VPN connection on box by selecting VPN option on the Home screen (Fig 1a).
- The first time you will setup a VPN connection it will ask you to set a passward on your box. You need to enter password to set the VPN. (Choose a password you'll remember. It should be memorable for you.)



(Fig 1a)



You will see your VPN connection on the screen.



- Enter your username and password given to you by your VPN service provider.
- Select the connect button as shown in figure 1c.






(Fig 1c)

Diagnostics

- You can go to Diagnostics on box by selecting Diagnostics option on the Home screen (Fig k1).
- Product Info will show your box information including box ID, firmware version, application version etc (Fig k2).
- Connectivity option will show connectivity with home network, internet and server. It will also run a speed test after connectivity checks (Fig k3).
- To check the internet speed on box, run the speed test from diagnostics as shown in Figure k4.
- User Info will show you the email address to which your box is registered and your home country. (Fig k5).
- Clear Cache will clear cached data for jadooTV[®] application (Fig k6).
- If you are having any problem after the setup, please contact JadooTV[™] support and they will help you in getting the debug information from the box if necessary (Fig k7).



Initial Setup using Setup Wizard


Starting the Setup Wizard

 To launch "Setup Wizard", select "Setup" from home page using the "Arrow Keys" on the remote and then press the "OK" (Fig a).



(Fig a)


 Setup will be launched with "Setup Wizard" highlighted in the Menu (Fig b). Follow the steps to complete the setup.



(Fig b)

Step 01: Connection Type

- You can select either a "Wired" or a "Wireless" connection by using the "Arrow Keys" and then pressing the "OK" button as shown in Figure 1.
- If you select a wired connection, the setup wizard will take you to Step 2 with Wired Network Connection option (Fig 2a).
- If you select a wireless connection, the setup wizard will take you to Step 2 with Wireless Network Connection option (Fig 2d).



Setup Guide

Check Updates

available for box (Fig j).

Check Updates »

Setup

You can view video tutorials for box installation, setup guide and other features (Fig h).

Setup Guide •		

You can use this option to check if a new update is

Your box is up to date.

(Figj)

hickor 🖉

About Box

About box will show your box information including box ID, firmware version, application version etc (Fig i).

	IP Address	1921681.92	
	Subnet Mask		
	Default Gateway		
	Primary DNS		
	Secondary DNS		
	Box ID		
About Box)	Firmware Version	V0038001_20141219	
	Android Version		
	Launcher Version		

(Fig i)

Advance Options

This wil take you to the advance android options (Fig k).



(Fig k)

Step 02: Wired Network Connection

- "Auto" option is already selected. Go to 'Next' button as shown in Figure2a.
- The setup wizard will start configuring the IP automatically as shown in the Figure 2b.



Display Settings

This will show you all the supported resolutions by your TV. You can change the display settings by selecting the resolution (Fig d).



Internal Storage

This will show you the total and used space on your box (Fig e).



Time Settings

You can change time zone according to your location. You can change time format as well (Fig f).



User Account

You can reset your password in case if you forgot (Fig g).

Setup		Jupo
	Logout	
	Forgot Password	

Once the IP configuration is done, select the next button to move to Step 3 (Fig 2c).



Step 02: Wireless Network Connection (Optional)

- If you have selected Wireless Connection in "Step 01" then you will see "Step 02" as shown in Figure 2d. All available networks list will be shown. Select your network using the arrow keys on remote and then press "OK" button on remote.
- The wizard will ask you to enter the password for your wireless network and show you a soft keyboard at the bottom of the screen (Fig 2e).

A salous			Network Gettings			
	Connect to your wired or wireless network.		1911697			
Internet01.(W	PA)	(a	totoetal Stratupe		eless network requires a seword to connect.	
the Cettinger (Internet02 (W	PAZI	+ 7	- Title Schings	590	Network 01	
init Account Internet03 (W	EP)	а т	Main Account	Security:	WPA2 TKIP	
Internet04 (W	PAL		Service Reads			
About free InternetOS (W	PA21		About Box	Passeord		
ck Updates Internet05 (W	EP)		Chedi: Opdotes			2 Dane
			Advance deports			C III Laure
					T I Day Sugard 1	CU 22

(Fig 2e)

- - 16

pdool

- By default the password you will type will be hidden. To show the password, select the "Show Password" button on the soft keyboard and then press the "OK" button on the remote (Fig 2f) (Optional).
- Type your password by selecting the keys on the soft keyboard using the "Arrow Keys" and "OK" button on the remote. When finished entering the password, select the "DONE" button on the soft keyboard and press the "OK" button on the remote (Fig 2g).
- The setup wizard will verify the passward and start configuring the IP automatically as shown in the (Fig 2h).
- Once the IP configuration is done, select the "Next" button to move to Step 3 (Fig 2i).





Network Settings

pdan

WPA2 TKIP

123456789

You can select either a "Wired" or a "Wireless" connection by using the "Arrow Keys" and then pressing the "OK" button as shown in Figure a.

 The network settings will automatically establish an internet connection. Once the internet connection is established, select "Next" button to go to next step (Fig b).

The last step of the network settings will show the

internet connection status (Fig c).



Setup

Network Settings





- Use the "Down Arrow" button on the remote to go to "Temperature Scale" and press "OK" button on remote to select it (Fig 5c).
- Select "Celcius (°C)" or "Fahrenheit (°F)" and then press the "OK" buttom on remote (Fig 5c).



Step 03: Network Status

 The setup wizard will automatically establish an internet connection (Fig 3).
 Once the internet connection is established select "Next" button to move to step4.





Press the "Down Arrow" button on the remote to select the "Finish" button at the bottom of your TV screen and then press the "OK" button on the remote (Fig 5d).



Step 04: Time Settings

 Press the "OK" button on the remote with the "Time Zone" already selected (Fig 4a).





- Select the "Time Format" option by pressing the "Down Arrow" button and then press the "OK" button on the remote. Select from the "12 Hours" or "24 Hours" format and then press the "OK" button on the remote (Fig 4c).
- Press the "Down Arrow" button on the remote to select the "Next" button at the bottom of TV screen and then press the "OK" button on the remote to go to Step 5 (Fig 4d).

Step 05: Widgets Settings

 Press the "OK" button on the remote with "Your Location" already selected (Fig 5a).




(Fig Sa)

 A soft keyboard will appear on the screen. Now type your city name (Fig 5b). Once done, select the "DONE" button on the soft keyboard and press the "OK" button on the remote.



(Fig 5b)





(Fig 4d)

FCC 15.19 Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the

following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. The distance between user and products should be no less than 20cm. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.