

User manual

Yepzon™ Freedom



Yepzon Freedom is a personal alarm system that works with your smartphone or tablet.

The package contains one Yepzon Freedom, and a USB charger.

Getting started:

Before use

When you first start using your Yepzon Freedom, charge the battery for two hours. This ensures optimal performance and battery life.

Pairing the Yepzon Freedom to your smartphone or tablet for the first time

1. Download the Yepzon App to your smartphone or tablet from Google Play or the Apple Store.
2. Run the App and select **Add a Yepzon**. The welcome screen appears.
3. Select **Yepzon Freedom** on the screen.

Note: If you have trouble pairing the device to your phone, make sure the Wi-Fi on your smartphone or tablet is enabled. If the problem persists, attach the Yepzon Freedom to the charger and try again.

3. The App requests the QR code, which you can find printed on a leaflet in the sales box.
4. Select **Connect Yepzon**.

The Yepzon Freedom is connected to your smartphone or tablet and you can start using it.

Adding more users

Use the Yepzon App to connect your Yepzon Freedom to another smartphone or tablet. Please note that it cannot be paired again using the QR code.

You can add more users to your Yepzon Freedom on **Settings – General – Manage access rights – Add user**

Recommended precaution: Requesting a reset link

If the only smartphone or tablet your Yepzon Freedom is connected with is lost or broken, or you accidentally remove the Yepzon App without removing the user rights from the Yepzon device(s) first, Yepzon Freedom cannot be connected to another smartphone or tablet without a **reset**. To avoid losing the use of your Yepzon Freedom, you should request a reset link.

1. Run the Yepzon App on your device.
2. Select a Yepzon.
3. Select **Settings**.
4. Select **Create a restore link**.
5. Enter your e-mail address and select **Send**.

A message containing the reset link will be in your inbox in a few minutes.

Changing Modes

Yepzon Freedom has three Modes for optimal use in different situations. Pressing the button on the Yepzon Freedom sends its location to the Yepzon App in all Modes, and a push notification with specific SOS signal is shown and played by the phone, capturing your attention. Change between Modes by selecting Settings and then selecting the Mode you want to use.

Quick location Mode

- This is the factory setting of your Yepzon Freedom.
- The Yepzon Freedom can be located right away through the Yepzon App or by pressing the alarm button on the Yepzon Freedom.
- This mode uses less data but more power. Battery life will be about 1 day.

Use this Mode for active tracking, for example for a small child. Location data is available right away on the Yepzon App.

Battery Saving Mode

- In this Mode, Yepzon Freedom connects the Yepzon Cloud only at preset intervals, so the accurate location is not available instantly but after the next connection
- User can optimize the connection intervals between a short delay to get the accurate location and a long battery life.
- Battery life is from a few days up to several weeks depending on settings and usage.
- In this Mode, the Yepzon Freedom works similarly like the Yepzon One.

Use this Mode when you want to prolong the battery life and you can tolerate some delay in getting the accurate position. You can set the connection intervals in the Yepzon App. When accurate location is requested, the Yepzon Freedom starts the positioning right after the next connection to the Yepzon Cloud. The longer the connection interval, the longer the delay for starting the positioning but the longer the battery life as well.

SOS Only Mode

- Yepzon Freedom can only be located by pressing the alarm button.
- Yepzon Freedom cannot be located through the Yepzon App. Only battery status is available on the Yepzon App.
- Battery life will be several months.

Use this Mode when you want to have a personal alarm for someone who prefers not being tracked on the Yepzon App and does not want to pay attention to the battery charge frequently.

Setting notifications

Yepzon Freedom can be set to send notifications for specific situations, for example when Yepzon Freedom starts moving after a period of stillness.

1. Run the Yepzon App on your device
2. Select a Yepzon
3. Select **Settings**
4. Select **Edit Notifications**
5. Check the boxes for the events you want to be notified of.

Safety

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product meets applicable national SAR limits of 1.6W/kg. The specific maximum SAR values can be found at yepzon.com/support. When carrying the product, or using it while worn on your body, either use an accessory such as a holster or otherwise maintain a distance of 0,5 cm from the body to ensure compliance with RF exposure requirement.