




# DRUM CAMERA

Quick Manual for Android and iOS


Hangzhou Xiongmai Technology Co.,Ltd

## Packing list

After open packing list box ,please check product body and accessories as blow:




Drum camera×1 Power cable×1 Power adapter×1




Accessories kit×1 3M Traceless glue×2 Metal flake×1

## Interface

Before use ,please pay attention to the interface and button of camera.



Front



Back

## Operation

### 1.Download APP

Tips one:Scan QR code.




Android iOS

Tips two :Search "iCSee" in the App store or Googleplay and download.

### 2 Power on

Connect the camera to the power outlet .When the indicator light is red, indicating that the camera power is switched on.




### 3.Camera configuration

#### ★User login


01.open the app "iCSee",choose the "login" (picture 1) (If you don't have user name, please register first).

02.After Click "+" (picture 2).

picture 1



picture 2




picture 3




picture 4



picture 5



picture 6



picture 7



03.Enter to "Add device "(picture 3),please input WiFi router password (picture 4),Then confirm .

04.After you hear a camera voice "connect successfully ",will enter to "set pwd"Then confirm(picture 5).

05.After "confirm "will enter to "pick a name"(picture 6).


06.After click "save " will enter to video preview(picture 7).

## ★FAQ

**Q: How to store a video camera?**  
**A:** Currently, the camera supports FAT32G format Class6, Class10 TF Card, max supports 128G. When the TF Card is full, it will delete earlier video automatically and loop recording.

**Q: The camera be offline, how to do?**  
**A:** Check the power and WiFi.  
Restart power on and restart the camera.  
Reconfigure the camera.  
Check the home broadband network.

**Q: How to switch network environment?**  
**A:** When using in the new network environment, please long press the reset button (SET) for 6 seconds release the button. It means that restored to factory setting successfully. Then you can start to connect network configuration again.



- Open App "iCSee", choose temporary visit.
- click the upper right "+", according to promote tips ,finish add camera.
- Please refer to the "User model-02/03" introduce operation.

## Directions

App and device firmware will have new update irregularly,you could upgrade it online at app setting,instructions are for reference only.

**Notice**  
While using this product, please modify the user password, to avoid the delinquents misappropriation.  
Do not install the equipment in damp, dusty, children easy access to the venue.  
Please allow within the scope of use and storage of temperature and humidity, do not disassemble it at will.

## Warranty Card

|                |  |                 |  |
|----------------|--|-----------------|--|
| Product Name   |  | Model           |  |
| Purchase Date  |  | Purchase Store  |  |
| Cause          |  |                 |  |
| Process        |  |                 |  |
| Customer Name  |  | Customer Gender |  |
| Customer Phone |  | ZIP             |  |
| Address        |  |                 |  |

Warranty period:one year.  
This warranty card is only for our company's products.

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **FCC Radiation Exposure Statement:**

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.