

USER MANUAL



ELEMENT PRO 2



Read the instruction manual before
start operating the smartphone

Thank you for purchasing this KALLEY product.
For more information please visit us at
www.kalley.com.co or contact us for free
to the line 01 8000 524 065

Kalley[®]



Content

3. Know your phone
4. How to use the telephone keys
4. Language
4. Dialing
5. Message
5. Video clips
6. gallery
6. Text editing
7. Photography
7. Gmail GO
8. Music
8. Environmental conditions
8. Environmentally friendly disposal
9. Environment

WARNING:

To reduce the risk of electric shock, do not remove the cover, there are no parts inside that can be repaired by the user, consult qualified service personnel.

IMPORTANT:

Read this user manual carefully so that you become thoroughly familiar with your new product before first use.

DEAR CUSTOMER:

Thank you for purchasing this KALLEY product. To ensure your safety and long time of use without inconvenience with your product, please read carefully the safety instructions.

The contents of this manual may differ in certain aspects of the description of your phone depending on the version of your software and your telephone operator.



Image for your reference



Know your phone

1. Receiver
2. Front camera
3. Screen
4. Volume
5. On / off
6. Earphone
7. Charger
8. Speaker / Speaker
9. Main camera
10. Flash
11. Fingerprint sensor



Operating Instructions



How to use the phone keys

On any screen:

Touch "<" to return to the previous screen or to exit the application.

Touch "o" to return to the main menu.

Touch "□" to show / delete all recent applications.

Touch the "on / off" button to turn the screen on and off and lock the screen.

Press and hold the "on / off" button to turn off or restart your mobile device.

Press and hold the "on / off" button and then press the volume down key to take a screenshot.

Language

Touch the configuration icon. Scroll down and touch the "language and the entry", then select the language in the language field.

Dialling

When you press the button on a phone number in the contacts application, you will make a phone call. Or press on the calling application and then make a phone call. Or make a phone call using the dial pad in the "dial" applications.



DIALLING



Messages


Touch the "messages" icon. Then you can send a message to another user. Enter the names and phone numbers in the corresponding field, or select someone in the contact list, then press the "send" button after entering the message.



MESSAGES

Video clips

Touch the "camera" icon to open the camera, switch to video mode.

Touch the "  " icon, ready for video clips of important moments of your life at any time.



CAMERA

Operating Instructions



Gallery

Touch the "gallery" icon to open the albums.

Feel free to browse through the photographs, moving memories.

View a photo, touch the "⌘" icon to enter edit mode, you can crop photos, adjust color filter effects, how to increase landscape adjustment functions.



PHOTOS

Text editing

The ELEMENT PRO 2 mobile phone will have some recommendations when you are writing. If you want to edit a text, choose the text and then press it or holding for several seconds, move the insertion point or use the Select all, cut and copy mode.

+ Hola





Photography

Touch the "camera" icon to open the camera. The ELEMENT PRO 2 mobile phone supports a variety of intelligent beauty images, HDR, panorama mode, automatically smile identification mode. The characteristics of the camera allow to take photos with many alternatives.



CAMERA

Gmail GO

Touch the "Gmail" icon.

After you set up your email account, you can send and receive messages through your mobile phone, you can stay in touch with friends or customers anytime, anywhere.



GMAIL

Operating Instructions



Music

Touch the "music" icon.

You can play songs by artists, albums, songs, and other models.



Google Play music

This app must be downloaded by the user from the Play Store.

Environmental conditions

Operating temperature: 0 ~ 40 ° C

Operating humidity: 65 +/- 20% RH

Environmentally friendly disposal

You can help protect the environment!

Please remember to respect the local regulations:

- Dispose of electrical equipment that does not work to an appropriate waste disposal center.
- Be aware of the warning that batteries (battery pack or batteries installed) should not be exposed to excessive heat such as direct sunlight, fire or the like.
- Caution: risk of explosion if the battery is replaced by an incorrect type of battery.
- Charge at a constant current until the voltage reaches 4.35V

Emergency call

If any emergency arises, dial 112/911 (or other emergency call number) for emergency help.

Due to the nature of cellular networking, the success of emergency call is not guaranteed.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types ELEMENT PRO 2 (FCC ID: 2AEP2ELEMENTPRO2) has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory, and product specific (Hotspot) are 0.66 W/kg, 0.78 W/kg, and 1.11 W/kg respectively. The Max simultaneous SAR is 1.30 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The logo features the word "Kalley" in a bold, white, sans-serif font. A white, curved line arches over the letters "a" and "l", starting above the "a" and ending above the "l". A registered trademark symbol (®) is positioned to the upper right of the word.

Kalley®